



Technical Specification 41-24

Issue <1> 2016

Guidelines for the Design, Installation, Testing
and Maintenance of Main Earthing Systems in
Substations

© <year of publication> **Energy Networks Association**

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Energy Networks Association. Specific enquiries concerning this document should be addressed to:

**Operations Directorate
Energy Networks Association
6th Floor, Dean Bradley House
52 Horseferry Rd
London
SW1P 2AF**

This document has been prepared for use by members of the Energy Networks Association to take account of the conditions which apply to them. Advice should be taken from an appropriately qualified engineer on the suitability of this document for any other purpose.

<Insert publication history here, e.g. "First published, December, 2011">

Amendments since publication

Issue	Date	Amendment
Issue <1>	<April, 2016>	Draft updated in line with comments from previous meeting. References to S34 highlighted for discussion at April Meeting. Some comments included in body for guidance. Other changes accepted and tracked changes removed [RW].
	June 2016	Minor changes for review at June meeting
	August 2016	Edits following June meeting. All changes accepted. Yellow highlight for S34 references remaining. TO DO: Case studies at end of document. Flow chart.

1	Contents	
2	Foreword	9
3	1 Scope	10
4	2 Normative references	10
5	3 Definitions	11
6	4 Fundamental Requirements	15
7	4.1 Function of an earthing system.....	15
8	4.2 Typical features of an earthing system.....	15
9	4.3 The effects of substation potential rise on persons.....	16
10	4.3.1 Touch potential	17
11	4.3.2 Step potential	17
12	4.3.3 Transfer potential	17
13	4.3.4 General	17
14	4.3.5 Limits for LV networks	18
15	4.3.6 Limits for Other systems	18
16	4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites).....	18
17	4.4 Safety criteria	18
18	4.4.1 General ‘permissible’ design limits	18
19	4.4.2 Effect of electricity on animals	22
20	4.4.3 Injury or shock to persons and animals outside the installation	22
21	4.5 Electrical Requirements	23
22	4.5.1 Method of neutral earthing.....	23
23	4.5.2 Fault Current	23
24	4.5.3 Thermal effects - general.....	23
25	5 Design	25
26	5.1 General approach (flowchart)	25
27	5.2 Design Considerations	26
28	5.2.1 Limiting values for EPR	26
29	5.2.2 Touch and Step voltages	26
30	5.2.3 Factors to include in calculation of EPR and Safety Voltages.....	26
31	5.2.4 Transfer Potential.....	26
32	5.3 Preliminary Arrangement and Layout	27
33	5.4 Design Guidelines	27
34	5.4.1 Outdoor Substations	27
35	5.4.2 Indoor Substations	28
36	5.4.3 Shared Sites.....	29
37	5.4.4 Distribution (or ‘Secondary’) Substations	29
38	5.4.5 Metallic Fences	29
39	5.4.6 Provision of Maintenance/Test facilities	30
40	5.5 Design data	30
41	5.5.1 Soil Resistivity	30
42	5.5.2 Fault currents and durations - general	31
43	5.5.3 Fault currents for EPR and safety voltage calculations	32

44	5.5.4	Fault currents and clearance times for conductor size calculations	33
45	5.5.5	Fault currents and clearance times for electrode size calculations	33
46	5.5.6	Fault current growth	36
47	5.6	Conductor and Electrode Ratings	36
48	5.6.1	Earthing Conductors	36
49	5.6.2	Electrode Surface Current Density Ratings	42
50	5.7	Design Assessment	44
51	5.7.1	Assessment Procedure.....	44
52	5.7.2	Methods to improve design (Mitigation measures)	45
53	5.7.2.1	EPR reduction.....	45
54	5.7.2.2	Touch Voltage reduction.....	46
55	5.8	Risk Assessment.....	46
56	6	Construction of Earthing Systems	48
57	6.1	General Design Philosophy	48
58	6.1.1	Materials.....	48
59	6.1.2	Avoiding Theft	48
60	6.2	Jointing Conductors and Equipment Connections	49
61	6.2.1	General	49
62	6.2.2	Transition washers.....	49
63	6.2.3	Copper to Copper Connections	50
64	6.2.4	Copper to Earth Rods	50
65	6.2.5	Electrode Test Points.....	50
66	6.2.6	Copper to Equipment (Steel, or Galvanised Steel) Connections.....	50
67	6.2.7	Aluminium to Equipment Connections	50
68	6.2.8	Aluminium to Aluminium Connections.....	51
69	6.2.9	Aluminium to Copper Connections	51
70	6.2.10	Earthing Connections to Aluminium Structures.....	52
71	6.2.11	Steel Structures	52
72	6.3	Above Ground Earthing Installations	53
73	6.3.1	Fixing Above Ground Conductor to Supports	53
74	6.3.2	Prevention of Corrosion of Above Ground Conductors	53
75	6.3.3	Metal Trench Covers	53
76	6.3.4	Loops for Portable Earth Connections	54
77	6.4	Below Ground Earthing Installations	54
78	6.4.1	Installation of Buried Electrode within a Substation	54
79	6.4.2	Positioning of Buried Electrode	54
80	6.4.3	Other Earth Electrodes	55
81	6.4.3.1	Earth Rods	55
82	6.4.3.2	Earth Plates	56
83	6.5	Use of Structural Earths including Steel Piles and Rebar.....	56
84	6.5.1	Sheet Steel Piles.....	56
85	6.5.2	Horizontal Steel Reinforced Foundations.....	56
86	6.5.3	Vertical Steel Reinforced Concrete Columns.....	57
87	6.6	Metallic Fences	57

88	6.6.1	Independently Earthed Fences.....	57
89	6.6.2	Segregation between independently earthed fence and earthing	
90		system.....	58
91	6.6.3	Fences Bonded to the Substation Earthing System	59
92	6.6.4	Third Party Metallic Fences	60
93	6.6.5	Insulated Fence Sections.	60
94	6.6.6	Chain Link Fencing (Galvanised or Plastic Coated)	61
95	6.6.7	Coated Fence Panels	61
96	6.6.8	Electric Security Fences	61
97	6.6.9	Anti-climbing Precautions	61
98	6.7	Specific Items	61
99	6.7.1	Water Services to Substations	61
100	6.7.2	Non-current carrying metalwork	62
101	6.7.3	Items normally bonded to the main earth grid:.....	62
102	6.7.4	Items NOT normally bonded to the Earth Grid.....	62
103	6.7.5	Non-standard bonding arrangements.....	63
104	6.8	Overhead Line Terminations.....	63
105	6.8.1	Tower Terminations Adjacent to Substation	63
106	6.8.2	Steel Tower Termination with Cable Sealing Ends.....	63
107	6.8.3	Terminal Poles with Stays Adjacent to Substation Fence	63
108	6.8.4	Down drop Anchorage Arrangement with Arcing Horns	64
109	6.8.5	Loss of Aerial Earth Wires	64
110	6.9	HV Cable Metallic Sheath / Armour Earthing	64
111	6.9.1	Insulated (Polymeric) Sheath Cables	64
112	6.9.2	Cables Entering Substations	65
113	6.9.3	Cables Within Substations.....	65
114	6.9.4	Outdoor Cable Sealing-Ends.....	65
115	6.9.5	Use of Disconnected, Non-Insulated Sheath/Armour Cables as an	
116		Electrode	66
117	6.10	Light-current Equipment Associated with External Cabling	66
118	6.11	Metal Clad and Gas Insulated (GIS) Substations.....	66
119	6.11.1	Metal Clad Substations.....	66
120	6.11.2	Gas Insulated Switchgear (GIS)	66
121	6.12	Fault Throwing Switches, Earth Switches and Disconnectors	67
122	6.12.1	Background.....	67
123	6.12.2	Fault Throwing Switches (Phase - Earth).....	68
124	6.12.3	Earth Switches	68
125	6.12.4	Isolators.....	68
126	6.13	Operating Handles, Mechanisms and Control Kiosks.....	68
127	6.13.1	Background.....	68
128	6.13.2	Earth Mats (Stance Earths)	68
129	6.13.3	Connection of Handles to the Earth Grid and Stance Earths	69
130	6.14	Surge Arrestors and CVTs.....	69
131	7	Measurements	71

132	7.1	General.....	71
133	7.2	Safety	71
134	7.3	Instrumentation and Equipment.....	71
135	7.4	Soil Resistivity Measurements	72
136	7.4.1	Objective	72
137	7.4.2	Wenner Method	72
138	7.4.3	Interpretation of Results.....	72
139	7.4.4	Sources of Error	72
140	7.4.5	Driven Rod Method	73
141	7.5	Earth Resistance/Impedance Measurements	74
142	7.5.1	Objective	74
143	7.5.2	Method	74
144	7.5.3	Interpretation of Results.....	74
145	7.5.4	Sources of Error	75
146	7.6	Comparative Method of Measuring Earth Resistance.....	76
147	7.6.1	Objective	76
148	7.6.2	Method	76
149	7.6.3	Interpretation of Results.....	77
150	7.6.4	Sources of Error	77
151	7.7	Earth Connection Resistance Measurements (Equipment Bonding Tests).....	78
152	7.7.1	Objective	78
153	7.7.2	Method	78
154	7.7.3	Interpretation of Results.....	78
155	7.8	Earth Conductor Joint Resistance Measurements.....	79
156	7.8.1	Objective	79
157	7.8.2	Method	79
158	7.8.3	Interpretation of Results.....	79
159	7.9	Earth Potential Measurements	79
160	7.9.1	Objective	79
161	7.9.2	Method	80
162	7.9.3	Interpretation of Results.....	80
163	7.10	Earth Electrode Separation Test.....	80
164	7.10.1	Objective	80
165	7.10.2	Method	80
166	7.10.3	Interpretation of Results.....	80
167	7.11	Buried Earth Electrode Location	81
168	7.11.1	Objective	81
169	7.11.2	Method	81
170	8	MAINTENANCE.....	82
171	8.1	Introduction.....	82
172	8.1.1	Inspection.....	82
173	8.1.2	Maintenance and Repairs.....	82
174	8.2	Types of Inspection	83
175	8.2.1	Introduction	83

176	8.2.2	Frequent Visual Inspection	83
177	8.2.3	Infrequent Detailed Visual Inspection	83
178	8.2.4	Detailed Visual Inspection, Testing and Analysis	84
179	8.2.4.1	Testing	84
180	8.2.4.2	Selected Excavation and Examination of Buried Earth	
181		Electrode	85
182	8.2.4.3	Analysis and Recording of Test Results	85
183	8.3	Maintenance and Repair of Earthing Systems	86
184	8.4	Procedure for the Remaking Defective Joints or Repairing Conductor	
185		Breaks	87
186	8.4.1	Introduction	87
187	8.4.2	Joint Repair Methods	87
188	8.4.3	Flexible Braids	88
189	9	Ground Mounted Distribution Substation Earthing	89
190	9.1	Introduction.....	89
191	9.2	Relocation of Pole Mounted Equipment to Ground Level	89
192	9.3	General design requirements.....	89
193	9.3.1	Design Data Requirements.....	90
194	9.3.2	Conductor and electrode sizing	90
195	9.3.3	Target resistance	90
196	9.3.4	EPR design limit.....	91
197	9.3.5	Calculation of EPR.....	91
198	9.3.5.1	Factors to consider:	91
199	9.3.5.2	Transfer Potential from source	92
200	9.3.6	Step/Touch Potentials at the Substation	92
201	9.3.7	Simplified approach	92
202	9.4	Network and other contributions	93
203	9.4.1	Additional Electrode	93
204	9.4.2	Parallel contributions from interconnected HV and LV networks.....	93
205	9.4.3	Ascertaining Network Contribution	94
206	9.4.4	Global Earthing Systems	94
207	9.5	Transfer Potential onto LV network	95
208	9.5.1	General	95
209	9.5.2	Touch voltage on LV system as a result of HV faults	95
210	9.5.3	Stress Voltage.....	96
211	9.6	Combined HV and LV earthing	96
212	9.7	Segregated HV and LV earthing.....	96
213	9.7.1	Separation Distance	96
214	9.7.2	Transfer voltage to third parties.....	97
215	9.7.3	Further Considerations	98
216	9.7.4	Multiple LV electrodes on segregated systems.....	98
217	9.8	Situations where HV/LV systems cannot be segregated	98
218	9.9	Practical Considerations	99
219	9.10	LV installations near High EPR sites	99

220	9.11	Supplies to/from High EPR (HPR) sites	99
221	9.11.1	Special Arrangements	100
222	10	Pole Mounted Substation and Equipment Earthing	101
223	10.1	General Comments & Assumptions.....	101
224	10.2	Pole Mounted Transformers	101
225	10.3	Electrode Configuration for Pole Mounted Equipment	102
226	10.4	HV Earth Electrode Value	103
227	10.5	Electrode Arrangement Selection Method.....	103
228	10.6	Earthed Operating Mechanisms Accessible From Ground Level	104
229	10.7	Air Break Switch Disconnecter (ABSD) with an isolated operating	
230		mechanism.....	108
231	10.8	Surge Arresters	110
232	10.9	Cable Terminations	110
233	10.10	Operations at Earthed Equipment Locations.....	111
234	10.11	Installation	111
235	10.12	Inspection & Maintenance of Earth Installations	112
236	10.12.1	Items to Inspect.....	112
237	10.12.2	Items to Examine	112
238	10.12.3	Items to Test	112
239	11	Case studies / examples	114
240			
241			
242			

243 **Foreword**

244 This Technical Specification (TS) is published by the Energy Networks Association (ENA)
245 and comes into effect from **January, 2017**. It has been prepared under the authority of the
246 ENA Engineering Policy and Standards Manager and has been approved for publication by
247 the ENA Electricity Networks and Futures Group (ENFG). The approved abbreviated title of
248 this engineering document is “ENA TS 41-24”.

249 This Specification is to be used in conjunction with **Engineering Recommendation S34**
250 (2015). In this document account has been taken of:

- 251 (i) UK Adoption of BS EN 50522:2010 (Earthing of Power Installations Exceeding
252 1kV a.c.), in particular with reference to acceptable touch/step voltage limits
253 derived from IEC/TS 60479-1:2005 (Effects of current on human beings and
254 livestock);
- 255 (ii) changes to earthing practice as outlined in ESQC (Electrical Safety, Quality, and
256 Continuity) Regulations, 2002, in particular with regard to smaller ‘distribution’ or
257 ‘secondary’ substations. These are described in Sections 9 and 10 of this
258 specification;
- 259 (iii) the requirements for Protective Multiple Earthing systems as outlined in
260 Engineering Recommendation G12. (The relevant items concerning substation
261 earthing in EREC G12/4 have now been transferred to this document);
- 262 (iv) the increasing use of plastic sheathed cables;
- 263 (v) the differing requirements of earthing systems at various voltages and for differing
264 types of substation installation.

265

266 **1 Scope**

267 This Specification applies to fixed earthing systems for all electricity supply systems and
268 equipment earthing within EHV, HV and HV/LV substations.

269 It also applies to:

- 270 (i) terminal towers adjacent to substations and cable sealing end compounds;
- 271 (ii) pole mounted transformer or air-break switch disconnecter installations;
- 272 (iii) pole mounted reclosers with ground level control.

273 It does not apply to earthing systems for quarries and railway supply substations.

274 **2 Normative references**

275 The following referenced documents, in whole or part, are indispensable for the application of
276 this document. For dated references, only the edition cited applies. For undated references,
277 the latest edition of the referenced document (including any amendments) applies.

278 BS 7430:2011+2015 (Code of Practice for Protective Earthing of Electrical Installations)

279 ESQC (Electrical Safety, Quality, and Continuity) Regulations, 2002 (As amended)

280 BS EN 50522:2010 (Earthing of Power Installations Exceeding 1kV a.c.)

281 IEC/TS 60479-1:2005 (Effects of current on human beings and livestock). (Part 1 – General
282 Aspects)

283 IEC/TR 60479- 3 – (Effects of currents passing through the body of livestock)

284 ITU-T: Directives concerning the protection of telecommunication lines against harmful
285 effects from electric power and electrified railway lines: Volume VI: Danger, damage and
286 disturbance (2008)

287 CIGRE Working Group 23.10 Paper 151 (044) (Dec. 1993): Earthing of GIS – An Application
288 Guide

289 Other references as included in this document: ER 134, S34, BS EN 62305, IEEE 80, IEEE
290 81, BS EN 62561-2

291

292

293 **3 Definitions**

APPROVED EQUIPMENT	Equipment Approved in operational policy document for use in the appropriate circumstances.
AUXILIARY ELECTRODE	See SUPPLEMENTARY ELECTRODE
BACKUP PROTECTION	Protection set to operate following failure or slow operation of primary protection – see NORMAL PROTECTION below. For design purposes the backup protection clearance time may be taken as a fixed (worst case) clearance time appropriate to the network operator's custom and practice.
BONDING CONDUCTOR	A protective conductor providing equipotential bonding.
CROSS COUNTRY FAULT	Two or more phase-to-earth faults at separate locations and on different phases. Effectively this creates a phase-phase fault with current flowing through earth electrode and/or bonding conductors. The result can be an increased 'EARTH FAULT CURRENT' for design purposes at some locations. CROSS COUNTRY FAULTS are usually considered only if a first phase-earth fault does not automatically clear within a short period, or if significant phase voltage displacement (neutral voltage displacement) could occur. If an accurate figure is not available, a value of 85% of the double phase-to-earth fault current may be assumed.
EARTH	The conductive mass of earth whose electric potential at any point is conventionally taken as zero.
EARTH ELECTRODE	A conductor or group of conductors in intimate contact with, and providing an electrical connection to, earth.
EARTH ELECTRODE POTENTIAL	The difference in potential between the 'EARTH ELECTRODE' and a remote 'EARTH'.
EARTH ELECTRODE RESISTANCE	The resistance of an 'EARTH ELECTRODE' with respect to 'EARTH'.
EARTH ELECTRODE RESISTANCE AREA	That area of ground over which the resistance of an 'EARTH ELECTRODE' effectively exists. It is the same area of ground over which the 'EARTH ELECTRODE POTENTIAL' exists.
EARTH FAULT	A fault causing current to flow in one or more earth-return paths. Typically a single phase to earth fault, but this term may also be used to describe two phase and three phase faults involving earth.
EARTH FAULT CURRENT	The worst case steady state (symmetrical) RMS current to earth, i.e. that returning to the system neutral(s) resulting from a single phase to earth fault. This is normally calculated (initially) for the 'zero ohm' fault condition. Depending on the circumstances, the value can be modified

by including 'earth resistance'. Not to be confused with 'GROUND RETURN' current which relates to the proportion of current returning via soil.

In some situations, particularly 'CROSS COUNTRY FAULTS', a different single phase to earth fault at two separate locations can result in 'EARTH FAULT CURRENT' (as seen at the fault-point) that does not return to the system neutrals yet should still be considered at the design stage.

EARTH POTENTIAL RISE (EPR) OR GROUND POTENTIAL	The difference in potential which may exist between a point on the ground and a remote 'EARTH'. Formerly known as RoEP (Rise of Earth Potential). The term 'GPR' (Ground Potential Rise) is an alternative form, not used in this standard.
EARTHING CONDUCTOR OR EARTHING CONNECTION	A protective conductor connecting a main earth terminal of an installation to an 'EARTH ELECTRODE' or to other means of earthing.
EARTH MAT	Definition requested by WPD. Group to decide form of words, e.g.: A buried or surface laid mesh or other electrode, usually installed at the operator position close to switchgear or other plant, intended to control or limit hand-feet TOUCH POTENTIAL.
EARTHING SYSTEM	The complete interconnected assembly of 'EARTHING CONDUCTORS' and 'EARTH ELECTRODES' (including cables with uninsulated sheaths).
EHV	Extra High Voltage, typically used in UK to describe a voltage of 33kV or higher.
ELECTRODE CURRENT	The current entering the ground through the substation's electrode system under earth fault conditions. This term is generally used in the context of electrode sizing calculations and is slightly different to Ground Return Current since the ground return current may flow through alternative paths such as auxiliary electrodes etc. For design purposes the electrode current may be taken as the worst case current flowing into a substation's electrode system under foreseeable fault conditions including, where relevant, the loss of metallic return paths and/or cross country faults.
GLOBAL EARTHING SYSTEM	An earthing system of sufficiently dense interconnection such that all items are bonded together and rise in voltage together under fault conditions. No 'true earth' reference exists and therefore safety voltages are limited.
GROUND RETURN CURRENT	The proportion of EARTH FAULT CURRENT returning via soil (as opposed to metallic paths such as cable sheaths or overhead earth wires) If there is a metallic return path for EARTH FAULT CURRENT (e.g. a cable screen or overhead earth wire), this

will typically convey a large proportion of the earth fault current. The remainder will return through soil to the system neutral(s). Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return currents may be applied to calculate the GROUND RETURN CURRENT. The GROUND RETURN CURRENT is used in EPR calculations as it flows through the resistance formed by a substation's overall earth electrode system (and that of the wider network) and thus contributes to voltage rise of that system. Annex I of BS EN 50522 describes some methods for calculating this component. Further guidance is given in ENA **EREC S34**.

GROUND VOLTAGE PROFILE

The radial ground surface potential around an 'EARTH ELECTRODE' referenced with respect to remote 'EARTH'.

HOT / COLD SITE

A HOT site is defined as one which exceeds ITU limits for EPR, typically these thresholds are 650 V (for reliable fault clearance time ≤ 0.2 seconds), or 430 V otherwise. The requirements derive from telecommunication standards relating to voltage withstand on equipment.

Note: These thresholds have formerly been applied as design limits for EPR in some areas. The terms HOT and COLD were often applied as a convenience (on the basis that many COLD sites do achieve safe step/touch limits) but do not relate directly to safe design limits for touch and step voltages in substations. Refer to 'HIGH EPR' below.

HIGH EPR / HPR

High Potential Rise resulting from an earth fault. An EPR greater than twice the permissible touch voltage limit (e.g. 466 V for 1 second faults on soil or outdoor concrete).

HV (High Voltage)

A voltage greater than 1kV and less than 33kV. Typically used to describe 6.6kV, 11kV and 20kV systems in UK.

MES (Main Earthing System)

The interconnected arrangement of earth electrode and bonds to main items of plant in a substation.

NORMAL PROTECTION OPERATION

Clearance of a fault under normal (usual) circumstances. The normal clearance time will include relay operating time and mechanical circuit breaker delays for all foreseeable faults, and may be calculated for design purposes. Alternatively a network operator may work to the 'worst case' protection clearance time applicable to the network in a given area. This time assumes that faults will be cleared by normal upstream protection and does not allow for e.g. stuck circuit breakers or other protection failures/delays. Certain parts of an earthing design should consider slower 'BACKUP PROTECTION' operation (see above) which allows for a failure of normal protection.

NETWORK OPERATOR	Owner or operator of assets. Includes DNO (Distribution Network Operator), IDNO (Independent or 'Inset' DNO) and Transmission Network Operator (TNO) as defined in the Distribution Code (DCode) or System Operator Transmission Code (STC) as appropriate.
SUPPLEMENTARY ELECTRODE	Electrode that improves the performance of an earthing system, and may increase resilience, but is not critical to the safety of the 'as designed' system.
STEP POTENTIAL	See Section 4.3.2 for definition.
STRESS VOLTAGE	Voltage difference between two segregated earthing systems, which may appear across insulators/bushings etc. or cable insulation.
TOUCH POTENTIAL	See Section 4.3.1 for definition.
TRANSFER POTENTIAL	See Section 4.3.3 for definition.
WITHSTAND VOLTAGE	The maximum STRESS VOLTAGE that can be safely permitted between items of plant or across insulation without risk of insulation breakdown or failure.

295 **4 Fundamental Requirements**

296 **4.1 Function of an earthing system**

297 Every substation shall be provided with an earthing installation designed so that in both
298 normal and abnormal conditions there is no danger to persons arising from earth potential in
299 any place to which they have legitimate access. The installation shall be able to pass the
300 maximum current from any fault point back to the system neutral whilst maintaining step,
301 touch, and transfer potentials within permissible limits (defined in Section 4.3) based on
302 normal* protection relay and circuit breaker operating times. In exceptional circumstances
303 where the above parameters may not be economically or practically kept below permissible
304 limits a probabilistic risk assessment may be carried out. Where this shows the risk to be
305 below accepted ALARP levels the level of earth potential rise mitigation may be reduced
306 (refer to Section 5.8).

307 The earthing system shall be designed to avoid damage to equipment due to excessive
308 potential rise, potential differences within the earthing system (stress voltages), and due to
309 excessive currents flowing in auxiliary paths not intended for carrying fault current.

310 The design shall be such that the passage of fault current does not result in any thermal or
311 mechanical damage [for backup protection clearance times] or damage to insulation of
312 connected apparatus. It shall be such that protective gear, including surge protection, is able
313 to operate correctly.

314 Any exposed normally un-energised metalwork within a substation, which may be made live
315 by consequence of a system insulation failure can present a safety hazard to personnel. It is
316 a function of the station earthing system to eliminate such hazards by solidly bonding
317 together all such metalwork and to bond this to the substation earth electrode system in
318 contact with the general mass of earth. Dangerous potential differences between points
319 legitimately accessible to personnel shall be eliminated by appropriate design.

320 The earthing system shall maintain its integrity for the expected installation lifetime with due
321 allowance for corrosion and mechanical constraints.

322 The earthing system performance shall contribute to ensuring electromagnetic compatibility
323 (EMC) among electrical and electronic apparatus of the high voltage system in accordance
324 with IEC/TS 61000-5-2.

325 **4.2 Typical features of an earthing system**

326 The earthing installation requirements are met principally by providing in each substation an
327 arrangement of electrodes and earthing conductors which act as an earthing busbar. This is
328 called the 'main earth grid' or 'main earth system' (MES) and the following are connected to
329 it:

- 330 (i) all equipment housing or supporting high voltage conductors within the substation
331 such as transformer and circuit breaker tanks, arcing rings and horns and metal
332 bases of insulators;
- 333 (ii) neutral connection of windings of transformers required for high voltage system
334 earthing. For high voltage systems the connections may be via earthing resistors
335 or other current limiting devices, as described in Section 4.4. (The neutral earthing
336 of low-voltage systems is separately considered in Section 9);

* See 'Definitions' in Section 3

- 337 (iii) earth electrodes, additional to the main earth grid which may itself function as an
338 earth electrode;
- 339 (iv) earth connections from overhead line terminal supports and the sheaths / screens
340 of underground cables;
- 341 (v) earth mats, provided as a safety measure, to reduce the potential difference
342 between points on the area of ground adjacent to manually operated plant and the
343 metalwork including handles of that plant (but see also 10.6);
- 344 (vi) 'Grading Electrodes' (intended to reduce touch voltages on equipment), which as
345 a minimum consist of a horizontal ring electrode around all items of earthed plant
346 and the equipment and bonded to it. This often must be supplemented by
347 additional grading electrodes inside the ring;
- 348 (vii) 'High Frequency Electrodes', conductors and electrodes specifically configured to
349 reduce the impedance to lightning, switching and other surges at applicable
350 locations, e.g. surge arresters, CVTs and GIS bus interfaces;
- 351 (viii) all other exposed and normally un-energised metalwork wholly inside the
352 substation perimeter fence, e.g. panels (excluding floating fence panels), kiosks,
353 lighting masts, oil tanks, etc. Conductive parts not liable to introduce a potential
354 need not be bonded (e.g. metal window frames in brick walls). Items such as
355 fences, cables and water pipes which are not wholly inside the substation are
356 separately considered in Sections 6.6 and 6.7.
- 357 (ix) Fences may be bonded to the main earth system in some situations – refer to
358 Section 6.6.

359 Substation surface materials, for example stone chippings which have a high value of
360 resistivity, are chosen to provide a measure of insulation against potential differences
361 occurring in the ground and between ground and adjacent plant. Although effective bonding
362 significantly reduces this problem the surface insulation provides added security under
363 system fault conditions. Permissible 'touch/step' voltages are higher where an insulated
364 surface layer is provided – refer to 'Safety Criteria' below.

365 **4.3 The effects of substation potential rise on persons**


366 During the passage of earth-fault current a substation earth electrode is subjected to a
367 voltage rise (Earth Potential Rise, or 'EPR', sometimes denoted as U_E). Potential gradients
368 develop in the surrounding ground area. These gradients are highest adjacent to the
369 substation earth electrode and the ground potential reduces to zero (or 'true earth potential')
370 at some distance from the substation earth electrode.

371 A person will be at risk if he/she can simultaneously contact parts at different potential; thus
372 in a well designed system the voltage differences between metallic items will be kept to safe
373 levels regardless of the voltage rise (EPR) on the system.

374 Ground potential gradients around the electrode system, if great enough, can present a
375 hazard to persons and thus effective measures to limit them must be incorporated in the
376 design.

377 The three main design parameters relate to 'Touch', 'Step' and 'Transfer' voltages as defined
378 below. These terms are shown as U_{VT} , U_{VS} and 'A' in Figure 1.

379



380

381

Figure 1 – Showing Touch, Step, and Transfer Voltages resulting from an earth fault

382

383 4.3.1 Touch potential

384 This term describes the voltage appearing between a person's hands and feet. It arises from
 385 the fact that the ground surface potential at a person's feet can be somewhat lower in value
 386 than that present on the buried earth electrode (and any connected metalwork). If an earthed
 387 metallic structure is accessible, a person standing on the ground 1 metre away and touching
 388 the structure will be subject to the 'touch potential'. For a given substation the maximum
 389 value of 'touch potential' can be up to two or three times greater than the maximum value of
 390 'step potential'. In addition, the permissible limits for step potential are usually much higher
 391 than for touch potential. As a consequence, if a substation is safe against 'touch potentials', it
 392 will normally be safe against 'step potentials'.

393 In some situations, the 'hand-hand' touch potential needs to be considered, for example if
 394 'unbonded' parts are within 2 metres. The permissible limits for this scenario can be
 395 calculated as described in IEC/TS 60479-1, using the body impedance not exceeded by 5%
 396 of the population. In general, such situations should be designed out, e.g. by increasing
 397 separation or introducing barriers if the systems must be electrically separate, or by bonding
 398 items together. The siting of fences needs consideration in this regard.

399 4.3.2 Step potential

400 As noted above, a potential gradient in the ground is greatest immediately adjacent to the
 401 substation earth electrode area. Accordingly the maximum 'step potential' at a time of
 402 substation potential rise will be experienced by a person who has one foot on the ground of
 403 maximum potential rise and the other foot one step towards true earth. For purposes of
 404 assessment the step distance is taken as one metre. This is shown as U_{VS} in Figure 1.

405 4.3.3 Transfer potential

406 4.3.4 General

407 A metallic object having length - a fence, a pipe, a cable sheath or a cable core, for example,
 408 may be located so as to bring in ('import') or carry out ('export') a potential to or from the site.

409 By such means a remote, or 'true earth' (zero) potential can be transferred into an area of
 410 high potential rise (HPR) or vice-versa. For example a long wire fence tied to a (bonded)
 411 substation fence could export the site EPR to the end of the wire fence, where it may pose
 412 an electric shock hazard to somebody standing on soil at 'true earth' potential. Similarly, a
 413 metallic water pipe (or telephone cable, or pilot cable, etc.) could 'import' a zero volt

414 reference into a substation, where local voltage differences could be dangerous. Bonding the
415 cable or pipe to the substation system might reduce local risk but could create a problem
416 elsewhere; isolation units or insulated inserts (for pipework) are typical solutions that may
417 need to be considered.

418 The limits for permissible transfer voltage relate to shock risk (Touch and Step Voltage), and
419 equipment damage / insulation breakdown (Stress Voltage).

420 **4.3.5 Limits for LV networks**

421 Safety criteria (as defined in Section 4.4.1) apply to the voltage that may be transferred to LV
422 networks. Further information is given in Section 9.5.

423 **4.3.6 Limits for Other systems**

424 Voltages carried to pipelines, fences, and other metallic structures during HV fault conditions
425 must not exceed permissible touch and step voltage limits as defined below (Section 4.4.1).
426 In some circumstances (for example pipelines connected to gas or oil pumping or storage
427 facilities), lower limits may apply as defined in relevant standards.

428 **4.3.7 Limits for Telecommunications Equipment (HOT/COLD sites)**

429 Care must be taken to ensure that telecommunications and other systems are not adversely
430 impacted by substation or structure EPR; in general these systems must be routed so that
431 the insulation withstand is not exceeded by passing through an area of high potential rise.
432 Where the EPR on substations (or structures) exceeds certain levels, the operators of these
433 systems must be notified. Refer to ENA ER S36 for more information.

434 ITU Directives† presently prescribe limits (for induced or impressed voltages derived from HV
435 supply networks) of 430 V rms or, in the case of high security lines, 650 V rms. (High security
436 lines are those with fast acting protection which, in the majority of cases, limits the fault
437 duration to less than 200 milliseconds.) Voltages above and below these limits are termed
438 'HOT' and 'COLD' respectively, although it should be noted that these terms do not relate
439 directly to safety voltages.

440 For telecoms connections to 'HOT' sites, consultation with telecommunications provider may
441 be necessary to arrive at a solution, e.g. isolation transformers or optic fibre links to ensure
442 the telecoms system is segregated from the substation earth.

443 **4.4 Safety criteria**

444 **4.4.1 General 'permissible' design limits**

445 An effective earthing system is essential to ensure the safety of persons in, and close to
446 substations, and to minimise the risk of danger on connected systems beyond the substation
447 boundaries. The most significant hazard to humans is that sufficient current will flow through
448 the heart to cause ventricular fibrillation.

449 The basic criteria adopted in this specification for the safety of personnel are those laid down
450 in BS EN 50522, which in turn derive from IEC/TS 60479-1. In addition, ITU-T directives are
451 considered where relevant, and where their limits might be lower than BS EN 50522.

452 The relevant limits for touch and step voltages are given in Tables 1 and 2 below.

453 These use the body impedance values not exceeded by 5% of the population, and the 'C2'
454 current curve as described in National Annexe NA of BS EN 50522:2010.

† (ITU-T: Directives concerning the protection of telecommunication lines against harmful effects from electric power and electrified railway lines: Volume VI: Danger, damage and disturbance (2008))

455 In selecting the appropriate limits, the designer must consider the type of surface covering,
456 and if footwear will be worn. Within substations, it should be assumed that footwear will be
457 worn. IEC/TS 60479-1 states that these design limits are sufficiently conservative to apply to
458 all humans including children; however it is recommended that further reference be made to
459 that standard, and relevant (lower) limits adopted as necessary if a substation is in close
460 proximity to, or might otherwise impinge on high risk groups.

461

Table 1 – Permissible touch voltages for typical fault clearance times:

Permissible touch voltages V ^(A)	Fault clearance time, seconds																			
	0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 ^(B)
Bare feet (with contact resistance)	521	462	407	313	231	166	128	106	92	84	80	76	73	71	69	67	63	60	58	57
Shoes on soil or outdoor concrete	2070	1808	1570	1179	837	578	420	332	281	250	233	219	209	200	193	188	173	162	156	153
Shoes on 75mm chippings	2341	2043	1773	1331	944	650	471	371	314	279	259	244	232	223	215	209	192	180	173	170
Shoes on 150mm chippings or dry concrete ^(D)	2728	2379	2064	1548	1095	753	544	428	361	321	298	280	266	255	246	239	220	205	198	194
Shoes on 100mm Asphalt	13500	11800	10200	7600	5300	3600	2500	2000	1600	1400	1370	1300	1200	1100	1100	1080	990	922	885	866

NOTE: These values are based on fibrillation limits. Immobilisation or falls/muscular contractions could occur at lower voltages. Steady state or standing voltages may require additional consideration.

- A) Additional resistances apply based on footwear resistance as well as contact patch, as defined in BS EN 50522, i.e. each shoe is 4kΩ and the contact patch offers 3xp, where ρ is the resistivity of the substrate in Ω·m. Thus for touch voltage, the series resistance offered by both feet is 2150 Ω for shoes on soil/wet concrete (effective ρ=100 Ω·m). For 75 mm chippings, each contact patch adds 1000 Ω to each foot, giving 2500 Ω (effective ρ=333 Ω·m). For 150mm chippings (and a conservative estimate for dry concrete), the total resistance is 3000 Ω (effective ρ = 670 Ω·m). Concrete resistivity typically will vary between 2,000-10,000 Ω·m (dry) and 30-100 Ω·m (saturated). For asphalt, an effective ρ =10,000 Ω·m gives 34kΩ per shoe.
- B) The >= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to 'let-go' threshold values.
- C) This assumes no contact resistance but does apply the 'dry' body impedance values with large contact areas. For other scenarios (e.g. salt-water wet) refer to IEC/TS 60479-1.
- D) Dry assumes indoors. Outdoor concrete, or that buried in normally 'wet' areas or deep (>0.6m) below ground level should be treated in the same way as soil.

464

Table 2 – Permissible step voltages for typical fault clearance times:

Permissible step voltages V ^(B)	Fault clearance time, seconds																				
	0.1	.15	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	2	3	5	≥10 ^(C)	
Bare feet (with contact resistance)	22753	19763	17077	12715	8905	6044	4290	3320	2770	2434	2249	2098	1992	1897	1823	1771	1616	1503	1442	1412	
Shoes on soil or outdoor concrete	A)	A)	A)	A)	A)	A)	A)	A)	A)	21608	19067	17571	16460	15575	14839	14267	13826	12629	11727	11250	11012
Shoes on 75mm chippings	A)	A)	A)	A)	A)	A)	A)	A)	A)	24906	21976	20253	18971	17951	17103	16445	15936	14557	13517	12967	12692
Shoes on 150mm chippings or dry concrete	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	24083	22559	21347	20338	19555	18951	17311	16074	15420	15092
Shoes on 100mm Asphalt	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)	A)

NOTES:

1) As for touch voltage, these limits are calculated according to fibrillation thresholds. Immobilisation or falls / involuntary movements could occur at lower voltages.
 2) In general, compliance with touch voltage limits will achieve safe step voltages.

A) Limits could not be foreseeably exceeded, i.e. 25kV or greater.
 B) Additional footwear / contact resistances appear in series (rather than parallel for the hand-foot case), and are therefore 4x those in equivalent touch potential case.
 C) The >= 10s column is an asymptotic value which may be applied to longer fault duration. This is a fibrillation limit only; it may be prudent to apply lower limits to longer duration faults or steady state voltages sufficient to limit body current to 'let-go' threshold values.
 D) This assumes no contact resistance but does apply the 'dry' body impedance values. For wet or salt-water wet, scenarios refer to IEC/TS 60479-1.

465

466 The figures above give acceptable touch and step potentials as a function of fault current
467 duration. Note that touch and step voltages are normally a fraction of the total EPR, and
468 therefore if the EPR (for all foreseeable fault conditions) is below the limits above then it
469 follows that the site will be compliant. (The full design assessment procedure is given in
470 Section 5.)

471 Permissible limits are a function of normal protection clearance times. Figure B2 of BS EN
472 50522 shows curves showing intermediate values, if required.

473 Touch and Step Voltages are sometimes collectively referred to as 'Safety Voltages' since
474 they relate directly to the safety of persons or animals.

475 Substations shall be designed so that 'Safety Voltages' are below the limits defined in Table
476 1 and Table 2 above. It will be appreciated that there are particular locations in a substation
477 where a person can be subjected to the maximum 'step' or 'touch' potential. Steep potential
478 gradients in particular can exist around individual rod electrodes or at the corner of a meshed
479 grid.

480 The presence of a surface layer of very high resistivity material provides insulation from
481 these ground potentials and greatly reduces the associated risks. Thus substations surfaced
482 with stone chippings/concrete or asphalt are inherently safer than those with grass surfacing,
483 and permissible limits are higher. These relate to the 'Additional Resistance' rows in the
484 tables above.

485 **4.4.2 Effect of electricity on animals**

486 The main focus of this document is human safety. However, horses and cattle are known to
487 be particularly susceptible to potential gradients in soil. There are no safety limits prescribed
488 for animals but technical report (IEC/TR 60479-3) provides some limited experimental data.
489 Interpretation of this data suggests that voltage gradients (e.g. around remote electrodes or
490 structures placed in fields) not exceeding 25 V/m will generally not result in animal fatality.

491 **4.4.3 Injury or shock to persons and animals outside the installation**

492 (This from S34 – probabilistic approach. Safety voltage limits for animals should be
493 considered only where necessary)

494 [Refer to Risk Assessment Case Study]

495 These can be introduced by metallic transfer (fence, pipe, cable) or via the soil. Where a
496 hazardous transferred potential can occur due to metallically conductive means, that
497 eventuality should be removed by the introduction of insulation or other protective measures
498 (examples include insulated sections introduced into external metal fences). Where metal
499 fences are bonded to the substation earthing system, the touch and step potentials external
500 to them must be controlled by the design, such that they are within the acceptable limits. In
501 other words, most risks should be managed by design. An ideal application for risk
502 assessment is coated type fencing (such as expanded metal) where parts of the coating may
503 degrade over time. Where HV and LV earthing systems are combined, the EPR is
504 transferred from the installation into domestic, commercial or industrial properties and must
505 be at a level that complies with the requirements of section 9.5.

506 (We consider some research is needed to determine the threshold voltage for this from a
507 safety perspective. At present it is 430 V – an ITU equipment limit value). [NB 466 V now
508 introduced from BS EN 50522]

509

510 [Review once project complete]

511 Issues include identification of the realistic shock scenarios in a range of property types, and
512 the probability of this occurring and risking electrocution at a range of voltage levels. Where
513 HV and LV systems are combined, the EPR (or part of it) will be transferred to the LV
514 system.

515 For potentials transferred via the soil, the risk is related to the EPR magnitude (together with
516 proximity of the person, animal or property to the installation), the likely presence of humans
517 or animals and the degree/time of exposure. If the substation has an elevated EPR, obvious
518 concerns are shock risk to humans who do not have appropriate footwear (beach-side or
519 camping site locations) and if applicable electrocution to animals (such as a horse –
520 especially one that is being trained/ridden at the time).

521 Some guidance is needed for areas of high EPR. The situation here is related to safe touch
522 and step potentials, not equipment thresholds. For example – risk of shock in a house
523 (similar scenario to the HV/LV bonded issue at a distribution substation), risk of shock in a
524 field, risk of shock to a horse whilst being ridden in an adjacent field.

525 **4.5 Electrical Requirements**

526 **4.5.1 Method of neutral earthing**

527 The method of neutral (or ‘star point’) earthing strongly influences the fault current level. The
528 earthing system shall be designed appropriate to any normal or ‘alternative’ neutral earthing
529 arrangements, in a similar way that it will be necessary to consider alternative running
530 arrangements that may affect fault levels or protection clearance times.

531 Note, if the system uses a tuned reactor (arc suppression coil (ASC) / Petersen coil)
532 connected between the transformer neutral and earth, the magnitude of the current in the
533 earthing system may be small due to the tuning of the ASC reactance against the
534 capacitance to earth of the unfaulted phases. However, other conditions can occur that
535 require a higher current to be considered. For instance, if the tuned reactor can be shorted
536 out (bypassed), e.g. for maintenance or protection purposes whilst the transformer is still on
537 load, then it is necessary to design for this (refer to sections 5.5.2 and 5.5.4). Furthermore,
538 even if there is no alternative method of system earthing it is still necessary to consider the
539 possibility of a neutral bushing fault on the tuned reactor effectively shorting out the tuned
540 reactor. Such considerations also apply to all impedance earthed systems if there is a
541 foreseeable risk of the impedance ‘failing’ and remaining out for any significant time.

542 The likelihood of phase-to-earth insulation failure is increased on ASC systems, particularly if
543 earth faults are not automatically disconnected. This is because a first earth fault will cause
544 phase displacement such that the two healthy phases will become at increased voltage
545 relative to earth (approaching line-line voltage). Consideration should be given to a ‘cross-
546 country’ fault where two phase-to-earth faults occur simultaneously on different phases. The
547 current can approach phase-to-phase levels if the earth resistance at each fault site is
548 minimal or if there is metallic interconnection between the sites.

549 **4.5.2 Fault Current**

550 The passage of fault current into an electrode system causes voltage rise (EPR, and
551 touch/step/transfer voltages) and heating. Both are related to the magnitude of fault current
552 flow. Section 5.5 describes the fault currents (and durations) applicable to earthing design.

553 **4.5.3 Thermal effects - general**

554 The earthing system shall be sized according to the maximum foreseeable current flow and
555 duration to prevent damage due to excessive temperature rise. For main items of plant in
556 substations (switchgear, transformers, VTs, CTs, surge arrestors, etc.), consideration needs
557 to be given to the possibility of simultaneous phase-earth faults on different items of plant,

558 which could result in phase-phase current flows through the MES. Refer also to Section
559 5.5.4.


560 Any current flowing into an electrode will give rise to heating at the electrode and surrounding
561 soil. If the current magnitude or duration is excessive, local soil can dry out leading to an
562 increase in the resistance of the electrode system. Section 5.6.2 defines a 'surface current
563 density' limit (in terms of Amps per m² or cm² of electrode area). In some situations, even if
564 target resistance and design EPR values are achieved, it may be necessary to increase the
565 electrode contact surface area to ensure compliance with this requirement (Section 5.5.5).

566

567 **5 Design**

568 **5.1 General approach (flowchart)**

569 The general approach is summarised in the flowchart below:



571 **5.2 Design Considerations**

572 This section describes general arrangements applicable to all substations. Further discussion
573 relating to those items specific to distribution substations is included in Section 9, and pole-
574 mounted systems are further described in Section 10.

575 **5.2.1 Limiting values for EPR**

576 The design shall comply with the safety criteria (touch, step and transfer voltages) and with
577 the earthing conductor and earth electrode conductor current ratings, and will need to allow
578 sufficient current flow for reliable protection operation.

579 There is no design requirement which directly limits the overall EPR of a substation to a
580 particular value, however, the design will need to consider insulation withstand between
581 different systems, and voltage contours in surrounding soil. The need to comply with these
582 requirements, and safety limits, will naturally tend to restrict the acceptable EPR. In practice,
583 an upper EPR limit may be applied by different network operators based on equipment
584 specifications and/or proximity to third party systems.

585 **5.2.2 Touch and Step voltages**

586 Touch and Step voltages (collectively referred to as 'Safety Voltages') are the most important
587 design criteria. A substation that fails to achieve permissible touch voltage limits will not be
588 safe. Formulae for calculating touch and step voltages are presented in EREC S34.

589 **5.2.3 Factors to include in calculation of EPR and Safety Voltages**

590 For each operating voltage at a substation, two conditions of earth fault should be considered
591 to determine the maximum value of earth electrode current. In one, the earth fault is external
592 to the substation; here the current of concern is that returning to the neutral(s) of the
593 transformer(s) at the substation under consideration. The other is for an earth fault in the
594 substation; here the current of concern is now that value returning to the neutral(s) of the
595 transformer(s) external to the substation under consideration. These currents are
596 components of the system earth fault currents. If these return currents have available to them
597 other conducting paths directly connected to the earthing system of the substation, for
598 example overhead line earth-wires and cable sheaths, then the currents in these paths shall
599 be deducted from the appropriate return current to derive the value of current passing
600 through the earth electrode system of the substation. Evaluation of this 'ground-return'
601 current component is described in EREC S34. See also Section 5.5.2.

602 **5.2.4 Transfer Potential**

603 A further factor that needs to be considered is 'transfer voltage' that may arise from a fault at
604 the source substation(s), if there is a metallic connection (cable sheath or earth wire)
605 between the substation earthing systems. Methods for calculating the transferred potential
606 are described in ENA EREC S34.

607 A person at a remote location could theoretically receive the full (100%) EPR as a touch
608 potential since he/she will be in contact with 'true earth'. This may be disregarded if the EPR
609 at the source substation is known to meet the safety criteria, i.e. is within acceptable touch
610 voltage limits. However, particular care is needed if there is a possibility of hand-hand
611 contact between a transfer potential source, and other earthed metalwork. The possibility
612 should be excluded by appropriate barriers (e.g. insulated glands, enclosures) or bonding. If
613 this cannot be ensured, then lower voltage limits apply to the hand-hand shock case (refer to
614 IEC/TS 60479-1).

615 **5.3 Preliminary Arrangement and Layout**

616 In order to determine fully the requirements for and adequacy of an earthing system it is
617 necessary to produce a preliminary design arrangement of that earthing system. From a site
618 layout drawing showing the location of the plant to be earthed, a preliminary design
619 arrangement of the earthing system for the substation should be prepared, incorporating the
620 relevant 'functions' of Section 4.1 and the relevant 'features' of Section 4.2. The particular
621 layout arrangement will be unique to each substation but all will have some dependence on,
622 inter alia, a combination of the factors described in Section 5.5.4, relating to fault level, fault
623 duration, electrode current and soil type.

624 **5.4 Design Guidelines**

625 This Section gives an outline of those features of earthing system arrangements which have
626 proved to be most satisfactory in practice.

627 **5.4.1 Outdoor Substations**

628 Except for pole mounted equipment, it is recommended that the earthing arrangement be
629 based on a bare 'perimeter electrode' (peripheral buried horizontal earthing electrode),
630 generally encompassing the plant items to be earthed such that the perimeter earth electrode
631 is at least 1m out from the plant items to provide touch voltage control at arm's reach.
632 Internal connections shall connect from the perimeter electrode to the items of plant. These
633 internal connections function as earthing conductor if not in contact with soil, or electrode
634 otherwise. Where reasonably practicable, the amount run above the surface shall be
635 minimized to deter theft. In addition, discrete earth electrodes, e.g. rods or plates, may be
636 connected to this perimeter electrode. These may variously be employed to reduce the
637 surface current and/or the electrode resistance of the overall earth electrode system. The
638 overall electrode system is termed the Main Earthing System (MES).

639 The electrode system may be augmented with inter-connected, buried, bare cross-
640 connections to form a grid. Such cross-connections increase the quantity of earth electrode
641 conductor and mesh density of the grid, reduce touch voltages on plant within the grid, and
642 provide local main conductors to keep equipment connections short; in addition they increase
643 security/resilience of connections by introducing multiple paths for fault current, which is an
644 important consideration.

645 In all substations it is recommended that duplicate connections are made from the Main
646 Earthing System (MES) to main items of plant, in order to increase resilience (refer to
647 Section 5.5.4 for conductor sizing).

648 Where regular contact of an operator with an earthed structure is anticipated, e.g. at a switch
649 handle, the earthing system shall be enhanced by providing an earth mat (or, if a mat poses
650 difficulties, appropriate grading electrode) at or just below the surface of the ground and
651 bonded to the metalwork, so arranged that the metalwork can only be touched while standing
652 above the mat (or enhanced area).

653 Pole-mounted equipment presents a particularly difficult ground potential gradient problem
654 and the special precautions noted in Section 10 shall be observed. It may be necessary to
655 apply these precautions in some ground-mounted substations.

656 Fault current flowing through an earth electrode system to ground uses the outer extremities
657 of the electrode system to a greater extent than the inner parts of the system. Thus, adding
658 more earth electrode, whether as vertical rods or as horizontal tape, to the inner area of a
659 small loop or well integrated grid electrode system, will have little impact in reducing earth
660 resistance or the current density in the outer electrode conductors of the system (however
661 this can help to control step/touch potentials around specific items of plant).

662 Such reductions (in overall earth resistance) as may be desirable are best achieved by
663 extending the electrode system to cover a greater area of ground (e.g. by buried 'radial'
664 electrodes), or by driving rods around the periphery of the system or by a combination of
665 both.

666 The vertical rod electrode is most effective for use in small area substations or when low soil
667 resistivity strata, into which the rod can penetrate, lies beneath a layer of high soil resistivity.
668 Rods are least effective where there is a high resistivity layer beneath one of lower resistivity,
669 e.g. where underlying bedrock is near to the surface. In these locations extended horizontal
670 electrodes in the low resistivity surface layer are more effective.

671 For large area substations employing a grid electrode system, the addition of vertical rods,
672 even when optimally installed around the periphery of the system, may make only a marginal
673 improvement.

674 **5.4.2 Indoor Substations**

675 The plant of indoor substations will normally be erected on a concrete raft, often containing a
676 steel reinforcing mesh (re-bar). To control touch and step potentials around plant, it is
677 common for re-bar to be bonded to the main earthing system, or for a dedicated 'grading
678 mesh' (usually consisting of prefabricated steel or copper mesh) to be buried in concrete
679 screed in the substation area. These measures are to control potential gradients and are not
680 intended to act as an 'electrode' (they may be employed for example above basement
681 areas); dedicated electrodes will also be required to provide a connection to the mass of
682 earth and achieve the functional requirements. For new substation buildings a buried
683 peripheral horizontal electrode may be conveniently installed around the building foundation
684 and supplemented with vertical rod electrodes as required. Coordination with the civil
685 engineering design can result in a cost-effective installation.

686 Where reinforcing mesh in concrete is to function as supplementary earth electrode, it must
687 be designed to carry the current without cracking the concrete, be constructed with mesh
688 panels welded together and be welded to the peripheral buried earth electrode at suitable
689 intervals (e.g. 5 m).

690 The provision of a buried main earth bonding conductor within the confines of an existing
691 building is often impractical and thus a surface mounted main earthing conductor loop, is
692 normally installed with surface run (and duplicate) spur connections to the various items of
693 plant. The earth electrode system employed with this arrangement may differ depending on
694 the magnitude of earth fault current that the electrode system is required to carry.
695 Marshalling earth bars are sometimes used in addition to, or instead of, a surface laid loop,
696 and (if properly labelled) can facilitate measurement/maintenance. The convenience of such
697 an arrangement often brings with it a high reliance on bolted connections and so the
698 'resilience' aspect needs to be balanced with convenience.

699 Substations in buildings may require a buried loop/ring electrode outside the building if any
700 extraneous metalwork (e.g. metal cladding, steel joists, handrails, communications antennae
701 etc.) is bonded to the substation earthing system and could otherwise present a touch
702 potential issue to those outside the building. The same considerations apply where a
703 substation is installed in an existing building (for example in the basement of a tower block),
704 even if the building is not recognisable as a 'substation building'; in fact risks associated with
705 members of the public will often be higher in such installations and warrant additional
706 consideration.

707 Electrode systems (rod nests, etc.) should not be sited close to main access/egress routes
708 without consideration of step and touch voltage in these areas.

709 Grading electrode (where required) should be positioned 1 m from metal-clad buildings, and
710 bonded to the building's internal HV or EHV earthing system at two or more separate points.

711 If the building is to be provided with a lightning protection system that will be bonded to the
712 main earthing system, the LPS electrodes may contribute to potential grading. Calculations
713 and/or computer modelling will normally be necessary to demonstrate whether such
714 measures can be used in place of dedicated grading electrodes.

715 Sparsely positioned rods (e.g. associated with a lightning protection system to BS EN / IEC
716 62305-1) may serve this function if compliance can be demonstrated at the design stage.

717 A lightning protection electrode system if purposely designed with regard to power system
718 fault currents and with closely spaced rods (or interconnecting electrode ring), could serve
719 the dual purpose of lightning protection and potential grading. Care is needed to ensure that
720 such a system cannot be disconnected from the building, e.g. by removal of test links.

721 Conversely, any earthing system designed for power system fault current may be used for
722 lightning protection system if compliant with BS EN / IEC 62305-1, particularly with regard to
723 high frequency components and down-conductor routing (free of tight bends etc.)

724 **5.4.3 Shared Sites**

725 Where the customer operates HV (and/or EHV) switchgear, there will be a natural boundary
726 between Network Operator's ownership, and customer ownership. Ideally the Network
727 Operator should not rely on the customer's earthing system to ensure electrical safety
728 around the Network Operator's assets, unless maintenance agreements can be made. In
729 practice, the systems may need to be connected together, but each system should (where
730 reasonably practicable) be designed to be safe (touch voltages) in the absence of any
731 (electrode) contribution from the other system.

732 Neither party should rely on the other's earthing system unless regular maintenance/testing
733 of both systems can be assured.

734 **5.4.4 Distribution (or 'Secondary') Substations**

735 Distribution (HV:LV) substation earthing is particularly important given that LV system
736 neutral/earth conductors may be connected to, or close to HV earthing systems and
737 consequently could export 'transfer potential' to customer installations. Specific examples for
738 ground mounted substations are given in Section 9, and pole mounted equipment is covered
739 in Section 10.

740 **5.4.5 Metallic Fences**

741 Substation fences are typically either a) Bonded to the MES, or b) Separately earthed. In
742 general, a bonded design will be required if 2m separation (or barriers/effective insulation)
743 cannot be established to prevent simultaneous contact (hand-hand) between the systems. A
744 separately earthed system is preferable otherwise to minimise the EPR (and resulting touch
745 voltage) that may be accessible externally.

746 In the case of bonded fences, consideration must be given to touch voltages that appear on
747 the fence under fault conditions; an external peripheral electrode may be required 1m around
748 the outside of the fence to achieve acceptable levels. Care must also be taken to ensure that
749 voltage rise is not 'exported' via third party fences etc. that may be in contact with the fence.

750 Refer to Section 6.6 for more details.

751 **5.4.6 Provision of Maintenance/Test facilities**

752 Facilities for Monitoring Earth System Efficiency (described in Section 6.2.5) should be
753 included at the design stage. Refer to Section 7.5 for information on earth resistance
754 measurements.

755 Test points (e.g. for clamp meter testing) should be shown on earthing drawings.

756 **5.5 Design data**

757 The final design of the earthing system can only be undertaken when sufficient knowledge is
758 available of the proposed physical and electrical arrangements of the substation.

759 As a minimum, the designer must have knowledge of:

- 760 1) value of fault current
- 761 2) fault duration (or protection settings)
- 762 3) soil resistivity
- 763 4) substation dimensions

764 Any special features about the site, such as subsoil of a corrosive nature and the suitability of
765 the site for driven earth rods or other forms of electrode, must be ascertained. Other relevant
766 features, such as existing earth electrodes, nearby earthed structures, buried pipes or piled
767 foundations are also required to be noted and taken into consideration.

768 In urban areas in particular the substation may be served by an underground cable network
769 which (particularly if incorporating non-insulated sheaths/armours) will make a 'contribution'
770 which may be taken into consideration. Refer to Section 9.4.3 for details on the contribution
771 from typical 11kV networks.

772 **5.5.1 Soil Resistivity**

773 The value of the specific resistivity of the soil may be ascertained by reference to published
774 data or by direct measurement. Table 3 (below) sets out typical values relating to types of
775 soil but these should be used for very preliminary assessments only.

776 [Nationally available soil survey data can also be used for this purpose, e.g.

777 <http://mapapps.bgs.ac.uk/geologyofbritain/home.html>].

778

Table 3 - Typical soil resistivity values

779

Resistivity in $\Omega \cdot m$

SOIL	RESISTIVITY ($\Omega \cdot m$)
Loams, garden soils, etc	5 – 50
Clays	10 – 100
Chalk	30 – 100
Clay, sand and gravel mixture	40 – 250
Marsh, peat	150 – 300
Sand	250 – 500
Slates and slaty shales	300 – 3,000
Rock	1,000 – 10,000

780

781 Multi-layer soil models and computer modelling may offer more effective / optimal designs
782 than typical or 'homogeneous' soil models. Except for some smaller substations, (where the
783 additional expense may not be warranted), direct measurement will normally be necessary
784 prior to detailed design. The recommended method, using the Wenner Array, is described in
785 Section 7.4.

786 It should be noted that the top layers of soil may be subject to significant seasonal variation
787 due to fluctuating moisture content. Designs should utilise deeper more 'stable' strata
788 wherever possible; the depth of this 'stable' layer is variable depending on soil type and
789 weather/climate.

790 **5.5.2 Fault currents and durations - general**

791 The earthing system must remain intact, and safety voltages must be acceptable for all
792 foreseeable fault conditions. BS EN 50522 describes the need to consider single phase to
793 earth, two phase, and three phase to earth fault current flows, as well as 'cross country'
794 faults in some situations.

795 The relevant currents for earthing design are summarised in Table 4 below, and described in
796 detail in the following sections.

797

798

799 Table 4 – Relevant currents for earthing design purposes

Type of System Earth Supplying Fault	Relevant for EPR and Safety Voltages	Relevant for thermal effects	
		Earth Electrode	Earthing Conductor
Solid Earthing	Worst case earth fault current . Ground return current may be used if known, and if earth-return paths (e.g. cable sheaths and gland connections) are known to be reliable and rated for duty. See Section 5.5.3	Maximum foreseeable electrode current . This may be taken as the ground return current or value between ground return current and earth fault current , taking into account the loss of any metallic return paths (cable sheath or overhead earth wire) where relevant. See sections 5.5.5 and 5.6.2	Earth fault currents for all voltage levels at the substation. Three phase (or phase-to-phase) faults should be considered if phase-to-phase fault current can flow through earthing conductors (e.g. separately earthed items of plant, particularly single phase equipment). See section 5.5.4.
Impedance Earthing			
Arc Suppression Coil (ASC or Petersen Coil)	ASCs are generally used in addition to solid or impedance earthing. It is therefore usually appropriate to design to the alternative solid or impedance arrangement (as above) which is termed the 'bypass' arrangement. In addition, cross-country faults should be considered if they are likely to be more onerous in terms of magnitude and/or duration. Steady state currents (i.e. the maximum current that can flow in the earthing system without protection operation) may impose additional requirements on the designer.		
	Refer to Section 5.5.3	See section 5.5.5.	See Section 5.5.4
Notes:			
Fault currents associated with all voltages levels in substations must be considered. The appropriate protection clearance times for each voltage level must be applied – refer to Section 5.5.2			

800

801 Refer to Table 1 in BS EN 50522 for further details.

802

803 **5.5.3 Fault currents for EPR and safety voltage calculations**

804 The fault current applicable to EPR calculation (and therefore safety voltage calculations) is
805 the maximum (symmetrical RMS) current to earth (**earth-fault current**) that the installation
806 will see under fault conditions.

807 **Normal operating time** of protection relays and breakers should be used for safety voltage
808 calculations, rather than worst-case (back-up) protection clearance times.

809 Cable sheath or earth wire return paths should be included if they are reliable and rated for
810 duty, in which case the resultant (smaller) **Ground Return Current** may be used for design
811 purposes, since it is this current (or a fraction of it) that flows into the local electrode system
812 and gives rise to EPR. Designs should consider touch voltage that may result under various
813 failure scenarios and for all voltage levels at a substation.

814 If specific protection settings are not available, the design should use 'upper bound' (slowest)
815 clearance times associated with normal protection operation, as specified by the network
816 operator.

817 These considerations apply whether the source substation (i.e. that supplying the fault) is
818 impedance or solidly earthed. EPR should be calculated for all voltage levels at any
819 substation, for faults at the substation and on circuits fed from it. LV faults can usually be
820 shown to be insignificant in this regard.

821 For substations with Arc Suppression Coils (ASCs), the design should be based on the most
822 onerous (in terms of magnitude and/or duration) earth-fault or cross-country fault. In addition,
823 the design should consider long duration EPR conditions which may give rise to near 'steady
824 state' voltages on equipment or fences etc.

825 Note: In many cases the 'solid' earth fault level is an appropriate design figure for safety voltage assessment on
826 ASC systems, since this is likely to represent a realistic upper-bound. The need to consider alternative fault
827 scenarios / currents is subject to operational experience / risk assessment.

828

829 **5.5.4 Fault currents and clearance times for conductor size calculations**

830 Conductor sizing calculations should be based on **backup** protection clearance time, i.e. the
831 design shall allow for failure of primary protection without damage to the earthing system. In
832 the absence of network specific data, the following operating times should be assumed:

833 Up to and including 132 kV: 3 seconds (excluding LV)

834 275 kV and higher voltages: 1 second

835 For earthing conductors and electrodes in substations it is recommended that the design
836 fault-current should be the worst case foreseeable value (including phase-to-phase, or three-
837 phase, earth fault), including (where necessary) that which may result from a broken or
838 missing metallic return path (cable sheath or overhead earth wire).

839 NOTE: The decision of whether to include the 'missing return path' scenario is largely dependent on operational
840 experience and risk assessment. For example, the likelihood of complete failure of the metallic return path will be
841 higher for a single overhead earth wire than it would be for a triplex (3 x bunched single cores) cable network
842 arranged in a ring.

843 The maximum fault current applies wherever this may be borne by one spur connection, in
844 which case that spur must be sized accordingly. In grid (mesh) earthing designs there will
845 often be parallel paths to share the current; if the current is to flow in two or more paths (e.g.
846 around a ring) then each individual path shall be sized to no less than 60% of the fault
847 current.

848 Installations connected to, or part of the one where the highest fault current occurs, may only
849 be required to carry a portion of that current and the earth conductors may be sized
850 accordingly. For example, in lower voltage areas peripheral to a higher voltage one, their
851 earth conductors must be sized to meet the lower voltage fault current and calculations may
852 show that they are also adequate for their proportion of the HV or EHV fault current.

853 Conductor ratings are given in Section 5.6.1.

854 **5.5.5 Fault currents and clearance times for electrode size calculations**

855 The discrete earth electrode shall at all times retain its functional properties, i.e. both its
856 current carrying capability and its value of resistance to earth. For these reasons the
857 temperature rise of the electrode conductor and the density of current dissipation from
858 electrode to soil, during the passage of fault current through it, shall be limited.

859 Electrodes are thus subject to a) thermal requirements due to passage of fault current, b)
860 current limits imposed by the electrode-to-soil interface:

861 a) 'Conductor Thermal requirements' are satisfied by appropriate choice of material and
862 cross sectional area for each electrode and its connection to the main earthing
863 system (Section 5.6.1).

864 b) 'Surface Current Density' requirements are satisfied by ensuring sufficient electrode
865 surface area. In some cases it will be necessary to install additional electrode(s) to
866 satisfy this requirement, particularly if the electrode resistance requirements can be
867 met with a relatively small electrode system.

868 Further detail – surface current density:

869 The soil surrounding earth electrodes is of a much higher sensitivity than the electrode
870 conductor material and thus the passage of current through the soil will develop, relatively, a
871 much higher temperature rise. The effect of high temperature in the soil causes drying of the
872 surrounding soil, thus further increasing its resistivity, or even the production of steam which
873 can force a separation between the electrode conductor and its interfacing soil.

874 For this reason the current rating of an earth electrode is specified in terms of its surface
875 current density (A/mm^2), and is dependent on soil resistivity. As a consequence the current
876 rating of buried electrodes in practical installations is very much less than equivalent sized
877 above-ground earthing conductors (Section 5.6.2 gives typical ratings).

878 Where a multi-mesh buried main earth grid is installed, the density of fault current in the
879 earth electrode should rapidly reduce as the distance from the point of fault increases.
880 Provided, therefore, that a sufficient quantity of grid conductor is buried and is well
881 distributed, the surface current density will generally be satisfactory and high surface
882 temperature restricted to a small area close to the fault point and thus have negligible effect
883 on the value of total earth electrode resistance or on the efficacy of the earthing system as a
884 whole.

885 Design fault currents and clearance times for electrode ratings

886 The surface area of the main electrode through which the fault current flows to ground shall,
887 as a minimum, be sufficient to disperse the maximum foreseeable **electrode current** (i.e. the
888 total current flowing into the electrode system).

889 The **ground return current** (or even **earth fault current**) may be used in calculations if the
890 electrode current(s) are not known. Higher values may be appropriate for ASC systems, as
891 described below.

892 NOTE 1: The maximum current flow into individual electrode groups (where there is more than one) should be
893 assumed to be 60% of the ultimate overall figure used above.

894 NOTE 2: Reduction factors for neutral current flows (multiple earthed systems) and sheath/earth wire return
895 currents may be applied in the normal way to calculate ground return current or electrode current.

896 NOTE 3: Faults at all voltage levels in each substation must be considered.

897

898 The possibility of sheath failure or aerial earth wire failure can give rise to higher than normal
899 ground return current (and consequent electrode current) and should be considered where
900 necessary, as described in the previous section.

901 For ASC systems*, the **electrode current** calculation must consider **cross-country** faults
902 since these are more likely on ASC systems. The electrode current in such circumstances
903 can sometimes exceed the normal calculated **ground return current**. **Solid earth-fault**
904 level or **phase-to-phase** fault levels should be used if there is any doubt, even if the 'bypass'
905 is via resistor or reactor. The value to be used is subject to risk assessment and operational
906 experience.

907 * NOTE: This is particularly relevant where earth faults are not automatically disconnected within 3 seconds.

908 The relevant clearance times are for **backup** protection operation as described in the
909 previous section, since it is imperative that the earthing system remains intact if faults are
910 slow to clear.

911 Long term (steady state) current flows can cause drying of soil, and must be considered in
912 addition to normal faults (see below).

913 Relatively rare faults (e.g. bushing failures or internal faults) which may cause an ASC or
914 impedance to be shorted out should be considered if necessary, based on operational
915 experience.

916 Long term current flows

917 If significant ground-return current can flow for prolonged duration (i.e. without protection
918 operation), the effect of this current should be considered separately; it can lead to drying at
919 the electrode-soil interface and impose a steady state (or 'standing voltage') on plant which
920 can require additional measures to ensure safety. This may be relevant for ASC systems
921 where earth faults are not automatically disconnected, or where moderate current can return
922 via earth to the system neutral in normal circumstances due to un-balanced network
923 capacitance or leakage. The magnitude of this current may be taken as the ASC coil rating
924 or earth-fault protection relay current settings.

925 NOTE: A maximum surface current density of 40 A/m^2 is appropriate for long term current flows. This is unlikely
926 to cause drying at the electrode-soil interface.

927

928 Surface area and current density requirements

929 In many cases the electrode surface area requirement is satisfied by normal design practice
930 based on achieving a satisfactorily low earth resistance value; care is needed for systems
931 where a small electrode system is otherwise thought to be sufficient.

932 The appropriate fault current, as described above, should be divided by the surface area of
933 the electrode system (as described in EREC S34 section XXX) to demonstrate that the
934 current density at the electrode-soil interface is within limits given in Section 5.6.2.

935 It is permitted to use the surface area of all connected electrodes (main and auxiliary) in this
936 calculation. However, it is good design practice, wherever possible, to ensure that sufficient
937 main electrode meets this requirement.

938 NOTE: In situations such as substations in urban areas where the overall Ground Return Current is significantly
939 increased by interconnection to a larger network or other auxiliary electrode system, dividing this **overall ground**
940 **return current** (returning via a wide area electrode system, shown as I_E in EREC S34 Figure 3.2) into the **local**
941 electrode surface area will provide a safety margin. It is permissible, for design economy, to calculate the local
942 electrode current (i.e. by evaluation of the ground return current 'split' between the local electrode system and
943 other paths, shown as I_{ES} in S34 Fig 3.2), and dividing this resultant electrode current into the local electrode
944 area. This approach should be used with caution, or combined with the risk assessment approach outlined in
945 Section 5.8 as failure of auxiliary electrode connections etc. could result in overheating/failure of the local
946 electrode system under fault conditions.

947

948 Limiting values of surface current rating, calculated for some typical electrodes are given in
949 Table 8 below (section 5.6.2).

950 **5.5.6 Fault current growth**

951 Consideration should be given to future network alterations and alternative running
952 arrangements. A margin may be added to allow for future changes without detailed
953 assessment (e.g. 10-20% increase).

954 If fault levels are expected to approach the switchgear rating in the foreseeable future, the
955 **switchgear rating may be used as the design figure**. In any case the rating of the
956 earthing system should be reviewed if plant is to be upgraded such that higher fault levels
957 may be possible.

958 **5.6 Conductor and Electrode Ratings**

959 The earthing system must remain intact following a protection failure, i.e. the earth
960 conductors, electrodes and their joints must withstand the electrical and mechanical effects
961 for the fault magnitude(s) and duration(s) as described in section 5.5.4.

962 **5.6.1 Earthing Conductors**

963 Earthing conductors should normally be selected from standard copper or aluminium
964 sections; this does not exclude the use of other materials if longevity and resilience
965 (especially to corrosion) can be demonstrated. For alkaline or acidic soils (i.e. those where
966 the pH is greater than 10 or less than 4), or in other situations where corrosion is likely, it
967 may be necessary to oversize electrodes, or to apply other measures to give a reasonable
968 lifetime. Refer to BS 7430 for further details.

969 Based on maximum fault clearance times, the conductor temperature should not exceed
970 405°C for copper and 325°C for aluminium based on an initial temperature of 30°C. A lower
971 limit of 250°C (absolute) is relevant for bolted connections, since extreme thermal cycling can
972 lead to loosening over time.

973 Table 5 and Table 6 below give declared current ratings for a range of standard conductor
974 sizes for both 1 second and 3 second fault duration times. **The short time rating of other
975 conductors can be calculated from formulae given in EREC S34.**

976

977

Table 5 - CONDUCTOR RATINGS (COPPER)

978

(a) 405°C maximum temperature (Copper)

These copper sizes are based on a temperature rise of 375°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C (i.e. achieving a maximum temperature of 405°C) with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply.					
Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4	25 x 4	35mm ²	35mm ²
8		25 x 4	25 x 4	70mm ²	50mm ²
12		25 x 4	25 x 4	95mm ²	70mm ²
13.2		31.5 x 4	25 x 4	120mm ²	70mm ²
18.5		40 x 4	25 x 4	150mm ²	95mm ²
22		50 x 4	31.5 x 4		120mm ²
26.8		40 x 6.3	40 x 4		150mm ²
40		-	50 x 4		
	40	50 x 4	31.5 x 4		
	60	50 x 6.3	50 x 4		
	63				
NOTE: Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 35mm ² =19/1.53mm; 50mm ² =19/1.78mm; 70mm ² =19/2.14mm or 7/3.55mm(e.g. HDC); 95mm ² = 37/1.78mm; 120mm ² =37/2.03mm; 150mm ² =37/2.25mm. Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 502164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.					

979

980

981

982

(b) 250°C maximum temperature (Copper) – bolted connections

<p>These copper sizes are based on a temperature rise not exceeding 250°C, from an ambient temperature of 30°C with the currents in columns (a) and (b) respectively applied to the conductors. For each substation it will be necessary to specify whether column (a) or (b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.</p>					
Fault Current (kA) Not Exceeding		Copper Strip (mm)		Stranded Copper Conductor	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		25 x 4		50mm ²	35mm ²
8		25 x 4		95mm ²	50mm ²
12		25 x 6		120mm ²	95mm ²
13.2		25 x 6		150mm ²	95mm ²
18.5		38 x 5		185mm ²	120mm ²
22		40 x 6			150mm ²
26.8		50 x 6			185mm ²
40		-	40 x 6		
	40	40 x 6	50 x 3		
	60	-	50 x 6		
	63	-	50 x 6		
<p>NOTE: Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 35mm²=19/1.53mm; 50mm²=19/1.78mm; 70mm²=19/2.14mm or 7/3.55mm(e.g. HDC); 95mm²= 37/1.78mm; 120mm²=37/2.03mm; 150mm²=37/2.25mm.</p> <p>Consideration of corrosion risk may lead to the decision to specify minimum strand diameters (e.g. 1.7mm or larger as per BS EN 502164-2). A minimum strand diameter of 3mm is preferred by some DNOs for longevity of the electrode system particularly if corrosive soils exist.</p>					

983

984

985

986

Table 6 - CONDUCTOR RATINGS (ALUMINIUM)

987

(a) 325°C maximum temperature (Aluminium)

These aluminium sizes are based on a temperature rise of 295°C occurring in 3 seconds and 1 second above an ambient temperature of 30°C with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply.					
Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm ²	35mm ²
7.5		25 x 4	20 x 4	120mm ²	70mm ²
12		40 x 4	25 x 4		120mm ²
13.2		50 x 4	25 x 4		120mm ²
18.5		40 x 6	40 x 4		150mm ²
22		50 x 6	50 x 4		
26.8		60 x 6	40 x 6		
40		60 x 6	50 x 6		
	40	50 x 6	50 x 4		
	60	80 x 6	50 x 6		
NOTE: Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 35mm ² =19/1.53mm; 50mm ² =19/1.78mm; 70mm ² =19/2.14mm or 7/3.55mm; 95mm ² = 37/1.78mm; 120mm ² =37/2.03mm; 150mm ² =37/2.25mm.					

988

989

990

991

992

993

(b) 250°C maximum temperature (Aluminium) – bolted connections

These aluminium sizes are based on a temperature rise not exceeding 250°C in 3 seconds and 1 second from an ambient (initial) temperature of 30°C with the currents in columns 1(a) and 1(b) respectively applied to the conductors. For each substation it will be necessary to specify whether column 1(a) and 1(b) should apply. These figures are generally applicable to bolted connections between tapes or lugs etc. which offer a relatively small thermal mass.					
Fault Current (kA) Not Exceeding		Aluminium Strip (mm)		Stranded Aluminium Conductor (mm)	
(a)	(b)				
(3 secs)	(1 sec)	Single (spur) Connections	* Duplicate or Loop Connections	Single (spur) Connections	Duplicate or Loop Connections
4		20 x 4	20 x 2.5	70mm ²	50mm ²
7.5		25 x 5	25 x 3	120mm ²	70mm ²
12		50 x 4	25 x 5	185mm ²	120mm ²
13.2		50 x 4	25 x 5		120mm ²
18.5		50 x 6	50 x 4		185mm ²
22		60 x 6	50 x 4		
26.8		-	40 x 6		
40		-	60 x 6		
	40	60 x 6	40 x 6		
	60	-	60 x 6		
NOTE: Equivalent sizes for stranded conductor include, but are not limited to the following, quoted as number of strands/strand diameter: 35mm ² =19/1.53mm; 50mm ² =19/1.78mm; 70mm ² =19/2.14mm or 7/3.55mm; 95mm ² = 37/1.78mm; 120mm ² =37/2.03mm; 150mm ² =37/2.25mm. Duplicate or loop connections have been rated to carry 60 per cent of the full fault current.					

994

995

996

Table 7 - Cross sectional areas for steel structures carrying fault current

These sizes are based on the maximum temperature achieved after the passage of fault current for 3 seconds and 1 second from an ambient (initial) temperature of 30°C. For each substation it will be necessary to specify whether column 1(a) or 1(b) should apply.			
Fault Current (kA) Not Exceeding		250°C (applicable to bolted structures)	400°C (applicable to welded/continuous structures which are galvanised)
(a)	(b)		
(3 secs)	(1 sec)	mm ²	mm ²
4		109	91
7.5		204	171
12		327	273
13.2		359	301
18.5		503	421
22		599	501
26.8		729	610
40		1087	910
	40	628	525
	60	942	789

997

998

999

1000 **5.6.2 Electrode Surface Current Density Ratings**

1001 Table 8 below shows the current rating of typical electrodes. The limiting factor tends to be
1002 heating at the electrode-soil interface, consequently the ratings are dependent on soil
1003 resistivity.

1004

1005 **Table 8 - MAXIMUM CURRENT RATING OF TYPICAL ROD, TAPE AND PLATE ELECTRODES**

Soil Resistivity $\Omega \cdot m$	3 - Second Current Rating				1 - Second Current Rating			
	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape	Rod 16mm Dia. A (per metre length)	Plate 915 x 915mm A	Plate 1220 x 1220mm A	25 x 4 mm tape
10	69.7	2322	3135	80.3	120.7	4022	6979	138.9
30	40.2	1340	2217	46.4	69.7	2322	4128	80.3
40	34.9	1161	1568	40.1	60.4	2011	3575	69.3
50	31.2	1038	1402	35.9	54	1799	3197	61.7
60	28.4	948	1280	32.7	49.3	1642	2919	56.8
70	26.3	878	1185	30.3	45.6	1520	2702	52.6
80	24.6	821	1108	28.3	42.7	1422	2528	49.2
100	22	734	991	25.4	38.2	1272	2261	44
150	18	600	810	20.7	31.2	1038	1846	35.9
200	15.6	519	701	17.9	27	899	1599	31.2
250	13.9	464	627	16	24.1	804	1430	27.8
300	12.7	424	572	14.6	22	734	1305	25.4

1006

1007 In most practical installations the actual values of surface current density will be considerably
1008 less than the above limiting values, due to the quantity of bare buried conductor (electrode)
1009 employed in the installation to provide effective bonding and in some installations where
1010 extra electrodes have been added, to comply with the touch potential limits. **Further detail is
1011 given in EREC S34 – Equation to go in S34 and to be referenced from here;** note that this
1012 current density limit is independent on electrode material, and therefore the limits can be
1013 applied to rebar/piling/other 'fortuitous' or auxiliary electrodes, providing that temperature rise
1014 in these structures under fault conditions will not cause issues such as cracking/distortion
1015 etc.

1016 Where an electrode is encased in a material such as concrete, or material/agent other than
1017 surrounding soil, the surface area calculation should be carried out at the electrode-material
1018 interface, using the surface area of the metallic electrode itself and the properties of the
1019 'agent'. In some cases it will also be necessary to carry out a similar calculation at the
1020 interface of the 'agent' with surrounding soil, noting that the larger surface area offered by the
1021 agent will apply.

1022 A well designed earthing system should provide sufficient surface area to satisfy this
1023 requirement without reliance on rebar or other fortuitous / auxiliary electrodes.

1024 **5.7 Design Assessment**

1025 The assessment procedure outlined in 5.7.1 begins with an approximation which, if furnishing
1026 satisfactory results, avoids the need for a more detailed assessment. If the results of this
1027 approximate assessment indicate that the safety criteria could be exceeded or the rise of
1028 earth potential is considered to be excessive, then the more refined assessment should be
1029 employed.

1030 When an entirely theoretical approach is used for assessing the design of an earthing
1031 system, doubts on the reliability of the result may arise due to uncertainties as to the correct
1032 value of soil resistivity to be used or of the effects that other buried structures may have. In
1033 these circumstances recourse may have to be had to direct measurement to obtain a more
1034 reliable result.

1035 Recommended methods of measurement are given in Section 7.5. On the basis that the
1036 earth electrode system will not yet be installed, measurement may be made on
1037 representative test electrodes and the results extrapolated to the intended final design.
1038 Measurement may be delayed until a sufficiently representative part of the intended system
1039 is installed to obtain a better prediction of any improvements necessary. In any event a final
1040 check measurement of the completed installation is recommended prior to energisation.

1041 **5.7.1 Assessment Procedure**

1042 An approximate assessment considers both the internal and external earth fault conditions
1043 as explained above but disregards any contribution that external electrodes, e.g. overhead
1044 line earth-wires or cable sheaths, may have. An approximate assessment may be all that is
1045 required in many cases providing compliance with the safety criteria is demonstrated.

1046 By reference to the flowchart above (Section 5.1):

- 1047 1) Establish the soil resistivity (by measurement or enquiry)
- 1048 2) Estimate the resistance of the site electrode system (using computer modelling or
1049 calculations as detailed in **EREC S34**).
- 1050 3) Obtain the worst-case fault current flowing through the electrode system, disregarding
1051 the effect of 'fortuitous' electrode systems or cable sheath/earthwire return paths.
- 1052 4) Estimate the EPR, which is the product of resistance (point 2 above) and current
1053 (point 3).
- 1054 5) If the value derived in (4) above does not exceed 2x the permissible 'touch' potential
1055 then no further assessment needs to be done. The finalised design of the earthing
1056 system may be prepared taking into account the earthing and electrode conductor
1057 ratings.

1058 If the value derived under (4) above exceeds the appropriate safety voltages by a factor of 2
1059 or more, then a more refined assessment shall be made as detailed below.

- 1060 6) Determine the soil resistivity by measurement.
- 1061 7) Estimate the value of the substation earth electrode system resistance, including the
1062 contributions made by any overhead earthwires and/or earthed cable sheaths
1063 radiating from the site using the preliminary design assessment layout and the data
1064 provided in **EREC S34**.
- 1065 8) Obtain the appropriate total values of system earth fault current for both an internal
1066 and external earth fault and deduce the greater value of the two following quantities

- 1067 of earth fault current passing through the earth electrode system. Refer to EREC S34
1068 for guidance on this evaluation.
- 1069 9) For an internal fault, establish the total fault current less that returning to any local
1070 transformer neutrals and that returning as induced current in any earthwire or cable
1071 sheath/armour.
- 1072 10) For an external fault, that returning to local transformers less that returning as
1073 induced current in any earthwire or cable sheath/armour.
- 1074 11) Estimate the rise of earth potential (EPR) based on the product of items (7) and (9) or
1075 (10) above, whichever is the greater.
- 1076 12) If the EPR value derived under (11) above exceeds 2x the appropriate touch or step
1077 voltages, an assessment covering touch, step, and transfer potentials shall be made.
1078 The design should consider LV, telecoms, and remote systems where relevant (ref:
1079 **EREC S34 Section XXX**)
- 1080 13) If the earthing system is safe against 'touch' potential it will almost always be safe
1081 against 'step' potential*, although special consideration may be needed in certain
1082 situations such as wet areas, livestock, etc.

1083 Reference should be made to **EREC S34** for equations giving ground surface potential
1084 contours; the touch potential is the difference between EPR and ground surface potential up
1085 to 1m from plant / bonded items. Computer modelling may be necessary for complex
1086 systems.

1087 Depending on the results of the evaluation, further improvements in the design of the earth
1088 electrode system may be necessary until the appropriate safety criteria for touch, step and
1089 transfer potentials are met and any necessary isolation or additional insulation is provided to
1090 avoid contact with transferred potentials which exceed the appropriate safety limit.

1091 **5.7.2 Methods to improve design (Mitigation measures)**

1092 Following assessment, if the safety criteria are not met, the designer shall consider ways to
1093 either a) reduce overall EPR, or b) reduce the step/touch voltages.

1094 **5.7.2.1 EPR reduction**

1095 As described in 4.4.1, there is no specified limit to the rise of earth potential of the substation
1096 and the ultimate design limit is dependent on a number of factors. However, improvements
1097 may sometimes be justified to lower this value by reducing the value of the earth electrode
1098 resistance. If, for example, the surface potential outside the substation exceeds that which is
1099 acceptable to third parties in that area (e.g. telecoms or pipeline operators), then lowering the
1100 earth electrode resistance (and consequent EPR) may be considered.

1101 Reduction of earth resistance by extending electrode area may increase transfer potential
1102 onto third party metallic services and this must be considered in the design. Note that it may
1103 be cheaper and more practical instead to protect the other authorities' plant by isolation or
1104 additional insulation.

1105 EPR (arising from local faults) can generally be reduced by one or more of: a) earth
1106 resistance reduction, b) fault level reduction, or c) reducing the ground return component.

- 1107 a) Is probably more practical to achieve by installation of additional electrode.

* As stated in BS EN 50522: As a general rule meeting the touch voltage requirements satisfies the step voltage requirements, because the tolerable step voltage limits are much higher than touch voltage limits due to the different current path through the body.

1108 b) Can be achieved by impedance earthing (section 4.5.1), or changes to running
1109 arrangements, or possibly more accurate calculation of earth fault level including
1110 earth resistance values (which may be of benefit in marginal situations).

1111 c) Can be achieved by lower impedance metallic return paths (e.g. enhanced cable
1112 sheaths or earth-wires), or undergrounding a section of overhead line to make a
1113 complete cable circuit).

1114 An excessive EPR arising from transfer voltage, e.g. carried along the cable sheath from the
1115 source substation, can be reduced by lowering earth resistance as a) above, or by
1116 introducing a sheath break into the cable (e.g. by using an insulated gland or un-earthed
1117 overhead line section); special care is required in such circumstances to ensure that an
1118 individual cannot contact two earthing systems simultaneously. There may be other
1119 considerations which make a sheath break unacceptable or ineffective in some
1120 circumstances. Alternatively, measures could be employed to lower the EPR at the source
1121 substation. In any case, the design must be re-assessed to consider these revised
1122 arrangements.

1123 5.7.2.2 Touch Voltage reduction

1124 If reduction of EPR is not practicable or economic, touch voltage can be reduced by adopting
1125 measures to equalise potential between an operator's hands and feet; generally these
1126 measures involve additional bonded grading electrode or mesh under the operator's position,
1127 or insulated platforms.

1128 Equations are provided in **EREC S34** which give simple touch voltage calculations.

1129 The touch and step voltages must be re-calculated or re-modelled following any changes to
1130 the electrode layout. The touch voltages appearing on external parts of a substation
1131 (fences/doors/substations) must also be considered as these could cause issues for
1132 members of public.

1133 In some circumstances, asphalt (tarmac) or similar ground coverings may be used to justify
1134 an increase in the permissible limits so that the touch voltages are acceptable (see Section
1135 4.4.1). Protection enhancement (faster fault clearance) may be also explored in similar
1136 circumstances, since permissible limits for touch/step voltage are higher if faster fault
1137 clearance times can be achieved. These two measures should not be considered an
1138 alternative to a properly designed earthing system and should be used only as a last resort,
1139 or in conjunction with the risk assessment approach outlined below.

1140 **5.8 Risk Assessment**

1141 In some situations it may not be reasonable to achieve compliance with permissible safety
1142 voltages at all locations in and around a substation. Nevertheless, in some locations (e.g.
1143 unmanned sites with restricted access), it may be deemed to be an acceptably low risk. It is
1144 recognised in new standards that some risk must be accepted in order to provide electrical
1145 infrastructure to society.

1146 As set out in BS EN 50522, risk assessment is one of the acceptable tools for analysis of
1147 situations where the cost of removing an identified risk appears to be disproportionately high.
1148 A risk-based approach needs to consider the statistical probability of injury occurring, and to
1149 weigh this against the cost needed to mitigate against that risk.

1150 Risk Assessment should only be used in circumstances where strict compliance with
1151 permissible safety voltage limits cannot be achieved, and where there are valid and well
1152 documented reasons for this. It should be used only as a last resort, as described in the
1153 flowchart in Section 5.1.

1154 Typical applications for risk assessment may be those outside an installation, on the basis
1155 that it is almost always possible to control step and touch potentials within the confines of a
1156 substation by using appropriate buried electrode and/or ground coverings.

1157 **Case Study XX** in section 11 describes a typical example of a house that has been built close
1158 to a substation with high EPR. Under substation fault conditions, touch voltages exceeding
1159 permissible design limits can appear in and around the house, due to voltage differences
1160 between the elevated soil potential and the remote LV system entering the house. The risk
1161 assessment approach allows the need for mitigation measures to be evaluated.

1162

1163 **6 Construction of Earthing Systems**

1164 **6.1 General Design Philosophy**

1165 Above ground connections may use copper or aluminium conductors. Metal structures may
1166 be used to provide connections between equipment and the earth grid where appropriate.

1167 Below ground earth grids will normally be installed using copper conductor.

1168 When designing and installing both above and below ground earthing installations the risk of
1169 theft and corrosion must be considered and mitigation measures put in place where
1170 necessary.

1171 **6.1.1 Materials**

- 1172 • The use of copper earthing conductor is preferable due to its electrical and material
1173 properties.
- 1174 • Copper tape and (hard drawn) stranded copper conductor (min strand diameter 2mm)
1175 may be used as buried electrode.
- 1176 • Bare aluminium or copper rope (fine braided) conductors must not be used
1177 underground in any circumstances due to risk of accelerated corrosion.
- 1178 • Aluminium (which is less prone to theft) may be used at least 150mm above ground.
- 1179 • Galvanised steel may be used as supplementary electrode where it is already installed
1180 for other reasons. Consideration should be given to the risk of corrosion over the
1181 lifetime of the installation. [Galvanised steel has an electropotential different to that of
1182 copper and can erode quickly if connected to a system which has copper electrodes]
- 1183 • In very hostile environments it may occasionally be necessary to use more resilient
1184 materials such as stainless steel.

1186 **6.1.2 Avoiding Theft**

1187 At the design stage all exposed copper electrode should be reduced to a minimum.
1188 On new installations above ground exposed copper and aluminium sections should be fixed
1189 using anti-theft fixing techniques. See Section 6.3.1 for conductor fixing detail.

1190 At new and existing high risk sites the use of additional anti-theft precautions must be
1191 considered.

1192 Precautions above ground may include:

- 1193 • application of anti-climb paint on above ground sections and / or above ground copper
1194 may be painted to look like aluminium or galvanised steel;
- 1195 • fitting galvanised steel anti-theft capping over the conductor to a height of at least 3 m
1196 or the equipment position;
- 1197 • fitting steel banding around structures and pinning the fixings;
- 1198 • stamping copper tape electrode with the owner's name;
- 1199 • earth connections to such items as metal cladding, metal structures, metal door frames
1200 or any other metallic panels should be made inside buildings;
- 1201 • additional site security precautions such as the application of alarms, electric perimeter
1202 fences, CCTV etc.;
- 1203 • use of forensic traceable liquids;
- 1204 • avoiding yellow/green insulated coverings (use e.g. grey instead).

1206 Precautions below ground may include:

- 1207 • placing concrete or concrete anchor blocks over buried electrode;
- 1208 • attaching earth rods every few metres to prevent removal of electrode;

- 1209 • pinning electrode at least every 300 mm where it is installed in concrete trench work or
- 1210 over concrete plinths;
- 1211 • laying electrode in conductive concrete or similar materials.

1212 Earthing conductors located in pre-formed concrete trenches (or similar) containing power
1213 and/or multicore cables should be fixed to the walls near the top (e.g. 100mm from the top).
1214 Where possible they should be concealed or otherwise protected against theft.

1215 **6.2 Jointing Conductors and Equipment Connections**

1216 **6.2.1 General**

1217 Exothermic welded, brazed and compression type joints are acceptable above and below
1218 ground.

1219 Bolted joints are only permissible above ground. For replacement work following theft this
1220 may not be initially practical but any temporary bolted underground joints must be replaced to
1221 make the repairs permanent.

1222 For connections made to equipment welded joints may be possible, but in the majority of
1223 cases, bolted joints will be necessary. The provision of bolted earth connections on
1224 equipment needs special consideration to achieve a low resistance arrangement which can
1225 withstand the maximum earth fault current without deterioration. Purpose designed
1226 connections should preferably be provided by the equipment manufacturer.

1227 Bolted connections should preferably be of the double bolt / double hole lug fixing type,
1228 however this generally requires drillings to be provided at the equipment procurement stage.
1229 Where single bolt / single hole lug fixings are provided the application of a washer and
1230 second (lock) nut provides extra security.

1231 With aluminium conductors in particular surface preparation is critical to achieving
1232 connections with ongoing low resistance.

1233 Nuts, bolts and washers are to be of high tensile stainless steel or galvanised steel, except
1234 for transition washers used for joining dissimilar metals.

1235 **6.2.2 Transition washers**

1236 A transition washer may be used to minimise corrosion when joining dissimilar metals with a
1237 bolted connection. Transition washers designed for copper-aluminium joints shall be surface
1238 penetrating, grease protected washers manufactured from corrosion resistant copper alloy to
1239 BS2874 (grade CZ121). They are designed to provide a stable corrosion resistant interface
1240 between aluminium and copper or tinned copper, and are usually provided as a pack
1241 including appropriate matched nuts, bolts and washers.

1242 Different transition washers may be required for connections from copper to galvanised
1243 metal.

1244 Transition washers tend not to be widely used for connections between aluminium and zinc
1245 coated (galvanised) steel, because zinc and aluminium are very close in the galvanic series.
1246 Such connections are likely to corrode however once the zinc coating has been lost, and
1247 therefore precautions should be taken to exclude moisture by use of an appropriate grease
1248 or paint applied after the joint is made.

1249 All bolted joints should be painted with two coats of bitumen paint, where practicable, as an
1250 aid to preventing corrosion.

1251 **6.2.3 Copper to Copper Connections**

1252 Tape to tape connections must be brazed or exothermically welded.

1253 Stranded to stranded connections must be exothermically welded or joined using
1254 compression joints.

1255 Stranded to tape connections must be exothermically welded or a lug must be compressed
1256 onto the stranded conductor, which for underground use is bolted and then brazed or welded
1257 onto the copper tape. For above ground purposes, the lug may be bolted to the tape but
1258 should preferably have a double bolt fitting.

1259 Soft soldered joints (e.g. lead-tin or lead free solder) shall not be used.

1260 **6.2.4 Copper to Earth Rods**

1261 Connections must be brazed or exothermically welded. Bolting and U-bolts are not
1262 acceptable. [Except for smaller distribution substations where hot works may not be
1263 practicable].

1264 **6.2.5 Electrode Test Points**

1265 Electrode test points may be required either at the rod top for long single rods or inline
1266 between a rod group and the main earthing system. To allow individual rod resistance values
1267 to be tested with a clip-on meter and facilitate electrode tracing all test points should be
1268 suitably constructed to allow the test clamp to fit and to avoid corrosion.

1269 Test links are not recommended, but where installed special procedures must be adopted to
1270 avoid inadvertent disconnection and to permit safe management/testing techniques.

1271 A test point associated with pile cap connections is useful but only if the design of the rebar
1272 is electrically separated from the rest of the site. At most sites the rebar will be connected
1273 together and while this provides an excellent earth, testing the individual pile cap earths is
1274 impossible. In these cases separate earth pins should have been provided in the design
1275 perhaps for high frequency and/or lightning protection which will allow testing between
1276 individual earth rods and the main earth grid.

1277 **6.2.6 Copper to Equipment (Steel, or Galvanised Steel) Connections**

1278 Connections should, wherever possible, be in the vertical plane. Remove paint from the
1279 metal at joint position on the equipment earth, sand metal smooth and apply neutral jointing
1280 compound. Drill the copper tape to accommodate the bolts (normal diameter is 10 mm) and
1281 then tin the complete contact area. The bolt holes must be less than one-third the width of
1282 the tape. Failing this a copper flag must be jointed to the copper tape and the holes drilled
1283 into this. A two bolt fixing is preferred, unless a suitably rated fixing is provided by the
1284 manufacturer. Copper joint surfaces, once drilled should be cleaned using aluminium oxide
1285 cloth (grade 80). Copper is tinned at all bolted connections; the tinning needs to be thin, and
1286 should not exceed an average of 0.5 mm, otherwise it will 'flow' from bolted sections under
1287 pressure. Neutral jointing compound is then to be applied to the joint faces.

1288 The same procedure should be used when joining to galvanised steel, in which case the zinc
1289 coating shall be removed from the joint faces.

1290 **6.2.7 Aluminium to Equipment Connections**

1291 Aluminium conductor connections to equipment should, where possible be in the vertical
1292 plane. In all cases joints must be made in accordance with Section 6.2.6 above. However,

1293 the aluminium tape should not be tinned, and appropriate transition washers should be used
 1294 at the aluminium to steel interface.

1295 **6.2.8 Aluminium to Aluminium Connections**

1296 The preferred method is either inert-gas tungsten-arc (TIG) or inert-gas metal arc (MIG)
 1297 welding provided that the area of the welded material at least matches that of the tape cross
 1298 section. Bolted joints are acceptable since aluminium is only used above ground.

1299 For bolted joints the following applies:

- 1300 • All joints require a two bolt fixing.
- 1301 • Bolts must be high tensile galvanised steel, fitted with large diameter galvanised steel
 1302 washers, or (optionally), transition washers designed to penetrate the aluminium
 1303 oxide coating.
- 1304 • The surface aluminium must be cleaned using grade 80 aluminium oxide cloth or
 1305 equivalent and coated with neutral compound grease. This may not be necessary if a
 1306 transition washer is used, in which case manufacturer’s guidance should be followed.
- 1307 • Bolts must be tightened using a torque wrench, to avoid over stressing in accordance
 1308 with Table 9 below. It is important not to compress aluminium connectors by excessive
 1309 tightening, as loss of ‘elasticity’ by plastic deformation can result in loosening of the
 1310 connection when subject to thermal cycling.
- 1311 • All excess grease must be wiped off the finished joint.
- 1312 • The joint must be sealed with two coats of bitumastic paint or equivalent.

1313

1314 **Table 9** – Bolt sizes and torques for use on aluminium

1315 Dimensions in millimetres

Bar Width	Bar Overlap	Bolt Diameter	Hole Size	Recommended Torque (Nm)	Washer Size	Washer Thickness
40	80	10	12	35	OD 25 ID 11	2.5
60	100	12	14	50	OD 28 ID 12.5	3.0

1316

1317 **6.2.9 Aluminium to Copper Connections**

1318 Connections are to be in the vertical plane, at least 150mm above the ground or concrete
 1319 plinth. They must be located in positions where water cannot gather and the aluminium will
 1320 be above the copper. Bimetallic joints must not be made on buried sections of electrode.

1321 All connections involving dissimilar metals must be cleaned with abrasive cloth and coated
 1322 with neutral compound grease, before making a bolted connection. Copper must be pre-
 1323 tinned. The finished joint should be sealed using bitumastic paint, compound, water proof
 1324 tape or a heat shrink tube filled with neutral grease. A transition washer [section 6.2.2] may
 1325 be used to minimise corrosion at bolted joints.

1326 Where joints have been made closer to ground level than 150 mm (usually following theft),
 1327 a corrosion risk assessment is necessary. If the ground is well drained and there is little

1328 chance of water being retained around the joint then the above arrangement is acceptable. If
1329 not then the copper must be extended upwards to reduce risk of corrosion.

1330 **6.2.10 Earthing Connections to Aluminium Structures**

1331 The following procedures are necessary to ensure that aluminium structures used to support
1332 substation equipment do not corrode:

1333 (i) The bottom surface of the structure base and the top surface where galvanised
1334 steel or other equipment is to be fitted, must be painted with two coats of
1335 bitumastic paint, prior to bolting into position on the concrete plinth. (Note - this
1336 reduces the possibility of bimetallic action which would corrode the aluminium). A
1337 conducting strap is required between any steel of the top level equipment support
1338 and the aluminium structure.

1339 (ii) Provision should be made for connecting below ground conductor to the structure
1340 via a suitable drilling and bi metallic connection (ref. 6.2.9).

1341 (iii) Except for fault throwers and high frequency earths (capacitor voltage
1342 transformers and surge arresters) the aluminium structure leg(s) may be used to
1343 provide earth continuity down to the connection to the main earth grid. The
1344 following is also necessary:

1345 Any bolted sections of the structure that may be subject to bimetallic corrosion, and/or may
1346 be of insufficient cross section, should be bridged using aluminium earth tape. The bridged
1347 joint must be made as any other aluminium to aluminium earth connection. Totally tinned
1348 copper straps can be used if necessary on connections to insulator supports from the
1349 aluminium. The copper and completed connection must be painted to prevent moisture
1350 ingress and corrosion.

1351 The aluminium structure must be connected to the main substation earth grid, using copper
1352 tape that is tinned at the joint position.

1353 Where the legs of the support structure are greater than two metres apart or the structure
1354 forms a bolted TT (or goalpost type) formation, an earth connection must be made on two
1355 legs of the structure.

1356 **6.2.11 Steel Structures**

1357 Steel structure legs should be used wherever practicable to provide the connection between
1358 the earth grid and equipment at the top, except for fault throwers and earth switches. For
1359 equipment requiring high frequency earths (e.g. capacitor voltage transformers and surge
1360 arresters), refer to section 6.14.

1361 Ideally the structure should be of the welded type or have one or more legs formed with a
1362 continuous section from ground to equipment level.

1363 If a steel structure is used to convey fault current, it must be reliable, and of sufficient current
1364 carrying capacity to avoid excessive temperature rise. If there is reliance on a single joint or
1365 leg, bolted shunts shall be considered. Where bolted shunts are used, the temperature rise
1366 of bolted connections shall be limited to 250 °C. Refer to Section 0.

1367 Joints should be reliable. Galvanising (zinc coating) of the steel forms an oxide which
1368 increases in thickness with age and could create a high resistance at steel - steel joint
1369 surfaces.

1370 Where aluminium tape is connected to a galvanised steel structure a transition washer is not
1371 required, however adequate preparation of the joint surfaces, and protection from water

1372 ingress is required in accordance with normal best practice. Refer to Section 6.2 for more
1373 detail of jointing practices.

1374

1375 **6.3 Above Ground Earthing Installations**

1376 **6.3.1 Fixing Above Ground Conductor to Supports**

1377 Previous standards required that above ground copper or aluminium tape was fixed to
1378 structures at 1m intervals using cleats. This is acceptable from a technical prospective;
1379 unfortunately the cleats used provide a convenient way for the above ground conductor to be
1380 stolen.

1381 To prevent theft, the following methods of fixing shall be used:

1382 Pinning at least every 300 mm for higher security using stainless steel pins. (The pins should
1383 have plastic spacers to separate the pin from the conductor and in the case of aluminium,
1384 plastic spacers to separate the aluminium from galvanised steelwork).

1385 Drilling and screwing with tamper proof screw heads. This method is more appropriate if the
1386 concrete support may be damaged by use of percussion driven pins. Again a plastic spacer
1387 is required to separate the screw from the metal. The screws should be stainless steel.

1388 It is important that the pins or screws are fitted such that water cannot gather and cause
1389 corrosion. Aluminium should preferably not be in direct contact with concrete, so if
1390 practicable, the back of the conductor should be coated with a high temperature aluminium
1391 grease or other heat-proof coating to prevent this.

1392 Consideration must be given to the reduction of conductor cross sectional area and current
1393 carrying capability due to drilling. Any holes introduced into the earth conductor should not
1394 exceed 10mm in diameter and one third of the width.

1395 Note that the design final temperature of a bolted connection is 250 °C, compared to that of
1396 405°C (copper) and 325°C (aluminium). Consequently earthing conductors with bolted
1397 connections have a rating that is between 80% and 90% of their normal value.

1398 **6.3.2 Prevention of Corrosion of Above Ground Conductors**

1399 Copper strip conductor supported from or in contact with galvanised steel should either be
1400 tinned or coated in a high temperature grease to prevent electrolytic action.

1401 Unless it is protected, aluminium earthing conductor should not be laid within 150 mm of
1402 ground level.

1403 **6.3.3 Metal Trench Covers**

1404 Within substation buildings, trench covers need to be indirectly earthed. This is best achieved
1405 by installing a copper strip (25mm x 3mm) along one edge of the trench top edge. The
1406 covers will be in contact with this when in position. The copper strip should be bonded to the
1407 switchgear earth bar or internal earthing system.

1408 [Feedback awaited re: Computer flooring / suspended flooring]

1409 **6.3.4 Loops for Portable Earth Connections**

1410 Earth loops of aluminium or copper strip conductor connected to the structure earth
1411 connection, must be provided at appropriate locations where portable earth leads need to be
1412 applied. The loops, if not provided as part of the structure shall preferably be formed
1413 separately and jointed to the aluminium or copper tape. Recommended size should be not
1414 less than 230 mm long and 75 mm high.

1415 Loops must not be installed in the run of high frequency earths associated with CVTs and
1416 surge arrestors since these will introduce a high impedance to high frequency/steep fronted
1417 surges. A loop for portable earths may be added in parallel to the straight earthing conductor
1418 rather than as a loop formed in the earthing conductor itself. 'D' loops should only be
1419 installed on fully rated conductors.

1420

1421 **6.4 Below Ground Earthing Installations**

1422 **6.4.1 Installation of Buried Electrode within a Substation**

1423 The electrode must be installed at least 600 mm deep. This gives physical protection to the
1424 electrode and connections. It also tends to place the electrode in moist soil below the frost
1425 line so helping ensure its resistance is stable. The resistivity of ice is in the region 10,000 to
1426 100,000 Ohm.m (e.g. compared with 10-1000 Ohm.m for most soils), therefore an earthing
1427 system's resistance will increase significantly if it is not clear of frost.

1428 Buried earth electrode should be surrounded by 150 mm of fine texture non-corrosive soil,
1429 firmly consolidated. The use of pulverised fuel ash (PFA) or coke breeze as backfill is not
1430 recommended as it may induce rapid corrosion of buried electrode and metallic cable
1431 sheaths. Where there is a risk of corrosion, the electrode size may need to be
1432 increased.

1433 If the indigenous soil is hostile to copper, i.e. acidic with a pH value of less than 6 or alkaline
1434 with a pH value of more than 10, suitable surrounding soil should be imported. However, if
1435 groundwater is present (which may serve to remove the imported soil) then other methods
1436 may be necessary to protect the electrode. More regular testing or inspection may be
1437 required.

1438 When laying stranded conductor, care should be taken to avoid distorting and opening the
1439 individual strands, because this increases the probability of accelerated corrosion.

1440

1441 **6.4.2 Positioning of Buried Electrode**

1442 The laying of earth electrode close and parallel to hessian served power cables, multicore
1443 cables, or bare metal pipes, is to be avoided. This is to reduce the risk of them being
1444 punctured due to high currents or voltage transients on the electrode.

1445 Electrode must be at laid at least 300 mm away from hessian served power cables and bare
1446 metal pipes and 150 mm away from plastic sheathed cables. Where a crossing is necessary,
1447 PVC tape or a split plastic duct must be applied around the cable or pipe for 0.5 m either side
1448 of a position where the cable or pipe crosses an earth electrode, or for the distance over
1449 which the 0.3 m separation cannot be maintained.

1450 Where copper tape within the site is to be buried under proposed cable routes care must be
1451 taken to ensure it is buried deep enough or otherwise protected in a duct so that it is not
1452 damaged during cable installation.

1453 Where electrode connected to the earthing system is laid under metal fencing, and the
1454 fencing is independently earthed, the electrode should be insulated for at least 2 m each side
1455 of the fence.

1456 Earthing conductors laid near drainage pits or other civil works should maintain a separation
1457 of at least 500 mm to avoid mechanical damage during subsequent works.

1458 Where bare electrode has to cross permanent trench routes:

- 1459 • short lengths of electrode may be laid under the trench for later connection to the
1460 grid;
- 1461 • a short duct may be laid under the trench to accommodate the electrode.

1462 Subsidiary connections to equipment may be laid at shallower depth. Due to variation of soil
1463 resistivity near the surface, their contribution to the overall earth resistance should be ignored
1464 in the design. Their contribution towards reducing touch and step potentials should be
1465 included.

1466 In cases where a concrete plinth covers the whole substation site, (e.g. 11 kV/LV unit type or
1467 urban 33kV substations) earth electrodes should be installed prior to construction of the
1468 plinth. Provision should be made to bring multiple connections out through the concrete. The
1469 extent of the electrode mesh required will be influenced by whether steel reinforcing is used
1470 and bonded, within the foundation.

1471 When routing bare electrode off site, either to reduce the overall earth resistance or to
1472 provide a connection to external equipment such as terminal poles, routes that may be
1473 frequented by people with bare feet or animals are to be avoided.

1474 If this is not possible, calculations or computer modelling should be used to confirm that the
1475 step potentials in these areas are acceptable (a design figure of 25 V/m may be used for
1476 livestock areas as described in Section 4.4.2). Where electrode crosses land that is
1477 ploughed it should be installed a minimum of 1m deep.

1478 When rebar is installed in building and equipment foundations duplicate connections may be
1479 made from the rebar to the grid for touch voltage control. (See section 6.5).

1480 Burying copper in concrete below ground level, and at a depth such that the moisture content
1481 remains reasonably stable, does not reduce the effectiveness of the earthing [except where
1482 damp-proof membranes are installed].

1483

1484 **6.4.3 Other Earth Electrodes**

1485 6.4.3.1 Earth Rods

1486 These are generally convenient to install where the subsoil is free from boulders and rock.
1487 Rod electrodes and their connections should be in accordance with ENA TS 43-94. The
1488 earth resistance of a rod or group of rod electrodes may be calculated from formulae given in
1489 **EREC S34**.

1490 A number of rods may be connected in parallel but they should be installed with sufficient
1491 spacing apart such that each is essentially outside the resistance area of any other. For
1492 worthwhile results the mutual separation should be not less than the depth of the rod.

1493 The rods may be connected to the earth grid via a test chamber which is capable of
1494 accepting a clip on resistance meter.

1495 Deep earth electrodes should, as far as possible, be driven into the earth vertically. If rods
1496 are installed in drilled holes they may be backfilled with a proprietary low resistance backfill
1497 material.

1498 Rods may be particularly advantageous if the earth resistivity falls with depth. If several deep
1499 earth electrodes are necessary in order to achieve a required parallel resistance, then, where

1500 space is available, the mutual minimum separation could usefully be double that of the
1501 effective length of an individual earth electrode.

1502 Substations in large urban developments are often located below ground level in tanked
1503 structures. In such situations special facilities for installing earth electrodes are required.

1504 6.4.3.2 Earth Plates

1505 Earth plates tended to be used in older earthing system designs when they were often
1506 situated in groups or “nests” near the main transformers. Modern designs make little use of
1507 plates, except where the soil is such that it is difficult to drive in earth rods or at the corners of
1508 the earth grid perimeter electrode. In this case a plate will be installed in the vertical plane
1509 and acts as a replacement for a rod.

1510 In older sites, should an earth plate require replacement, it is likely that the earthing system
1511 itself will require redesign and this may render the plate obsolete. Where there is any doubt,
1512 the plate can be replaced on a like for like basis, or by several 2.4m rods in parallel, close
1513 together. Plates are typically 1220 mm or 915 mm square in size, of ribbed cast iron and
1514 approximately 12 mm thick.

1515 **6.5 Use of Structural Earths including Steel Piles and Rebar**

1516 Structural metalwork (piles and foundations) can make a valuable contribution to an earthing
1517 system, specifically providing parallel paths for earth fault current, reducing overall earth
1518 resistance and increasing resilience. Such contributions should be viewed as additional,
1519 rather than instead of, a dedicated earthing system.

1520 Horizontal (meshed) rebar installed in concrete or in a screed below plant can provide good
1521 control of touch voltages. In this sense it should be viewed in terms of touch voltage control,
1522 rather than as an electrode system.

1523 **6.5.1 Sheet Steel Piles**

1524 Sheets that are more than 3m long and 2m wide are to be bonded to the earthing system, as
1525 specified by the Design Engineer. Stainless steel studs are to be exothermically welded to
1526 each second sheet at a suitable height (normally 600mm below finished ground level) and a
1527 strip of 40mm x 4mm copper tape will be bolted to these. The strip will in turn be connected
1528 to the main substation earthing system. If the piles form a separate electrode connected to
1529 the earthing system at one point, then the connection should be via a test chamber such that
1530 the contribution of the piles may be monitored. Bolted connections should be avoided where
1531 possible.

1532 **6.5.2 Horizontal Steel Reinforced Foundations**

1533 For transformer and switch rooms, the most significant benefit of shallow rebar mesh is in
1534 potential grading (touch voltage control). Where this is necessary to ensure operator safety
1535 (i.e. in situations where the EPR exceeds safe touch voltage limits), it is important to ensure
1536 the integrity of any connections.

1537 For touch voltage control, rebar will be installed normally at shallow depth (i.e. with the rebar
1538 strips bound with soft steel wire, or as a prefabricated mesh), but with two or more rebar
1539 connections left protruding from the concrete for approximately 150mm sufficient to allow
1540 connection to copper or aluminium conductors. Alternatively connections may be provided
1541 before concrete is poured using a rebar clamp with flexible earth conductor. In either case
1542 any inaccessible rebar extension used for the final connections must be welded to the main
1543 rebar assembly.

1544 Ideally the rebar should be arranged with welded connections along at least two orthogonal
1545 edges such that welded joints connect each bar.

1546 If the rebar in concrete is to function as an auxiliary earth electrode (e.g. it is installed at
1547 sufficient depth to make a contribution), then current rating considerations may mean that
1548 exothermic welding is necessary for connections to the rebar and between rebar meshes.

1549 NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

1550 **6.5.3 Vertical Steel Reinforced Concrete Columns**

1551 Where these columns have steel reinforcing that extends further into the ground than it is
1552 possible to bury a conventional earthing system, then the design may require these to be
1553 bonded to the earthing system. The easiest method is to leave a section of bonded rebar
1554 150mm out of the concrete for a connection to be made later by the earth installers. This
1555 steel reinforcing bar must have its electrical continuity maintained at joint positions by
1556 welding the connection. Some designs require electrical connections between the piles made
1557 with rebar. In this case supervision of the civil works will be required before concrete is
1558 poured.

1559 NOTE: Protruding rebar may not be acceptable in some circumstances due to concerns with water ingress etc.

1560 **6.6 Metallic Fences**

1561 Two alternative earthing arrangements may be applied to metallic substation fences. These
1562 are:

- 1563 • an independently earthed (or segregated) fence arrangement where the fence is kept
1564 electrically isolated from the substation main earth system (Figure 2) or:
- 1565 • a bonded fence arrangement where the fence is bonded to the substation main earth
1566 system (Figure 3).

1567 Occasionally it may be appropriate to employ both methods on different fence sections at the
1568 same site. In this case insulated sections are used to physically link the fences with different
1569 earthing arrangements.

1570 Where the fence panels are supported by steel posts that are at least 1m deep in the ground,
1571 the posts can be considered as earth electrodes.

1572 Where it is important (mainly overhead lines crossing or in parallel with the fence or proximity
1573 to magnetic fields) to provide electrical continuity between adjacent panels, this can be
1574 provided by attention to the bolt/fixing connections or by providing a separate continuity
1575 conductor (buried or supported on the fence).

1576 **6.6.1 Independently Earthed Fences**

1577 Where the substation earthing system is effectively within the substation perimeter fence, the
1578 fence should be separately earthed with rods approximately 2.4 m long located at:

- 1579 • all fence corners;
- 1580 • one metre either side of each point where HV overhead conductors cross the
1581 fence;
- 1582 • additional locations such that the interval between rods sites shall not exceed
1583 50m.

1584 Gate posts should be bonded together with below ground connections to ensure that
1585 difference potentials do not arise when the two parts are bridged by a person opening the

1586 gates. Flexible copper bonds (minimum 16mm² cu or equivalent) should also be used to
1587 bond the gates to the posts as an additional safety measure.

1588 **6.6.2 Segregation between independently earthed fence and earthing system**

1589 A segregation distance above ground of at least 2 metres should be maintained between the
1590 substation fence and the substation earthing system including all items connected to it. (This
1591 is based on personnel avoiding simultaneous contact with the independently earthed fence
1592 and equipment connected to the earthing system.) A similar distance shall be maintained
1593 below ground, where practicable, taking into account the location of substation perimeter
1594 electrodes etc.

1595 The 2m segregation between the independently earthed fence and the earthing system shall
1596 be maintained on an ongoing basis. This must not be compromised by alterations such as
1597 the addition of lighting or security installations, where e.g. cable armours can compromise
1598 the segregation of the systems.

1599 Where the required segregation cannot be achieved then mitigation measures should be
1600 considered (e.g. insulating paint or barriers (that do not compromise security)). Alternatively,
1601 the risk assessment approach outlined in section 5.8 may be applied.

1602 Methods to calculate the transfer potential onto fences are described in **EREC S34**.


1603

1604

1605

1606

Figure 2 – Arrangement of separately earthed fence



1607
1608

1609 6.6.3 Fences Bonded to the Substation Earthing System

1610 This arrangement is used where substation plant and equipment is located with 2m of a
 1611 metallic fence and where internal fences which are located within the area encompassed by
 1612 the substation earthing system. The fences should be connected to the earth grid using
 1613 discrete but visible connections located at:

- 1614
- 1615 all fence corners;
 - 1616 one metre either side of each point where HV overhead conductors cross the fence;
 - 1617 additional locations such that the interval between connections does not exceed
1618 50m.


1619 Where the fence which is connected to the substation earthing system is the perimeter fence,
 1620 and where the touch potential external to the fence could exceed the safety limits set out in
 1621 Table 1, then the following requirements apply.

- 1622
- 1623 A bare electrode conductor shall be buried in the ground external to the perimeter
1624 fence at approximately a distance of 1 metre away and at a depth of 0.5 metres.
1625 In agricultural locations risk of disturbance due to ploughing should be addressed;
 - 1626 The conductor should be connected to the fence and to the earthing system at
1627 intervals of 50 metres or less such that it becomes an integral part of the
1628 substation earthing system. One method to achieve this is to 'expand' the
1629 substation grid such that the fence is located within the area of this grid. (Figure 3
1630 below);

- 1631 • Chippings or asphalt around the substation perimeter will provide additional
 1632 protection to animals/persons outside the substation.

1633 At locations where fencing connected to the substation earth grid abuts with independently
 1634 earthed fencing and this presents a touch hazard, there should be electrical isolation
 1635 between the two fence systems. See para. 6.6.5 for methods of achieving electrical isolation
 1636 between fences using insulated fence sections.

1637 **Figure 3 – Arrangement of bonded fence**



1638
 1639

1640 **6.6.4 Third Party Metallic Fences**

1641 Third parties shall not directly connect their metal fences to a metallic substation fence, as
 1642 this may introduce a transfer potential risk. Where such third party fences are present or are
 1643 likely to be present within 2 m of the substation, one of the options listed below should be
 1644 implemented to maintain electrical isolation between the two fence systems.

1645 Note: Security considerations may preclude this if the third-party fence could act as a climbing aid.

1646

1647 **6.6.5 Insulated Fence Sections.**

1648 Insulated fence sections to segregate lengths of fencing which are bonded to the main earth
 1649 grid from those which are independently earthed or connected to third party fences may be
 1650 used. The insulated sections may be formed by:

- 1651 a) Installing a 2 m (or longer) insulated fence panel made wholly of insulating material.
 1652 b) Installing a 2 m (or longer) metal fence panel mounted on insulated supports /
 1653 standoff insulators. (The insulators need a voltage withstand capability in excess of

1654 the highest EPR at the perimeter of the site whilst at least maintaining the equivalent
1655 physical strength of the fence).

1656 Coated fences (section 6.6.7) must not be treated as insulated sections unless specifically
1657 designed and tested for such purposes.

1658 **6.6.6 Chain Link Fencing (Galvanised or Plastic Coated)**

1659 Such fencing should be earthed by bonding the support posts, fence and straining wires and
1660 any anti-climbing devices to the independent or bonded fence earth electrode system as
1661 appropriate. This may conveniently be achieved by the addition of an electrode run with the
1662 fence to aid bonding/earthing. The fence shall be treated as if it were bare metal, i.e. no
1663 insulation withstand should normally be assumed.

1664 If a touch potential issue exists with a plastic coated chain link fence it should be addressed
1665 by installing a grading electrode rather than by relying on the integrity of the plastic fence
1666 coating which may not be comprehensive and is also likely to deteriorate.

1667 **6.6.7 Coated Fence Panels**

1668 These typically consist of galvanised steel support posts and galvanised steel mesh panels,
1669 all of which are coated. When used for enclosing electrical apparatus or a substation, they
1670 shall be earthed and precautions are necessary to cater against damage or erosion of the
1671 coating. The support posts shall be earthed via a bolted connection and ideally the metal of
1672 each panel should in turn be similarly connected to the post. Ideally these should be via
1673 manufacturer provided facilities. The overall fence is connected to earth in a similar manner
1674 to a separately earthed or bonded metal palisade fence.

1675 Such fences should not be treated as insulating, unless the covering is specifically designed
1676 for this purpose and its longevity can be assured.

1677 If a touch potential issue exists with a coated fence it should be addressed by installing a
1678 grading electrode.

1679 **6.6.8 Electric Security Fences**

1680 When electric security fencing is installed on independently earthed fence installations, the
1681 isolation of segregated fence sections from the main substation earthing system must be
1682 maintained. This may require independent electric fence zones and special consideration of
1683 electric fence earth connections.

1684 **6.6.9 Anti-climbing Precautions**

1685 Where barbed wire or other metal anti-climbing devices are erected along the top of brick
1686 walls or other non-metallic barriers they may be connected to earth using the same
1687 procedure as with fencing. Note that metallic parts not liable to introduce a potential need not
1688 be bonded (e.g. short lengths of barbed wire or spikes etc.).

1689 Care should be taken to ensure that anti climbing guards do not bridge fencing sections that
1690 are designed to be separately earthed or isolated. This includes e.g. the metal centre rods of
1691 plastic 'vane' guards etc.

1692 **6.7 Specific Items**

1693 **6.7.1 Water Services to Substations**

1694 Water supplies to substations shall be run in non-metallic pipes. This avoids the substation
1695 potential rise being transferred outside so endangering other users of the water supply
1696 system. This is now largely a legacy issue at older sites as insulated pipes are used for new

1697 construction. When such an existing site is being refurbished or upgraded at least a section
1698 of insulated plastic pipe should be inserted in the incoming metallic water service.

1699 Any metallic pipe used within the substation site should be bonded to the substation earthing
1700 system and adequately segregated from separately earthed fence sections.

1701 **6.7.2 Non-current carrying metalwork**

1702 Most non-current carrying metalwork of all kinds within the perimeter fence shall be securely
1703 bonded to the main earthing system to ensure that all such items are held to the same
1704 potential and, if called upon to do so, will carry fault currents without damage. Exceptions
1705 apply to conductive parts not liable to introduce a potential, and these need not be bonded.

1706 The cross section of any bonding conductors shall be as described in Table 5 and Table 6. If
1707 there is no likelihood of current flow or corrosion/erosion, equipotential bonding conductors
1708 should be no smaller than 16mm² copper or equivalent.

1709 NOTE: Small metallic items (extraneous metalwork) that are unlikely to introduce or carry a significant potential,
1710 need not be bonded to the main earthing system (ref: 4.2). Such items may include, but are not limited to, window
1711 frames, signposts, wall brackets, small access steps/handrails etc.; However if there is any foreseeable likelihood
1712 of them adopting a potential in service (sufficient to cause a touch voltage hazard), such items should be bonded
1713 to the main earthing system.

1714 Larger items, even if some distance from current carrying metalwork, may adopt a stray voltage due to induction
1715 or capacitive coupling and should always be bonded.

1716 **6.7.3 Items normally bonded to the main earth grid:**

1717 These include:

- 1718 • overhead line termination structures including towers, gantries and earthed wood pole
1719 structures within or adjacent to the substation;
- 1720 • power cable sheaths and armours (at one or more points);
- 1721 • transformer and reactor tanks, coolers and radiators, tap changers, earthing resistors,
1722 earthing reactors, high voltage transformer neutral connections;
- 1723 • metal clad switchgear assemblies and cases, isolators and earth switch bases;
- 1724 • metal gantries and structures and metalwork mounted on wood structures;
- 1725 • metallic building structures including steel frames (bonded at each corner), rebar and
1726 piles. Miscellaneous metalwork associated with oil and air tanks, screens, steel structures
1727 of all kinds;
- 1728 • all panels, cubicles, kiosks, LV AC equipment, lighting and security masts.

1729 Critical items such as transformer tanks and terminal towers shall have duplicate connections
1730 to the main earth grid.

1731 **6.7.4 Items NOT normally bonded to the Earth Grid**

1732 The following list is not exhaustive, and includes some typical items that a designer may
1733 specify to remain un-bonded.

- 1734 • The perimeter fence is only bonded to the main earth system if all or part if it cannot be
1735 kept at least 2 m clear of earthed structures and the main earthing system. (Section 6.6)
- 1736 • Screens of telephone cables where they are taken into HOT sites. (Refer to 4.3.7);
- 1737 • Extraneous non-current carrying metalwork as described in Section 6.7.2
- 1738 • Parts intended to be isolated from earth (e.g. floating fence panels, some stay wires, etc.)

- 1739 • Some protection equipment, or equipment connected to (e.g.) frame leakage protection,
1740 which must be connected to earth in a specific manner.

- 1741 • LV neutrals/earths in some circumstances.

1742 **6.7.5 Non-standard bonding arrangements**

1743 Sometimes it may be necessary to isolate cable sheaths and screens from the main
1744 substation earth grid to avoid transfer potential issues. Such arrangements must be the
1745 subject of a bespoke design and precautions taken at the earth isolation point to avoid touch
1746 potential issues.

1747 NOTE: There may be other considerations which make a sheath break unacceptable or ineffective in some
1748 circumstances. ENA EREC C55 provides further related information.

1749 **6.8 Overhead Line Terminations**

1750 **6.8.1 Tower Terminations Adjacent to Substation**

1751 Where the aerial earth wire of an incoming overhead line terminates on a steel tower /
1752 terminal support adjacent to a substation, continuity shall be provided for current in the earth
1753 wire to flow into the main earthing system. Continuity is to be provided by:

- 1754 • bonding the aerial earth wire to the top of the line gantry, or;
1755 • bonding the aerial earth wire to the top of the tower, and bonding the base of the tower to
1756 the main substation earthing system.

1757 The rating of the bonds must at least be equal to that of the aerial earth wire.

1758 If not bonded via aerial earth wire, the tower must be bonded to the main earth grid via two
1759 continuous conductors which run from different tower legs via separate routes and connect to
1760 two different points on the main earth grid. Each below ground conductor must be fully rated.
1761 The bonds should be buried and be installed so as to minimise risk of theft. If the bonds run
1762 under an independently earthed fence they must be insulated for a 2 metre distance on
1763 either side of the fence.

1764 If the tower legs are located within 2 m of an independently earthed metal fence then the
1765 section of fence adjacent to the tower should be bonded to the tower and electrically isolated
1766 from the rest of the fence. Alternatively the relevant metal fence panels may be replaced by
1767 insulated panels, or suitable insulating coating applied (ref: 4.4.3 and 6.6). If this is not
1768 practicable a risk assessment should be carried out (section 5.8).

1769 **6.8.2 Steel Tower Termination with Cable Sealing Ends**

1770 Where an aerial earth wire terminates on a tower with a sealing end platform or an
1771 associated cable sealing-end compound that is well outside the substation, continuity
1772 between the base of the tower and the main earthing system will be provided by either the
1773 sheaths of the power cables or by an earth continuity conductor laid and installed in
1774 accordance with ENA EREC C55.

1775 **6.8.3 Terminal Poles with Stays Adjacent to Substation Fence**

1776 Stay wires that are external to the site and more than 2 m from the fence or earthed
1777 metalwork may be left un-earthed, if this is in accordance with normal practice. They should
1778 be earthed within the substation compound where possible to minimise risk from current
1779 leakage across the stay insulator.

1780 Earthed stay wires can present a touch potential risk if the stay is in very close proximity to
1781 an independently earthed fence, and may form an inadvertent connection between the
1782 independently earthed fence and the main earth grid. To address this, in addition to installing
1783 the normal upper stay insulator a second stay insulator should be installed as close to

1784 ground level as possible leaving the centre section of the stay unearthed. 2 m segregation
1785 must be achieved between the lower earthed section of the stay including the rod and the
1786 fence.

1787 Unless the earthed stay rod is inside the earth grid, a loop of buried electrode should be laid
1788 around the rod at a 1m radius, and bonded to the rod/main earthing system to control touch
1789 potential.

1790 **6.8.4 Down drop Anchorage Arrangement with Arcing Horns**

1791 Where it is necessary to have an assembly of ferrous fittings such as turn buckles, links,
1792 shackles etc. between the insulators and an earthed structure or ground anchor point,
1793 precautions may be required if the earth fault current is very large.

1794 The earthed end arc-ring (or horn) anchorage arrangement may be attached to the main
1795 earth connection by means of a flexible copper shunt, in order to limit earth fault current
1796 flowing through the discontinuous ferrous fittings. This prevents mechanical damage due to
1797 arcing.

1798 **6.8.5 Loss of Aerial Earth Wires**

1799 If alterations are carried out to overhead lines which break an otherwise continuous aerial
1800 earth wire between substation sites, consideration must be given to the increase in ground
1801 return current and consequent increase in EPR which arises.

1802 There may also be a further increase in EPR due to reduction of the chain impedance
1803 contribution. It may be necessary to consider the installation of an overhead or buried earth
1804 conductor to provide continuity of the aerial earth wire.

1805 **6.9 HV Cable Metallic Sheath / Armour Earthing**

1806 This section covers all HV power cables contained within or entering HV substations but
1807 excludes those HV cables which feed HV/LV transformers located in the substation where
1808 the LV supply is exclusively for use in the substation. The requirements for these latter
1809 cables are dealt with under Section 9.

1810 **6.9.1 Insulated (Polymeric) Sheath Cables**

1811 The metallic sheath/armour of cables can, due to their inductive coupling properties, provide
1812 a very low impedance return path for earth fault current flowing in the cable phase
1813 conductors. This can greatly reduce the current that returns to source though the ground and
1814 subject to the sheath being continuous significantly reduce the EPR at associated terminal
1815 substations.

1816 To achieve this, the sheath/armour must be earthed at least at both ends. This arrangement
1817 of earthing is generally satisfactory for three-core and TRIPLEX type high voltage cables
1818 forming part of general distribution system circuits.

1819 Simply bonding sheaths/armours at both ends of single-core cables or very heavily loaded
1820 circuits such as transformer interplant cables can cause de-rating as large steady-state
1821 currents may flow in the sheath/armours, causing additional heating and risking damage.

1822 Consequently two methods of installation have been developed for single-core cables where
1823 the length is sufficient to cause this problem.

1824 a) Single Point Bonding – where the sheaths are connected to earth at one point. A parallel
1825 Earth Continuity Conductor may be laid with the cables to provide continuity between
1826 items of plant.

1827 b) Cross bonding – where the sheaths are connected to earth at each end, and periodically
1828 transposed to cancel circulating currents flowing in the sheaths.

1829 Single-point bonding preserves the rating of the cables, but permits a voltage to develop
1830 between the sheaths/armours and earth at the unearthed ends of the cables which could, on
1831 long cable runs, require shrouding or other measures to ensure safety.

1832 Cross-bonding provides a return path for earth fault current in the sheaths without permitting
1833 significant steady-state de-rating current to flow or exceeding the sheath voltage rise limit.
1834 Care is needed at link boxes/transposition points.

1835 Both methods, together with their merits and disadvantages are described in detail in ENA
1836 EREC C55 “Insulated Sheath Power Cable Systems”, together with solutions to the problems
1837 described above. A bespoke cable and earthing / bonding design is usually required for very
1838 heavily loaded circuits (e.g. interplant cables) or circuits operating above 33 kV.

1839 Methods for calculating the sheath return current and resulting ground return current (for
1840 systems with sheaths earthed at both ends) are given in **ENA EREC S34**.

1841 **6.9.2 Cables Entering Substations**

1842 The sheath/armour at the substation end of the cable should be earthed to the substation
1843 earthing system.

1844 TRIPLEX, three-core, and fully cross-bonded cables will, in addition, be earthed at their
1845 remote ends. This provides both a conductive and inductive path for fault current. With cross-
1846 bonded single-core cables, it is the usual practice to install further additional sheath earths
1847 along the route of the cable. The additional sheath earths will normally produce an
1848 insignificant benefit, and can be ignored in the assessment of the substation earth
1849 resistance.

1850 **6.9.3 Cables Within Substations**

1851 Three-core cables will have their sheath/armour earthed at both ends.

1852 Single-core cables will usually be short enough to allow single-point sheath/armour earthing,
1853 without causing serious sheath voltage rise problems. The single sheath/armour bond to
1854 earth should be located where personnel are most frequently present, for example at
1855 switchgear. Screens should be shrouded at the unearthed end. An earth continuity conductor
1856 may be required. Refer to ENA EREC C55 for further details.

1857 For the higher voltage systems, sheath voltage limiting devices (SVLs) may be installed
1858 between the sheath and earth at the unearthed end of the cable to protect the integrity of the
1859 sheath and its terminating point insulation against transient voltage surges on the sheath.

1860 **6.9.4 Outdoor Cable Sealing-Ends**

1861 Where cables terminate at outdoor sealing-ends, pedestal-type insulators are fitted to
1862 insulate the sealing-end base and gland from its support structure. If sheath earthing is made
1863 at this location special earthing bonds are required in accordance with ENA TS 09-15 or
1864 EREC C55 as appropriate.

1865 When the standing sheath-voltage at a termination can exceed 10 volts to earth, the base
1866 metalwork of the sealing-end shall be screened against accidental contact by means of an
1867 insulating shroud of the type illustrated in EREC C55.

1868 Sealing-end support insulators should be used only for short single-core cable tails with an
1869 earth bond made at the trifurcating point of any three-core cable.

1870 **6.9.5 Use of Disconnected, Non-Insulated Sheath/Armour Cables as an Electrode**

1871 Metallic sheathed/armoured hessian served cables are often decommissioned or replaced
1872 with insulated sheath cables. Where these are laid direct in soil, they can provide a valuable
1873 electrode contribution. Where practicable (particularly if the buried length exceeds 200 m)
1874 these redundant cables should be retained as earth electrodes to maintain their contribution
1875 towards lowering overall substation earth resistance and EPR.

1876 If such sections are retained, the phase conductors and sheaths/armours of these cables,
1877 once disconnected should be joined together to maintain their contribution to the electrode
1878 system. The start ends should ideally be connected to the earth grid via test chambers to
1879 permit continuity or resistance measurements. The remote ends should, if practicable, be
1880 connected to the electrode system at a joint or distribution substation. Cable and earthing
1881 records should be annotated to show such cables are being used as substation earth
1882 electrode.

1883 Constant-force springs (CFS) or plumbed joints may be appropriate for connecting stranded
1884 copper conductor to lead sheathed cables; other types of connection may loosen in service
1885 as the lead continues to flow or 'creep' under contact pressure. In any case moisture should
1886 be excluded from such joints using heat shrink boots or similar. Manufacturer's guidance
1887 should be sought if connecting to sheaths of other cable types.

1888 **6.10 Light-current Equipment Associated with External Cabling**

1889 All exposed conductive parts of light current equipment shall be earthed to the main earthing
1890 system as required. Where pilot or communication cables operate between two remote
1891 points and the rise of earth potential at each end of the circuit does not exceed the
1892 appropriate ITU-T limit, any required circuit earth may be made at either end. If the rise of
1893 earth potential at either end exceeds the appropriate ITU-T limit, then protective measures
1894 shall be applied to those circuits. Refer to ENA EREC S36, and sections 4.3.7 and 6.9.3.

1895 **6.11 Metal Clad and Gas Insulated (GIS) Substations**

1896 **6.11.1 Metal Clad Substations**

1897 Metal clad substations will normally be erected on a concrete raft. The provisions for an earth
1898 electrode system in these circumstances will be similar to those described under item 9.3.1.
1899 Where touch potential is an issue consideration should be given to using an enclosure made
1900 of insulating material and to using surface-laid earth mat/grating.

1901 **6.11.2 Gas Insulated Switchgear (GIS)**

1902 Gas Insulated Switchgear (GIS) employing single-phase busbar enclosures require
1903 additional earthing precautions incorporated into the design of the substation earthing
1904 system.

1905 Due to close coupling with individual phase conductors busbar enclosures can experience
1906 high levels of induction. Steelwork used to support the enclosures and adjoining items of
1907 plant may form closed paths in which induced inter-phase and earth currents flow under both
1908 steady-state and fault conditions. These currents can be undesirably high and may approach
1909 the phase conductor current. The flow of circulating current renders secondary wiring more
1910 vulnerable to inductive interference.

1911 A further issue with GIS is the creation of surge voltages on the enclosures and associated
1912 steelwork during switching or other transient/high frequency system disturbances.

1913 To help minimise the above effects it is recommended that an earth grid, well integrated and
1914 with locally enhanced electrode (e.g. increased mesh density and vertical rods) in the regions
1915 close to the plant, be laid over the raft from which short spur connections can then be taken

1916 to the specific earthing points on the equipment. Typical arrangements are described in
 1917 CIGRE Paper 044/151 - “Earthing of GIS – An Application Guide”, issued by Working Group
 1918 23.10 (December 1993).

1919 To retain current in the busbar enclosures, short circuit bonds, together with a connection to
 1920 the earthing system, should be made between the phase enclosures at all line, cable and
 1921 transformer terminations, at busbar terminations and, for long busbar runs, at approximately
 1922 20 metre intervals. Switchboards > 20 m long will require intermediate connections. Except
 1923 where adjacent enclosures are insulated from each other the interface flanges of the
 1924 enclosures should have bonds across them and the integrity of bolted joints of all bonds
 1925 should be checked.

1926 As a guide the resistance of the bonded flanges should not exceed 5 micro-ohm. At insulated
 1927 flanges consideration should be given to the installation of non-linear resistive devices to
 1928 prevent transient flash-over.

1929 **6.12 Fault Throwing Switches, Earth Switches and Disconnectors**

1930 **6.12.1 Background**

1931 Fault throwing switches, earth switches and disconnectors are normally mounted on steel,
 1932 aluminium, steel reinforced concrete or wood pole structures.

1933 Metallic structures may be of electrically continuous all welded construction or assembled
 1934 using several large pre welded sections or individual bolted members. In some cases though
 1935 the structure is of bolted construction there may be a continuous metallic section from ground
 1936 to equipment level. Where there is more than one metallic section in series in a fault current
 1937 path continuity between sections needs to be considered.

1938 Where steel or aluminium support structures are used to support isolators and / or earth
 1939 switches it is desirable to use the structure itself to carry earth fault current in order to reduce
 1940 the need for above ground earth conductors with consequent risk of theft. This arrangement
 1941 is only acceptable where the metallic structure can provide a reliable earth connection with
 1942 adequate current carrying capacity.

1943 NOTE: Some Network Operators may not use support structures in lieu a dedicated earthing conductor. See also
 1944 6.2.6

1945 When installing earth connections to earth switches and isolators the design will take into
 1946 account the magnitude and duration of the prospective earth fault currents involved. **Fault**
 1947 **throwing switches shall have a dedicated earth connection, see 6.12.2.**

1948 The main earth connection to these devices carries earth fault current under the following
 1949 conditions:

1950 **Table 10 – Conditions for the passage of earth fault current**

Device	Condition For Passage of Earth Fault Current
Fault Throwing Switch	By design when protection operates
Earth Switch	When there is an equipment failure or switching error. May also carry lightning induced current when closed.
Isolator	When the isolator or its connections fault, or when the isolator is used in a sacrificial mode if main protection fails.

1951

1952 The main options for connecting earth switches and isolators are to use either:

- 1953 • a fully rated earth conductor, fixed to the structure. This method is most applicable to
1954 higher fault current applications (e.g. systems operating at 90kV and above) or where the
1955 support structure cannot provide an adequate earth fault current path. See Table 5 and
1956 Table 6 for conductor ratings;
- 1957 • alternatively a metallic structure may be used to conduct earth fault current from the top
1958 of the structure equipment to the grid. This is subject to the structure having sufficient
1959 current carrying capability and being electrically continuous. The method is more
1960 applicable to lower fault current applications (e.g. 33 kV systems) which use welded or
1961 continuous metallic structures.

1962 The following earthing arrangements apply to fault throwing switches, earth switches and
1963 isolators located within secured substation sites fitted with earth grids.

1964 Different arrangements (e.g. insulated down-leads) may be required for equipment located
1965 outside substations in areas accessible to the public.

1966 **6.12.2 Fault Throwing Switches (Phase - Earth)**

1967 A direct earth connection shall be made from the switch earth contact to the main earth grid
1968 using a conductor fixed to the structure.

1969 **6.12.3 Earth Switches**

1970 Connections from earth switches to the main earth grid may be made by either:

- 1971 a) An earth conductor, fixed to the structure or:
1972 b) By using the metallic support structure as a conductor subject to the aluminium or steel
1973 structure having sufficient current carrying capability and being electrically continuous.

1974 **6.12.4 Isolators**

1975 Connections from isolator support metalwork to the main earth grid may be made by either:

- 1976 a) A fully rated earth conductor, fixed to the structure or:
1977 b) By using the metallic support structure as a conductor subject to the aluminium or steel
1978 structure having sufficient current carrying capability and being electrically continuous.

1979 **6.13 Operating Handles, Mechanisms and Control Kiosks**

1980 **6.13.1 Background**

1981 Earthing arrangements for operating handles of isolators, circuit breakers, earth and fault
1982 throwing switches must provide touch and step potential control for the operator.

1983 These are critical locations which require careful consideration and sound construction.

1984 A full earth grid may not always be present at some older sites and additional precautions
1985 may be required when operational work and/or minor alterations are being carried out to
1986 ensure safe touch and step potentials. Generally, with exceptions outlined below, stance
1987 earths shall be provided at all locations where operators may stand to operate high voltage
1988 equipment handles, mechanisms and control equipment.

1989 **6.13.2 Earth Mats (Stance Earths)**

1990 New installations will have touch and step potential control provided by a purpose designed
1991 earth grid. If it can be demonstrated that such measures are adequate to ensure operator
1992 safety, and if a network operator's operational policy allows, an additional stance earth may
1993 not be required. In making this assessment, the likelihood of deterioration due to theft or

1994 corrosion should be considered. Portable or visible (surface laid) stance earths may be
1995 required in addition to any buried grading electrode as a risk reduction measure.

1996 NOTE: Surface-laid earth mats are preferred over buried earth mats; they give much better touch control and their
1997 presence can readily be checked. The size and position of the mat must match the operator stance position(s) for
1998 the given equipment. Galvanised steel grating earth mats can be readily extended to cover the operator path
1999 followed with horizontal operation handles. Buried earth mats may be a suitable alternative to surface-laid earth
2000 mats where the resulting touch voltage is sufficiently low.

2001 **6.13.3 Connection of Handles to the Earth Grid and Stance Earths**

2002 The earth connection from the handle to the grid shall always be separate to that for the
2003 switch metalwork and be as short as possible.

2004 The earth connection shall use standard copper conductor connected direct to the main
2005 substation earth.

2006 In some cases an insulated insert may be fitted between the operating handle and the switch
2007 metalwork to help prevent any fault current flowing down the handle and mechanism into the
2008 earth grid.

2009 Refer also to Section 10.6 (Earthed Operating Mechanisms Accessible From Ground Level).

2010 **6.14 Surge Arrestors and CVTs**

2011 Plant including surge arresters and CVTs (Capacitor Voltage Transformers), which are
2012 connected between line and earth, present relatively low impedance to steep-fronted surges
2013 and permit high-frequency currents to flow through them to earth.

2014 Unless a low impedance earth connection is provided, the effectiveness of the arrester could
2015 be impaired and high transient potentials appear on the earthing connections local to the
2016 equipment. The following installation earthing arrangements are recommended:

2017 Two connections to earth are required for both surge arresters and capacitive voltage
2018 transformers (CVTs):

2019 • The first connection (for power frequency earthing) will use the structure to the main
2020 substation earth grid.

2021 • The second (high frequency) connection should be direct to an earth rod, installed
2022 vertically in the ground as near to the surge arrester base as possible, with a tee
2023 connection to the support structure if metal. High frequency earth rods shall be driven
2024 vertically into the ground to a depth of approximately 4.8m. Where this is not achievable,
2025 a high density earth mesh arrangement or four (or more) long horizontally buried
2026 conductors (nominally 10m in length, minimum depth 600mm) dispersed at 90° (or less,
2027 equally spaced across the full 360°) may be used in place of the rod. Calculations must
2028 be provided to demonstrate that any proposal is equivalent to the 4.8m long earth rods.
2029 The high frequency connection shall be made to the centre of the alternative HF earthing
2030 designs. Dedicated earth mats or similar may be considered in difficult circumstances.

2031 Refer to BS EN 62305 (Lightning Protection Standard) and BS EN 62561-2 (Lightning
2032 Protection System Components – requirements for conductors and earth electrodes), or ENA
2033 ER 134 for more information.

2034 The benefit of surge arresters over arc gaps is greatest when the resistance to earth is less
2035 than 20 Ohms. When a surge arrester is provided at a cable termination, the earth side of the
2036 arrester should be connected to the cable crucifix and thereby to the cable sheath. Surge

2037 arresters should be sited as close as practical to the terminals of the plant, (e.g. transformer
2038 bushings or cable sealing ends) which they are protecting.

2039 The support structure and plinth will be designed to allow the high frequency earth
2040 connection to either pass through its centre, or through an angled slot to ensure that the
2041 connection is as short and straight as possible. This will aid performance and deter theft. It is
2042 particularly important to avoid sharp bends. This connection must not be enclosed within a
2043 steel support tube or box.

2044 Fully rated conductors must be used for both high frequency and power frequency
2045 connections. High frequency downleads should be insulated from the support structure
2046 (except where bonded to the structure at low level) to accommodate surge counters, and
2047 also to facilitate testing of the electrode with a clamp meter (Section 7.6.2(b)).

2048 **7 Measurements**

2049 **7.1 General**

2050 This section describes some of the most common measurements which may be required
2051 during the design, commissioning or maintenance of an earthing system at an electrical
2052 installation. An overview of the important measurement and interpretation methods is
2053 provided together with some guidance on avoiding sources of error. More detailed guidance
2054 and method statements would be expected to be available in company manuals and
2055 operational documentation.

2056 **7.2 Safety**

2057 The earthing related measurements described in this section are potentially hazardous. They
2058 must be carried out by competent staff using safe procedures following a thorough
2059 assessment of the risks. The risk assessment should include, but not be limited to,
2060 consideration of the following aspects and the necessary control measures implemented,
2061 e.g. personal protective equipment, special procedures or other operational controls.

2062 a) Potential differences that may occur during earth fault conditions between the
2063 substation earthing system and test leads connected to remote test probes.
2064 The likelihood of an earth fault occurring should be part of this assessment,
2065 e.g. not allowing testing to proceed during lightning conditions or planned
2066 switching operations.

2067 b) Potential differences that may occur between different earthing systems or
2068 different parts of the same earthing system. In particular, approved safe
2069 methods must be used when disconnecting earth electrodes for testing and
2070 making or breaking any connections to earth conductors which have not been
2071 proven to be effectively connected to earth*.

2072 c) Potential differences occurring as a result of induced voltage across test
2073 leads which are in parallel with a high-voltage overhead line or underground
2074 cable.

2075 d) Environmental hazards of working in a live substation or a construction site as
2076 governed by the electricity company safety rules or the CDM regulations as
2077 applicable.

2078 e) Injury when running out test leads for large distances in surrounding land.

2079

2080 * NOTE: Disconnection from earth can cause voltage differences to arise in the case of the path from tower line-
2081 earthing system due to induction; as it is related to current in the tower line, and therefore present continuously, it
2082 represents a particularly serious hazard.

2083

2084 **7.3 Instrumentation and Equipment**

2085 It is imperative that measurements are taken using the most suitable instrumentation for the
2086 required task which is in good working order and has a valid calibration certificate. The
2087 instrumentation will be used for field measurements in all weather conditions. It must
2088 therefore be robust, have a sufficient level of water resistance and be suitably protected from
2089 electrical transients (e.g. by fuses) and shielded for use in high-voltage installations. Further
2090 advice on this may be sought from a reputable instrument manufacturer.

2091 Instruments shall be calibrated regularly (e.g. annually) to a traceable national standard.
2092 Heavily used instruments should be checked more frequently, e.g. against other calibrated
2093 instruments or standard resistors, between formal calibration periods. Instruments must be

2094 periodically serviced/safety tested and any identified damage or faults must be rectified
2095 before re-use.

2096 Many of the measurements require ancillary equipment such as test leads, earth rods,
2097 connection clamps, etc. and it is equally important that these are also fit-for-purpose and
2098 well-maintained.

2099 **7.4 Soil Resistivity Measurements**

2100 **7.4.1 Objective**

2101 Site specific measurements are required to determine the resistivity of the materials (soil,
2102 rock, etc.) that make up the ground where an earth electrode is installed. The results
2103 obtained can be interpreted to provide a uniform equivalent resistivity for use in standard
2104 design equations (EREC S34) or a multi-layer soil model, which can be used in commercially
2105 available computer simulation tools. Important design parameters such as the earth
2106 resistance and EPR are strongly dependent on the soil resistivity so it is essential for the
2107 accuracy of the design that proper attention is given to these measurements and their
2108 interpretation as early as possible in the design process.

2109 **7.4.2 Wenner Method**

2110 A four-terminal earth tester is used for these measurements. There are a number of available
2111 measurement techniques which involve passing current through an array of small probes
2112 inserted into the surface of the soil and measuring the resulting potentials at specified points.
2113 Using Ohm's law a resistance can be calculated which may be related to the apparent
2114 resistivity at a particular depth using suitable formulae. Varying the positions of the probes,
2115 and hence forcing the current to flow along different paths, allows the apparent resistivity at
2116 different depths to be measured. The most commonly used arrangement for earthing
2117 purposes is the Wenner Array (Dr Frank Wenner, UK Bureau of Standards – now NIST) and
2118 this is described in more detail in BS EN 50522 UK National Annex C.

2119 NOTE: There are variations on the Wenner Array method using uneven electrode spacings that can be used and
2120 these include the Schlumberger Array method and the General Array method.

2121 For large substations it is important to take measurements at a number of different locations
2122 around the site so that an average may be used. In urban areas meaningful measurements
2123 may only be obtained from the nearest parks or open ground and so results from several
2124 locations around the substation are essential.

2125 **7.4.3 Interpretation of Results**

2126 It is difficult to interpret measurement results by inspection other than for a uniform or two-
2127 layer soil model. Formulae for interpretation of data for soils with three or more layers are
2128 cumbersome and practically requires the use of software. There are a number of suitable
2129 software tools available commercially. Because most of these are based on a curve-fitting
2130 approach, geo-technical information such as borehole records are useful to reduce
2131 uncertainty in the soil resistivity model by indicating layer boundary depths, materials, water
2132 table height, bedrock depth, etc. and should be used where available.

2133 Knowledge of the soil resistivity at different depths is important when designing the most
2134 effective electrode to reduce the substation earth resistance. For example, vertical rods are
2135 better suited to a soil with a high resistivity surface layer and low resistivity material beneath.
2136 Conversely, where there is low resistivity material at the surface with underlying rock then
2137 extended horizontal electrodes will be more effective.

2138 **7.4.4 Sources of Error**

2139 There are a number of sources of measurement error which must be considered when
2140 planning and carrying out these measurements. These include, but are not limited to:

- 2141 (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth
2142 electrodes, pipes, etc. Measurements taken above or near buried metallic services
2143 will indicate lower resistivity values than actually exists. This can lead to under-
2144 designed earthing systems which may be costly to rectify at the commissioning stage.
2145 Measurement locations must be carefully planned to avoid interference from metallic
2146 structures by consulting service records and, where there remains uncertainty, the
2147 use of scanning methods on site. It is also important that measurements are taken at
2148 a number of different locations (minimum of two) around the site of interest so that
2149 any influenced results become apparent in comparison to unaffected results. Two
2150 orthogonal sets of measurements can also help to indicate an error;
- 2151 (b) interference from stray voltages in the soil or induction from nearby electrical systems
2152 may adversely affect measurement results, normally evident as an unstable reading
2153 on the instrument or unexpectedly high readings. This may be reduced by avoiding
2154 test leads running in parallel with high voltage power lines/cables or near other
2155 potential sources of interference, e.g. electric traction systems.
- 2156 (c) the wenner spacings used must be appropriate for the size of the earthing system
2157 and recommended spacings are provided in BS EN 50522 National Annex C.
2158 Spacings that are too short may not identify the lower layer resistivities which can
2159 introduce large positive or negative error into design calculations;
- 2160 (d) low resistivity soils, especially at long wenner spacings, require relatively small
2161 resistances to be measured at the surface. Instrumentation with an inadequate lower
2162 range may reach its limit and incorrectly indicate higher resistivity values than exist;
- 2163 (e) care must be taken in interpreting the measurement data. If using computer software
2164 tools, it should be remembered that the result is a 'model' of the soil conditions which
2165 is largely determined by automatic curve-fitting routines or user judgement. To
2166 increase confidence it is good practice to 'test' the model by comparing it to other
2167 geological data available for the site and the expected range of resistivity values for
2168 the materials known to be present. Measured resistances of vertical rods installed at
2169 the site can also be compared to calculated values obtained using the soil model to
2170 increase confidence. It should be recognised that the soil resistivity model may need
2171 to be refined throughout the project as more supporting information becomes
2172 available.

2173 7.4.5 Driven Rod Method

2174 The driven rod method is an alternative to the Wenner Method which is particularly useful in
2175 built-up urban areas where there is inadequate open land to run out test leads. This method
2176 should be used with caution and measures must be taken to avoid the possibility of damage
2177 to buried services, in particular HV cables. Where the absence of buried services cannot be
2178 established, rods must not be driven. An earth rod is driven vertically into the ground and its
2179 earth resistance measured as each section is installed using either of the methods from
2180 Sections 12.5 and 12.6. Using a simple equation (for uniform soil equivalence – refer to ENA
2181 EREC S34) or computer simulation (for multi-layer analysis) the soil resistivity may be
2182 deduced from the measured rod resistance and its length in contact with the soil. This
2183 method can be cost-effective as the rods can be used as part of the earthing installation.
2184 Where possible the results from driven rods at a number of locations around the site should
2185 be used together with any available Wenner Method data to improve confidence in the
2186 derived soil resistivity model.

2187 **7.5 Earth Resistance/Impedance Measurements**

2188 **7.5.1 Objective**

2189 The substation earth resistance or impedance is normally measured where practicable on
2190 commissioning of a new substation and subsequently at maintenance intervals. The
2191 measurement will include all earthing components connected at the time of the test and the
2192 result represents the value which is normally multiplied by the ground return current to
2193 determine the EPR. This method may also be used to measure the earth resistance or
2194 impedance of individual electrodes, tower footings or tower line chain impedances. (Refer to
2195 **ENA EREC S34** for details of chain impedance and relevant calculations).

2196 **7.5.2 Method**

2197 The most commonly used method of measuring substation earth resistance or impedance is
2198 the fall-of-potential method and this is described in BS EN 50522 UK National Annex C. It
2199 requires temporary electrodes to be installed in the ground some distance from the
2200 substation and connected back via trailing leads. A standard four-pole earth tester should be
2201 used (as opposed to a three-pole tester – refer to 7.5.4(e) to inject a small test current into
2202 the earth electrode and returned via a remote probe. A voltage gradient is set up around the
2203 electrode and a second probe is used to measure this with respect to the electrode voltage
2204 rise. The resistance is calculated and results are normally presented as a curve of resistance
2205 versus distance from the substation along a particular route. Voltage measurements may be
2206 taken along any route but traverses which are parallel or orthogonal to the current lead are
2207 most commonly used and are more readily interpreted using standard methods.

2208 Most commercially available earth testers use a switched DC square wave signal. Where it is
2209 possible to select a very low switching frequency (below 5 Hz) the measured values will
2210 approach the DC resistance which will be accurate for small earth electrode systems in
2211 medium to high soil resistivity. When higher switching frequencies are used (128 Hz is
2212 common) inductive effects may be evident in the results. Where an appreciable inductive
2213 component is expected and long parallel test leads are used it is advisable to use an AC
2214 waveform, so that mutual coupling between the test lead may be subtracted and a true AC
2215 impedance obtained. Because of the appreciable standing voltage commonly found on live
2216 substation earth electrodes, AC test signals are normally selected to avoid the fundamental
2217 and harmonic frequencies. For the most accurate results, measurements should be taken
2218 using frequencies either side of the power frequency to allow interpolation. Additional
2219 guidance may be found in IEEE 81 **(add ref)**.

2220 It may not be possible to use the fall-of-potential method where no suitable routes exist for
2221 the test lead / probe set up, e.g. in urban or industrial areas. Alternative methods must be
2222 used in these locations as described in Section 7.6.

2223 The substation earth resistance or impedance can also be measured by injecting a current
2224 from a generator connected to a remote substation earthing system via a de-energised
2225 power line. The rise in electrode potential is then measured with respect to another remote
2226 earth electrode such as a telecommunication circuit earth. This method is more costly in
2227 terms of equipment resources and circuit outages; it is rarely used in the UK. Experience has
2228 shown that care must be taken to ensure that there are no unwanted metallic paths between
2229 the substation electrode and either of the reference electrodes as this will divert current and
2230 introduce errors, unless the diverted current can be measured and a correction applied. This
2231 is especially difficult to achieve in urban environments, otherwise this technique would be a
2232 good option where no suitable area for a fall-of-potential measurement exist.

2233 **7.5.3 Interpretation of Results**

2234 Earth resistance or impedance measurement results are normally in the form of a series of
2235 points on a curve which must be interpreted using a mathematical rule or procedure. Care

2236 must be taken in selecting a suitable method and their limitations must be understood. More
2237 detail on the methods available is given in BS EN 50522 UK National Annex C.

2238 **7.5.4 Sources of Error**

2239 There are a number of sources of measurement error which must be considered when
2240 planning and carrying out these measurements. These include, but are not limited to:

2241 (a) influence of buried metallic structures such as bare cable armouring/sheaths, earth
2242 electrodes, pipes, etc. Measurements taken above or near buried metallic services
2243 will generally underestimate the substation resistance. Measurement locations must
2244 be carefully planned to avoid interference from metallic structures by consulting
2245 service records and, where there remains uncertainty, the use of scanning methods
2246 on site. Measurement results that have been influenced by a parallel buried metallic
2247 structure will typically be lower than expected and the resistance curve will be flat. A
2248 metallic structure crossing the measurement traverse at right-angles will result in a
2249 depression in the resistance curve. If interference is suspected the measurement
2250 should be repeated along a different route or an alternative method used;

2251 (b) the distance between the substation and the remote current probe is important to the
2252 accuracy of the measurement. The theoretical recommended distance is between five
2253 and ten times the maximum dimension of the earth electrode with the larger
2254 separations required where there is underlying rock. In practice, where there is
2255 insufficient land to achieve this, the current probe should be located as far away from
2256 the substation as possible. Measurements taken using relatively short distances
2257 between the substation and return electrode may not be accurately interpreted using
2258 standard methods and require analysis using more advanced methods. Typical
2259 distances used range from 400 m for standard 33/11 kV Primary Substations up to
2260 1000 m or greater for large transmission substations or for large combined systems;

2261 (c) interference caused by standing voltage ('noise') on a substation earthing system
2262 may result in standard earth testers failing to produce satisfactory results. This is
2263 normally evident as fluctuating readings, reduced resolution or via a warning/error
2264 message. Typical environments where this may be experienced include transmission
2265 substations (275 kV and 400 kV), railway supply substations or substations supplying
2266 large industrial processes such as arc furnaces or smelters;

2267 (d) results must be interpreted using an appropriate method and compared to
2268 calculations. Where there is significant difference further investigation is required.
2269 Interpretation using the 61.8% Rule or Slope Method may not be appropriate in all
2270 circumstances as they are based on simple assumptions; Detailed analysis using
2271 computer software may give greater accuracy where:

- 2272 • the soil resistivity is non-uniform, i.e. multi layered soils;
- 2273 • where the current return electrode is relatively near to the electrode under test,
2274 e.g. less than five times the size of the earth electrode being tested;
- 2275 • for a large and irregular shaped electrode where the test is taken far away from
2276 the centre of the electrode
- 2277 • where there are known nearby buried metallic objects that may have influenced
2278 the measurements.

2279 (e) use of a three-pole earth tester is acceptable where the resistance of the single lead
2280 connecting the instrument to the electrode is insignificant compared to the electrode
2281 resistance. These instruments are generally suitable only for measuring small
2282 electrode components such as rods or a small group of rods in medium to high

2283 resistivity soils. For larger substations or low resistance electrodes a four-pole
 2284 instrument is essential to eliminate the connecting lead resistances which would
 2285 otherwise introduce a significant error.

2286 **7.6 Comparative Method of Measuring Earth Resistance**

2287 **7.6.1 Objective**

2288 To measure the earth resistance of small individual electrode components within a large
 2289 interconnected earthing system. This method is most effective where a relatively high
 2290 resistance electrode is measured in comparison to a 'reference earthing system' which has a
 2291 much lower resistance.


2292 **7.6.2 Method**

2293 Two different approaches may be used as follows:

2294 (a) The first method, illustrated in Figure 12.1, requires that the electrode being tested is
 2295 disconnected from the remainder of the substation earthing system, e.g. immediately
 2296 after installation prior to the connection being made or via opening of a test link at
 2297 existing sites. A standard four-pole earth tester may be used with terminals C1 and P1
 2298 connected to the electrode component being tested. Terminals C2 and P2 are connected
 2299 to the 'reference earth'. Current is circulated around the earth loop containing the
 2300 electrode and the reference earth resistances and the voltage developed across them is
 2301 measured. Using Ohm's Law the series 'loop resistance' is calculated and if the reference
 2302 earth resistance is sufficiently low relative to the electrode resistance the measured value
 2303 will approach the electrode resistance.

2304 (b) The second method, illustrated in Figure 12.2 uses a similar principle but does not require
 2305 disconnection of the electrode. A clamp type meter is placed around the connection to
 2306 the electrode which generates and measures current and voltage in the electrode loop
 2307 and displays the 'loop resistance'. The advantage of this method is that the earth
 2308 electrodes may be tested without disconnection hence avoiding the associated safety
 2309 risks and the need to apply earth disconnection procedures. This is the preferred method
 2310 for safety and facilities should be included in the design to allow access to rods for testing
 2311 with a clamp meter.

2312



2313

2314 **Figure 12.1 — Illustration of Earth Resistance Measurement using the Comparative Method and**
 2315 **a Four-Pole Earth Tester (Test Electrode Disconnected).**

2316

2317
 2318
 2319
 2320
 2321
 2322
 2323
 2324
 2325
 2326
 2327
 2328
 2329
 2330
 2331
 2332
 2333
 2334
 2335
 2336
 2337
 2338
 2339
 2340
 2341
 2342
 2343
 2344
 2345
 2346
 2347
 2348
 2349
 2350
 2351
 2352
 2353
 2354
 2355
 2356
 2357




Figure 12.2 Illustration of Earth Resistance Measurement using the Comparative Method and a Clamp Type Resistance Meter (Test Electrode Connected)

7.6.3 Interpretation of Results

In order to accurately measure an electrode resistance via this method it is necessary to have a very low reference earthing system resistance compared to the electrode resistance (10% or lower is recommended). It is also necessary to have a reasonable physical separation between the electrode and reference earth to reduce mutual coupling through the soil.

If the reference earth resistance is too high the measured result will be significantly higher than the Electrode resistance (if it is known it can be subtracted). If the electrode and reference earths are too close together then a value lower than the electrode resistance may be measured. These errors may be acceptable if the purpose of the measurement is a maintenance check where it is only necessary to compare periodic readings with historical results to identify unexpected increases, e.g. due to corrosion or theft.

If several different electrodes can be tested with respect to the same reference earth more detailed interpretation methods may be developed to increase confidence in the individual electrode resistances and in some circumstances allow the reference earth resistance to be deduced.

7.6.4 Sources of Error

- (a) If the reference earth resistance is too high relative to the electrode resistance the measured value may be significantly higher than the electrode resistance. An approximate assessment of this may be made by comparing the physical area covered by the respective earthing systems, e.g. a rod electrode measured with respect to a large substation earth grid would be expected to provide a reasonable accurate resistance for the rod electrode.
- (b) Where the test electrode and reference earth are in close proximity to each other there will be significant mutual coupling via the soil which may result in an apparently lower reading than the true electrode resistance.
- (c) The electrode under test may be inadvertently in contact with the reference electrode below ground level, or otherwise connected to it. The test current is then circulated around a loop and does not represent the intended earth electrode resistance.
- (d) This method cannot be directly used to measure the overall substation earth resistance which requires the use of the fall-of-potential method described in Section 12.6.


2358 **7.7 Earth Connection Resistance Measurements (Equipment Bonding Tests)**

2359 **7.7.1 Objective**

2360 To measure the resistance between a plant item and the main substation earth electrode to
2361 check bonding adequacy. This is essential during commissioning of a new substation to
2362 confirm that each item of plant is effectively connected to the earth electrode system. It is
2363 also useful as an on-going maintenance check and for operational procedures, e.g. post-theft
2364 surveys.

2365 **7.7.2 Method**

2366 The procedure is based upon the principle of measuring the resistance between a set point
2367 (or points) on the main electrode system and individual items of earthed equipment. A micro-
2368 ohmmeter is used and the connection arrangement is illustrated in Figure 12.3.
2369 Measurements can be taken from one central point (such as the switchgear earth bar) or, to
2370 avoid the use of unduly long leads, once a point is confirmed as being adequately connected,
2371 it can be used as a reference point for the next test and so on.



2372

2373 **Figure 12.3 Connections for Earth Bonding Conductor Resistance Measurements**

2374 To establish that a satisfactory connection exists between the grid and any exposed
2375 metalwork it is necessary to measure in the micro-ohms or milli-ohms range. An injection
2376 current of at least 100 mA is recommended.

2377 The probable path of the injected current must be considered and where the substation uses
2378 a bus-zone protection scheme care must be taken to ensure that any test current does not
2379 produce enough current to operate protection systems.

2380 Special procedures must be adopted when checking bonding between a substation earthing
2381 electrode and a terminal transmission tower. If the bond is ineffective or missing a potential
2382 difference may exist which may pose a shock hazard or damage to a test instrument.
2383 Normally these methods will include checking current flow in the terminal tower legs prior to
2384 testing as a higher proportion of current will flow in a leg with an effective connection to the
2385 substation. This would be supplemented by voltage measurements using suitably insulated
2386 probes and meters and buried electrode location techniques.

2387 **7.7.3 Interpretation of Results**

2388 The measured resistance between the two connection points will depend on the length,
2389 cross-sectional area, material and number of earth conductors between them. Based on a
2390 maximum distance of 50 m between connection points, a threshold value of 20 mΩ will
2391 provide a good indication of when further investigation is required.

2392 7.8 Earth Conductor Joint Resistance Measurements


2393 7.8.1 Objective

2394 To measure the resistance across an earth conductor joint to check its electrical integrity.
2395 This is normally performed for every joint created at a new substation prior to backfilling. It is
2396 also carried out during periodic maintenance assessments.

2397 7.8.2 Method

2398 The method described uses a micro-ohmmeter to measure electrical resistance and is
2399 suitable for bolted, compression, brazed and welded joints. It does not check the mechanical
2400 integrity of welds or for voids inside a joint.

2401 Most micro-ohmmeters are supplied with standard leads with two sharp pins that can
2402 penetrate through paint or surface corrosion to reach the metal underneath. The first set of
2403 leads is connected to one side of the joint and the second set to the other as illustrated in
2404 Figure 12.4. Ideally, the connectors should be no more than 25 mm either side of the joint. A
2405 suitable scale must be selected on the instrument (normally a minimum current of 10 A is
2406 required to measure in the micro-Ohm range) and an average value recorded after the test
2407 polarity has been reversed.



2408

2409 **Figure 12.4 Connections for Earth Conductor Joint Resistance Measurements**

2410 Joints must also be mechanically robust and survive a firm tap with a steel hammer.

2411 7.8.3 Interpretation of Results

2412 The measured resistance should not significantly exceed that of an equivalent length of
2413 conductor without a joint. Joints which exceed this by more than 50% must be remade.
2414 Where different sized tapes are involved, the threshold value used should be that of the
2415 smaller tape.

2416 At new installations it is recommended that a few sample joints are made under controlled
2417 conditions (e.g. in a workshop), their resistance measured and the median of these values
2418 used as the benchmark for all other similar joints made at the installation.

2419 7.9 Earth Potential Measurements

2420 7.9.1 Objective

2421 To measure Touch, Step and Transfer Voltages (e.g. 'Hot Zones') for comparison with
2422 calculated values. These measurements may be required to confirm that the installed design
2423 complies with the main safety limits (see Section 4.4). Advanced techniques and equipment
2424 are required to perform these measurements at live substations and guidance on the
2425 different methods available can be found in IEEE 81 (add ref).

2426 **7.9.2 Method**

2427 Earth potential measurements may be measured by injecting a current into the substation
2428 electrode and returning through a remote electrode via a connecting conductor. The return
2429 electrode may be another substation electrode connected via a de-energised power line or a
2430 temporary test lead and set of probes. Providing the return electrode is located at a large
2431 distance from the substation (relative to the size of the substation electrode) a potential
2432 profile will be set up around the substation proportional to that which would exist during fault
2433 conditions. The voltage between the substation electrode and different points on the surface
2434 can then be measured and related to Touch Voltage. Step Voltage can also be determined
2435 from measurements of the potential difference between points on the surface which are 1 m
2436 apart. In both cases the actual touch voltage can be found by scaling in the ratio of the test
2437 current and fault current.

2438 In a similar way, the potential gradients may be measured around the substation, for
2439 example emanating out from each corner, and equipotential contours derived to provide Hot
2440 Zone information. Measurements may also be carried out to determine the voltage
2441 transferred from a substation electrode to a nearby metallic structure, e.g. a steel pipe or the
2442 earthing system associated with a different electrical system.

2443 **7.9.3 Interpretation of Results**

2444 The measurement results must be interpreted by competent engineers and compared to
2445 calculated values. It is recommended that a series of measurements are taken at a number
2446 of locations around the substation where high touch or step voltages are expected (normally
2447 at the corners or in areas where the electrode mesh is less dense). This will enable the
2448 trends in the voltage gradients to be assessed to identify spurious data points. Where the
2449 return electrode is not located sufficiently far away from the test electrode large errors may
2450 be introduced. These errors may be corrected using a detailed computer model or by
2451 averaging the measurements obtained using different current return electrode locations.

2452 **7.10 Earth Electrode Separation Test**

2453 **7.10.1 Objective**

2454 To assess the electrical separation of two electrodes in the soil by measurement, e.g.
2455 segregated HV and LV electrodes at an 11 kV distribution substation or a substation earth
2456 electrode and a separately earthed fence.

2457 **7.10.2 Method**

2458 This method requires that the earth resistances of the two electrodes (R_1 and R_2) have been
2459 measured separately using the fall-of-potential method described in Section 12.5.

2460 Similar connections are then made as the bonding integrity checks (figure 12.3) and the
2461 'earth loop' resistance (R_3) of the two electrodes via the ground is measured.

2462 **7.10.3 Interpretation of Results**

2463 If the two electrodes are separated by a large distance then the R_3 will approach the series
2464 resistance of $R_1 + R_2$. Lower measured values of R_3 indicate a degree of conductive coupling
2465 through the soil. Generally, for the purposes of checking satisfactory segregation of earth
2466 electrodes the following test is used: $R_3 > 0.9(R_1 + R_2)$. Values lower than $0.9(R_1 + R_2)$ may
2467 indicate inadequate separation and further investigation is required (refer to Section 9.7.3).

2468 **7.11 Buried Earth Electrode Location**

2469 **7.11.1 Objective**

2470 At older substation sites, whilst an earthing system is in place, a record of its design may not
2471 exist or may be out of date. An earthing record is desirable to ensure that the design is
2472 satisfactory and to assist in the planning of new construction work. The record should include
2473 the position of the electrode, its burial depth, material, size and installation method (e.g.
2474 above ground, in ducts, or buried directly).

2475 Where existing electrode needs to be located within live substations, surface detection
2476 methods are usually the lowest cost option.

2477 **7.11.2 Method**

2478 The most effective surface detection techniques, found by experience are documented
2479 below. This includes commercially available low to medium frequency systems and Ground
2480 Penetrating Radar (high frequency) systems. It should be noted that these methods are
2481 subject to interference from other buried services and often need to be supplemented by trial
2482 excavations.

2483 A low to medium frequency system comprises a transmitter and receiver, working at
2484 frequencies from 50 Hz (detection of live mains cables) to nearly 100 kHz. The transmitter
2485 injects a signal into the earthing system which is to be traced (the “target line”). As this signal
2486 passes through the earth electrodes, it radiates an electric and magnetic field, one or both of
2487 which can be detected and interpreted by coils in the receiver. Basic receivers simply emit an
2488 audio tone as they are passed over the target line. More advanced receivers give
2489 information, such as burial depth and test current magnitude. This feature can sometimes
2490 enable one to distinguish between the target line and others which have erroneously picked
2491 up the transmitter’s signal through coupling.

2492 A ground penetrating radar system, used in conjunction with appropriate analysis software,
2493 can also be used to produce a reasonable graphical image of structures below the surface.
2494 Radar systems detect the dielectric contrast between a target and its surroundings and so
2495 are well suited for detecting conductive, metallic electrodes against soil which is relatively
2496 resistive. They are well suited to drained, high soil resistivity locations. The radar system is
2497 usually guided over the trace area in a grid pattern, with detection results being stored for
2498 later analysis by the computer.

2499 Where neither of the above methods are conclusive, e.g. in areas with a high density of
2500 buried services, selected trial holes may be required.

2501

2502 **8 MAINTENANCE**

2503 **8.1 Introduction**

2504 Earthing systems shall be inspected, maintained and repaired so as to ensure they will
2505 operate in the manner required on an ongoing basis.

2506 **8.1.1 Inspection**

2507 This falls into two main categories:

2508 (a) Visual Inspection

2509 (b) Detailed Physical Examination and Testing

2510 When setting inspection, testing and maintenance regimes for a substation consideration
2511 shall be given to identifying and where necessary rectifying issues arising from:

- 2512 • physical deterioration and damage/theft;
- 2513 • inappropriate installation alterations or third party actions which prejudice the principal of
2514 operation of the earthing system;
- 2515 • inappropriate installation / design;
- 2516 • changes to system operating regimes or construction which alter the magnitude, flow and
2517 / or duration of earth fault current to values outside the original earthing system design
2518 parameters;
- 2519 • magnitude of EPR and how close touch and step potentials are to safety limits.

2520 The frequency of inspection and testing should be set according to EPR, risk of theft,
2521 damage, and deterioration. It may be revised from time to time if circumstances change.

2522 If an extraordinary event occurs (e.g. delayed fault clearance) then additional ad hoc
2523 inspection and testing may be required

2524 **8.1.2 Maintenance and Repairs**

2525 When undertaking repairs or minor alterations to damaged earth conductor and buried
2526 electrode the procedures adopted must take into account:

- 2527 • Broken conductors may operate at elevated voltages even when the rest of the
2528 associated network is operating normally.
- 2529 • The possibility of transient or sustained system earths fault occurring while repairs are
2530 being undertaken.

2531 Inspection, testing and maintenance work must be undertaken in accordance with company
2532 operational and safety procedures. Where required risk assessments and method
2533 statements will be prepared. Inspectors must wear company specified personal protective
2534 equipment and only approach plant and equipment when it is safe to do so. See Sections 8.3
2535 and 8.4 for further issues.

2536

2537 **8.2 Types of Inspection**

2538 **8.2.1 Introduction**

2539 The main types of inspection may be summarised as:

- 2540 • a frequent basic visual inspection to check there is no visible damage, theft or obvious
2541 impairment of the earthing system;
- 2542 • a less frequent and more detailed visual inspection to review the standard of construction
2543 and condition as well as checking for damage, theft and impairment;
- 2544 • an infrequent more thorough visual inspection combined with testing, measurement and
2545 analysis.

2546 For an open busbar substation typical areas to be inspected include earth connections
2547 associated with:

- 2548 (i) aluminium, steel, concrete and wood structures;
- 2549 (ii) towers, earthed poles and above ground cable connections within or adjacent to
2550 the substation site.
- 2551 (iii) isolator mechanisms, fault-throwing switches, earth switches and control kiosks
2552 including associated surface and buried earth mats;
- 2553 (iv) transformers, reactors, VTs, CVTs, CTs, surge-arresters and arcing horns;
- 2554 (v) transformer neutral links and switches and associated connections to earth either
2555 direct or via earthing resistors, reactors or earthing transformers;
- 2556 (vi) metallic Fencing and gates;
- 2557 (vii) indoor switchgear (if present) including connections to plant, cables, structural
2558 steel work and earth bars.

2559 **8.2.2 Frequent Visual Inspection**

2560 This can form part of a normal routine substation inspection procedure or be a part of the
2561 procedures operation staff conduct when entering a substation. The objective is to frequently
2562 and quickly check for visible damage, theft or obvious impairment of the earthing system.

2563 During routine visual inspections accessible earth connections associated with key items of
2564 electrical plant in the substation should be checked. Procedures such as lifting trench covers
2565 will normally be avoided unless the initial inspection gives cause for concern.

2566 **8.2.3 Infrequent Detailed Visual Inspection**

2567 Before commencing a detailed examination, the substation earthing records should be
2568 checked to confirm they correspond to the actual layout. The inspector should be aware of
2569 the fence earthing arrangement and whether it is independently earthed or bonded to the
2570 earth grid or a mixture of both.

2571 The key items covered in the Frequent Inspection plus all other accessible connections to
2572 plant, circuits and civil infrastructure should be inspected thoroughly. As well as condition,
2573 the standard of construction should be reviewed against present practices and any
2574 inadequacies reported. Checks for damage, theft and impairment of the earthing system
2575 should also be carried out. Visual checks should be carried out on less accessible earthing
2576 conductors not covered in the Frequent Inspection such as those located under trench
2577 covers or located in basements.

2578 The results of all inspections must be documented in accordance with company procedures.

2579 A pre-prepared check list for each site will assist consistent reporting and record keeping.

2580 **8.2.4 Detailed Visual Inspection, Testing and Analysis**

2581 This consists of four related parts:

2582 • A thorough detailed visual inspection and review of the earth connections to all electrical
2583 plant, circuits and civil infrastructure as per 8.2.3

2584 • Carrying out specific testing and measurement of the earthing installation as per 8.2.4.1

2585 • Selecting portions of the buried electrode system for examination via trial holes as per
2586 8.2.4.2

2587 • Analysis and recording of results including review of EPR related issues as per 8.2.4.3

2588

2589 8.2.4.1 Testing

2590 See Section 7 for specific measurement and analysis techniques.

2591 Testing may include:

2592 (i) Measurement of the overall substation earth resistance/impedance value;

2593 (ii) Measuring resistance of:

2594 • Individual earth electrodes

2595 • Rod and plate groups

2596 • Fence earth rods

2597 • Test electrodes (where fitted).

2598 • Surge arrester, CVT and GIS high frequency earths;

2599 (iii) Measurement of soil resistivity;

2600 (iv) Resistance tests across a representative sample of important joints using a micro-
2601 ohmmeter. The value should be recorded and compared with the values
2602 recommended by the manufacturer, or taken for similar joints elsewhere. Any joint
2603 where the resistance value is excessive will require to be broken down, cleaned
2604 and remade, or replaced;

2605 (v) Confirmation of continuity between key items such as transformers, switchgear,
2606 terminal tower(s) etc. and the main substation earth grid using a micro-ohmmeter.
2607 This is especially important for items where corrosion, theft or damage is
2608 considered to have prejudiced the integrity of the connection;

2609 (vi) Confirmation of continuity between adjacent site earthing systems;

2610 (vii) Confirmation of whether metallic fences are isolated from or bonded to the main
2611 substation earth grid by carrying out a separation test;

2612 (viii) For substations fitted with frame leakage earth fault protection checking the
2613 integrity of the segregation between earth zones by testing and/or visual
2614 inspection and also testing across cable terminations where island glands are
2615 fitted;

2616 (ix) Measurement of Soil pH value;

- 2617 (x) Tracing of buried electrode if required to update the substation earthing drawing;
2618 (xi) Segregation tests and review of segregation between distribution substation HV
2619 and LV earths. (Refer to Sections 7.10 and 9.7);

2620 8.2.4.2 Selected Excavation and Examination of Buried Earth Electrode

2621 Since the earth electrode system is largely buried, it is impracticable to carry out a detailed
2622 examination of the whole installation. However, it cannot be assumed that the buried
2623 electrode system, once installed will remain in good condition.

2624 Particularly where a substation site is associated with former industrial use such as a coal
2625 power station or foundry which may have produced corrosive material used as landfill there
2626 is enhanced risk of corrosion of buried copper conductor. A similar risk may also arise if
2627 material from such sites is imported to construct a substation. It is recommended that
2628 representative locations be chosen to excavate and expose the buried electrode, in order to
2629 check its condition.

2630 These should include some below ground connections, e.g. an earth rod connection position,
2631 or other locations where the electrode is jointed. Several connections from above ground
2632 plant should be uncovered back to the connection to the buried earth tape/grid, to check their
2633 condition through the layers of chippings and soil. Conductor size should be compared with
2634 records.

2635 Whilst carrying out excavation, the soil pH value should be checked. This should lie between
2636 6.0 and 10.0. For pH values outside these limits, it is probable that corrosion of the copper
2637 conductors/connectors will be evident. In the past, power station ash has been used as
2638 bedding for earth electrodes. This is known to be acidic, and is likely to cause corrosion of
2639 the conductors.

2640 Where tests show the pH value of the soil to be outside the limits, if the copper electrode is
2641 corroded, then repairs or a new electrode system and either some imported soil or an inert
2642 backfill (such as bentonite) is required. If the electrode has limited corrosion, then a soil /
2643 corrosion investigation is necessary to assess the risk of future corrosion and any
2644 precautions necessary. Normally the corrosion rate will be uneven, with severe corrosion in
2645 some areas and none in others. Severely corroded electrodes will need to be replaced, whilst
2646 that elsewhere will need to be monitored and measures taken to limit corrosion in all
2647 important areas.

2648 Should examination of the exposed conductors or connections give cause for concern, then
2649 additional excavations elsewhere on site may be necessary to assess the extent of the
2650 problem.

2651 8.2.4.3 Analysis and Recording of Test Results

2652 Resistance values for the substation, individual electrode groups and for joints should be
2653 recorded and where previous values are available compared to indicate any trend.

2654 The earthing drawing should be updated if required with revised electrode sizes and
2655 positions.

2656 Once a new substation earth resistance is obtained it should be used to recalculate the
2657 substation EPR using up to date earth fault current data and earth fault current return paths
2658 (earth wires/cable sheaths etc). Safety voltages and conductor current ratings should be
2659 recalculated and any deficiencies identified.

2660 The presence (or otherwise), values and configuration of any resistances / impedances
2661 placed in high voltage transformer neutrals should be recorded and aligned with those
2662 contained in the company power system model.

2663 Defects should be listed and prioritised for remedial action.

2664 **8.3 Maintenance and Repair of Earthing Systems**

2665 In some cases, earthing related maintenance and repair work will be reactive, following theft
2666 or damage revealed by an inspection.

2667 Before undertaking earthing system repair or measurement work, the responsible person in
2668 charge of the work must familiarise themselves with the site specific risks and consequences
2669 of:

- 2670 • Working on or touching unsound earthing systems;
- 2671 • Open circuiting (even for a short time) earth conductor circuits;
- 2672 • Extending (even temporally) earthing systems from sites where touch and step potentials
2673 are controlled;
- 2674 • Working on broken earthing conductors;
- 2675 • An earth fault occurring on the system being worked on. For primary substations
2676 supplying extended high voltage rural overhead line networks this can be a relatively
2677 frequent occurrence (e.g. at least once a week). Supervisors should avoid work or testing
2678 being carried out in high risk periods such as during storms or fault switching.

2679 There is risk of serious or fatal electric shock when working on intact and depleted/damaged
2680 earthing systems. The responsible person in charge of any remedial work should be suitably
2681 qualified to undertake this area of work. Network Operators should develop their own
2682 policies/procedures for dealing with depleted earthing systems.

2683 Specialised equipment including insulated rods, shorting leads and conductor clamps are
2684 required to make repairs. PPE including insulated footwear and gloves must be available if
2685 required.

2686 High voltages can appear on earth system conductors even under normal running conditions.
2687 Items requiring particular caution include connections associated with CVTs, transformer
2688 neutrals, underground cable bonding arrangements and connections between main earth
2689 grids and overhead line towers.

2690 Examples of situations requiring remedial work include:

- 2691 • broken or damaged below ground earthing conductors which have been exposed in the
2692 course of excavation work;
- 2693 • broken or damaged bonding conductors on underground cable systems (such as cross-
2694 bonding connections that can be expected to carry significant current under normal
2695 operating conditions);
- 2696 • repairs to/replacement of high resistance earth connections (Para 8.4);
- 2697 • minor alterations to/diversions of earthing systems for construction work;
- 2698 • repairs after theft of earthing conductors (Remedial work on depleted earthing systems is
2699 normally the subject of a bespoke company instruction and is outside the scope of this
2700 document).

2701

2702 **8.4 Procedure for the Remaking Defective Joints or Repairing Conductor Breaks**

2703 **8.4.1 Introduction**

2704 It may be necessary to remake a joint or repair a break on the earth electrode system at a
2705 substation for a number of reasons:

2706 (a) The joint is obviously damaged.

2707 (b) The joint has failed a micro-ohmmeter test.

2708 (c) An earth electrode has been severed.

2709 (d) A minor diversion of the electrode system or other repair work may be proposed.

2710 Should a fault occur during the period when a repair is being carried out, to prevent danger
2711 from a high voltage, which could appear across the joint, precautions must be taken.

2712 The design of the earth grid (if present) may or may not be adequate to eliminate danger to
2713 personnel when touching a bare broken conductor even after a temporary earth continuity
2714 conductor has been applied.

2715 Before carrying out any repairs, the joint or break to be repaired must be short-circuited by
2716 connecting a fully-rated conductor to positions either side of the break or defective joint. This
2717 short must be applied using an approved procedure involving insulated rods.

2718 If company policy so states or any doubt exists the operator shall wear insulating footwear
2719 and gloves designed for electrical application when handling earth conductor to make a
2720 permanent repair.

2721 Whilst carrying out work, the operator should stand within the boundaries of the earth grid, or
2722 immediately above a bare buried earth conductor.

2723 For example, if a terminal tower earth connection is broken, a significant potential difference
2724 may be present between the tower and earth grid. Arcing and current flow will occur when
2725 trying to remake the connection. Insulated rods and approved connectors are required to
2726 apply the initial short-circuit. The repairs, as detailed in the next paragraph, can then be
2727 carried out.

2728 Similarly high voltages may appear across open circuited cross bonding conductors on high
2729 voltage underground cable circuits.

2730 **8.4.2 Joint Repair Methods**

2731 (i) Compression Joint – Cannot be repaired, must be replaced.

2732 (ii) Mechanical Connector - Disconnect, clean all contact surfaces, apply a company
2733 approved contact lubricant, reconnect and re-tighten.

2734 (iii) Cold-weld/Exothermic weld Joint - If defective this type of joint must be replaced.

2735 On completion of repair of any joint, having first connected the instrument across the joint,
2736 the temporary earth continuity conductor* should be removed; a micro-ohmmeter resistance
2737 test must then be carried out across the joint.

2738 * Shorting strap

2739 **8.4.3 Flexible Braids**

2740 Flexible bonding braids or laminations should be inspected for signs of fracture and corrosion
2741 and changed as required. A protective compound may be applied to flexible braids where
2742 corrosive conditions exist.

2743 **9 Ground Mounted Distribution Substation Earthing**

2744 **9.1 Introduction**

2745 Whilst the general principles of earthing can be applied to all voltage levels, small
2746 (distribution) substations providing supply to LV networks can present their own additional
2747 challenges. The key earthing related differences between distribution (or 'secondary')
2748 substations, and larger ('primary', or 'grid' substations) include:

- 2749 • high voltage distribution apparatus is often located in densely populated areas in close
2750 proximity to the public;
- 2751 • earth fault clearance times on distribution systems are usually longer;
- 2752 • many older 'legacy' installations do not have the benefit of a comprehensive earth grid
2753 environment, as they rely on metallic sheath cable systems to control touch and step
2754 potentials;
- 2755 • low-voltage earth connections may be combined with HV earthing systems, or in close
2756 proximity to them;
- 2757 • connections from the low voltage distribution system are taken into almost every property;
- 2758 • for new connections distribution network operators have a legal obligation to provide a
2759 low voltage earth terminal to their customers as long as it is safe to do so;
- 2760 • the low voltage system must be earthed such that earth potential rise due to high voltage
2761 earth faults does not cause shock or injury (to installation users, public or staff) or
2762 damage to internal electrical installations, distribution equipment or telecommunication
2763 systems.

2764 The design issues, therefore, can be summarised as: a) achieving safety in and around the
2765 HV:LV substation, and b) ensuring that danger does not arise on the LV system as a
2766 consequence of HV faults.

2767 The design approach outlined in Section 5.1 applies equally to distribution substations, and
2768 special considerations are described below.

2769 **9.2 Relocation of Pole Mounted Equipment to Ground Level**

2770 Due to the high EPR that can appear on pole mounted equipment, metallic items must not be
2771 re-located at ground level (e.g. replacing a pole transformer with a small padmount
2772 substation) without appropriate modifications to the earthing system.

2773 Ground mounted substations will introduce a touch potential risk that is absent from pole
2774 mounted installations, and consequently require an electrode system that not only limits
2775 EPR, but controls touch and step voltages to safe limits.

2776 Similarly, care should be exercised if other earthed equipment on the pole (e.g. auto-reclose
2777 relay cabinet) is within reach of those on the ground.

2778 Section 10 describes pole mounted installations in detail. In either case, the decision to
2779 operate with combined HV and LV, or otherwise, must consider the voltage that will be
2780 impressed on the LV system under HV fault conditions (Section 9.5).

2781 **9.3 General design requirements**

2782 In common with any earthing system, the design of any new build substation must satisfy
2783 requirements for EPR, touch/step voltages, transfer voltages, and stress voltages. If major

2784 changes are to be made to an existing substation, the effects of these proposed changes on
2785 the existing earthing system need to be considered. A significant consideration in all cases
2786 is the transfer potential that will be impressed on the LV network under HV fault conditions.
2787 See 9.5

2788 **9.3.1 Design Data Requirements**

2789 The data required is similar to that described in Section 5.5, as necessary to determine the
2790 current flow into the electrode system, and the fault duration. These include:

- 2791 1) fault level at the new substation, or at the source (primary);
- 2792 2) resistance of the earthing system at the primary substation (R_a), and at the new
2793 distribution substation (R_b);
- 2794 3) circuit length and cable type(s);
- 2795 4) whether there is any overhead line in the circuit.

2796 For worst case studies, if there is any overhead line, the ground return current (I_{gr}) can be
2797 assumed equal to the earth fault current at the distribution substation (i.e. $I_{gr}\% = 100\%$).

2798 **9.3.2 Conductor and electrode sizing**

2799 Earth conductors at distribution substations will usually connect key items of plant such as
2800 transformer(s), ring main unit / switchgear, and low voltage cabinets. In many 'unit
2801 substations' these items may be supplied with bonding connections in place. These bonds
2802 must be sized as described in 5.6.1; in general they must be sized for the maximum
2803 foreseeable earth fault level. For ASC systems the limited ASC current must not be used
2804 (see Section 5.5.4). DNOs may wish to use the earth fault level at the primary substation, or
2805 higher value allowing for growth and uncertainty, up to the 3-phase fault current.

2806 Electrodes must have sufficient surface area to meet the requirements of Sections 5.5.5 and
2807 5.6.2. The worst case foreseeable 'electrode current' should be used for design purposes,
2808 this may be taken as the maximum earth-fault current at the substation or its source, or the
2809 larger of cross-country fault current or bypass fault current on ASC systems.

2810 Note: If detailed modelling of current distribution is carried out, it will be seen that the 'ground return current', if
2811 calculated using a contribution from a wide area network, will be significantly higher than the local 'electrode
2812 current'. The electrode current or ground return currents may be used for electrode design purposes, providing
2813 that connection to the wider network contribution is reliable. If any doubt exists as to the prolonged integrity of
2814 sheath return paths and/or auxiliary electrode connections, the larger earth fault level (calculated for a zero ohm
2815 fault) should be used.

2816 **9.3.3 Target resistance**

2817 A HV electrode system must be established for the substation, that is of sufficiently low
2818 resistance to ensure reliable protection operation and to limit EPR (and touch/step voltages)
2819 to acceptable levels. The design process in this respect is no different to that outlined in
2820 Section 5.4. The resistance that must be achieved is termed the 'target resistance', and may
2821 be specified with and without contribution from parallel systems. Use of a target resistance
2822 for the substation's earthing system, which ensures compliance with the safety criteria, is
2823 useful as it is a more readily understood parameter that can be achieved and tested by
2824 installers. 'Network contribution' is discussed in Section 9.4.3.

2825 For ground mounted substations, traditional custom and practice (permitted by previous
2826 versions of this standard) was to apply a target resistance (before connection to the network)
2827 of 1 ohm. If this could be achieved, it was permissible to combine the HV and LV earthing
2828 systems. No perimeter or grading electrodes were installed in such 'legacy' systems, and
2829 often only one vertical rod or horizontal electrode would be installed. This approach relied

2830 heavily on contributions from lead sheathed cables radiating away from the substation, and
2831 often passing under the operator's position. In this way, these cables provided a degree of
2832 potential grading (thus reducing touch potentials) as well as reducing the overall (combined)
2833 earth resistance of the substation. Experience has shown that this approach is no longer
2834 applicable, particularly given the now widespread use of polymeric (insulated sheath) cables.

2835 Network operators may find that different 'target values' for earth resistance are generally
2836 applicable in different geographical areas, and for overhead or underground networks, and
2837 thus may choose to adopt a 'rule of thumb' to assist designers and other connections
2838 providers. In any case, calculations or measurements sufficient to demonstrate that the
2839 installed system will be safe must be carried out at the design stage. Refer to 9.3.7.

2840 Target resistance values should consider all foreseeable running arrangements or network
2841 configurations, especially if the network is automated or remote controlled. Refer to Section
2842 9.9.

2843 **9.3.4 EPR design limit**

2844 A natural EPR design limit is imposed by a) consideration of transfer voltage onto the LV
2845 systems for combined HV/LV systems, and b) insulation withstand (stress voltage) between
2846 the HV and LV systems for segregated systems. See section 9.5 for more detail regarding
2847 separation distances. These considerations may for example, lead to typical design EPR
2848 limits of 3 kV (or higher, depending on equipment withstand voltage) for segregated systems,
2849 and 466 V* for combined systems.

2850 **9.3.5 Calculation of EPR**

2851 The EPR for a distribution substation, for faults at that substation, is calculated in the
2852 conventional manner, i.e. by multiplying the ground return current by the overall (combined)
2853 substation earth resistance.

2854 **9.3.5.1 Factors to consider:**

2855 The ground return current value is influenced by the earth fault current 'split' between the soil
2856 return path and the cable sheath. The impedance of the cable sheath(s) is made up of a 'self
2857 impedance' (fixed), and a 'mutual impedance' that is dependent on a number of factors.

2858 The earth fault current is influenced by the resistance of the earthing system and the
2859 impedance of the cable sheath. The source impedance (primary substation), the resistance
2860 of the primary substation earthing system, and in particular the method of neutral earthing
2861 will have an effect.

2862 For most accuracy, some form of iterative calculation or computer model will be required to
2863 explore the relationship between fault current, EPR, and substation resistance. However, in
2864 any such design there are often other factors or unknowns / variables which may be of more
2865 significance. For this reason it may be sufficient for a design to err on the side of caution by
2866 using a 'zero-ohm' earth fault level (the maximum theoretical fault level at the distribution
2867 substation calculated using zero sequence impedances for the circuit). Fault impedance can
2868 then be introduced only if necessary to achieve an economic or practicable solution.

2869 ENA EREC S34 provides a detailed discussion of EPR calculations and includes worked
2870 examples to assist with the calculation of ground return current.

* This value is 2x the 1 second touch voltage limit of 233 volts, and replaces the previous design figure of 430 Volts.

2871 9.3.5.2 Transfer Potential from source

2872 A second contribution to EPR comes from **Transfer Potential** 'exported' from the source
2873 substation, since any EPR at the source will be conveyed along the cable sheath and will
2874 appear (in part) at the new substation.

2875 Transfer potential need not been considered if there is any overhead line in the circuit, or if
2876 the new substation is not the first on the feeder and transfer potential is known to be of no
2877 significance at previous distribution substations.

2878 In determining the acceptable transfer potential from source, the relevant protection
2879 clearance time at the source should be used in touch/step calculations.

2880 **9.3.6 Step/Touch Potentials at the Substation**

2881 Many network operators or connection providers opt for a 'standard' design of distribution
2882 substation, and it is possible to establish, by modelling or calculation, the step and touch
2883 potentials as a % of EPR for each 'standard' layout. These values are influenced to a small
2884 degree by the depth of rods and the proximity of other earthed metalwork, but for design
2885 purposes can be taken as fixed for each layout. Typical values for touch potential within a
2886 3x3m 'unit substation' that has a perimeter 'grading ring' and corner electrodes are 20-40%
2887 of EPR. A substation built on a fine (and bonded) rebar mesh might present a touch voltage
2888 in the region of 10% or less of EPR.

2889 Substations that employ a single rod electrode, or similar 'legacy' design, are unlikely to limit
2890 touch potentials to less than 75% of EPR away from the electrode, and may have
2891 unacceptably high step potentials (gradients) in the vicinity of the electrode, depending on its
2892 depth of burial. Computer modelling using an appropriate package and soil model will
2893 normally be necessary to demonstrate safety unless the system is simple enough to permit
2894 'first principle' calculations such as those presented in EREC S34 or other relevant
2895 standards.

2896 The appropriate design limits for touch and step potential are given in Table 2 and are
2897 dependent on normal (calculated or worst case) protection operation.

2898 **9.3.7 Simplified approach**

2899 In some cases, a safe system can be achieved without detailed design calculations; DNOs
2900 may wish to instead adopt simple rules in certain geographic areas, provided these rules can
2901 be shown to produce a site with acceptable touch, step and transfer voltages. For example, a
2902 'standard' layout (perhaps consisting of a perimeter electrode and corner rods) might be
2903 appropriate if:

- 2904 a) 11 kV fault current is limited by reactor or resistor, and;
- 2905 b) there is a continuous cable connection to the primary substation, and;
- 2906 c) there is interconnection to the wider (HV and LV) network, and;
- 2907 d) the transfer potential from the Primary Substation is below the permissible touch
2908 voltage (taking into consideration clearance times at the primary);
- 2909 e) there is some 'potential grading' to limit step/touch to 50% or less of EPR (this
2910 assumes that site EPR will not exceed 2x permissible touch voltage limits).

2911 This approach is broadly consistent with that outlined in the design flowchart (Section 5.1).

2912

2913 Circumstances where the simplified approach is not appropriate:

2914 More detailed assessments might be needed if one or more of the following apply:

- 2915 a) there is any overhead line in circuit, or other break in the earth-return path;
- 2916 b) the substation is not interconnected to the HV or LV network;
- 2917 c) the secondary winding of the main transformer at the primary substation is solidly
2918 earthed.
- 2919 d) dedicated earth fault protection is not installed;
- 2920 e) the primary substation is a site where the EPR is greater than twice the permissible
2921 touch voltage limit for the applicable fault clearance times and there is a cable
2922 connection giving a transfer voltage consideration.

2923 In difficult circumstances a 'HPR*' but 'Safe (step/touch) voltage' design is allowable by
2924 appropriate use of grading electrode/mesh to control step and touch voltages. Alternatively,
2925 the EPR may be reduced by appropriate means (refer to Section 5.7.2 - Methods to improve
2926 design).

2927 * High (earth) Potential Rise

2928 **9.4 Network and other contributions**

2929 Distribution substations are commonly connected to larger metallic systems which can serve
2930 as an electrode. The following sub-sections describe typical contributions which may be
2931 included in design calculations.

2932 **9.4.1 Additional Electrode**

2933 In many cases it will be possible to supplement the substation's electrode system by laying
2934 bare copper, or a long 'rod nest' beneath incoming or outgoing cables (subject to
2935 separation/segregation where required), although when there are several parties involved in
2936 a project it may not be possible for the substation installer to do so without agreement with
2937 the cable installers (and landowners) at the design stage. Test facilities (e.g. an accessible
2938 loop) may be provided so that the integrity of buried horizontal electrode can be tested
2939 periodically.

2940 Electrode contribution such as this may be considered in calculations for EPR, touch/step
2941 voltages, and surface current density. It should not be included in design calculations if it is
2942 vulnerable to theft and/or damage. Suitable precautions should be taken to ensure the
2943 integrity of any such connections if they are safety critical.

2944 **9.4.2 Parallel contributions from interconnected HV and LV networks**

2945 If it is not practicable to achieve a 'safe' (compliant) design based on HV electrode (and
2946 additional electrode) contribution alone, then a reasonable 'parallel' contribution from the HV
2947 network may be included in the design (Section 9.4.3 below). However, this '**network
2948 contribution**' must not be the sole means of earthing and it is recommended that the local
2949 (HV) electrode contribution does not exceed **40 Ohms** or value sufficient to ensure reliable
2950 protection operation. In this way, there is some protection against failure of cable
2951 sheath/glands.

2952 The LV network contribution may also be used if it can be shown that it is safe to combine
2953 the HV and LV networks. Consideration should be given to the magnitude of fault current
2954 that will flow into other (parallel) systems, particularly in the case of solidly earthed HV

2955 systems, to ensure that the thermal ratings of any conductor or cable sheath are not
2956 exceeded.

2957 The thermal rating and surface current density requirements of sections 0 and **Error!**
2958 **Reference source not found.** should ideally be satisfied where possible without reliance on
2959 network contribution, thus allowing the earthing system to withstand fault current without
2960 damage should the cable sheath/gland connections fail.

2961 **9.4.3 Ascertaining Network Contribution**

2962 The HV network or LV network, (if applicable), can serve as an effective electrode system,
2963 and will provide a reduction in earth resistance when combined with the substation earth.

2964 The 'Network Contribution' element is difficult to establish accurately at the design stage, and
2965 measurements of the LV and HV network may be necessary to inform the design. However,
2966 due to the relatively routine nature of most **11 kV** (or HV) connections, a conservative
2967 estimate is often made to expedite the design process.

2968 The contribution from the network is (for older networks) made up of horizontal electrodes
2969 (un-insulated cable sheaths) and 'point' electrodes at distribution substations.

2970 The cable connected distribution substations (whether connected with polymeric HV cables
2971 or otherwise) can be modelled as a 'ladder network', with cable sheath impedances forming
2972 the series elements, and earth electrode resistances forming the parallel parts. This is
2973 termed the 'chain impedance', and is akin to the treatment of metal EHV towers in ENA
2974 **EREC S34**. The 'chain impedance' contribution from the HV network substations falls as
2975 distance increases from the new substation. In practice the substations within a 1-2 km
2976 radius are those which need to be considered.

2977 The 'horizontal electrode' contribution from any lead sheathed or hessian served HV cable
2978 sheaths can be treated in the same way as a buried horizontal conductor (**EREC S.34**). In
2979 practice, each conductor will have an effective length, beyond which no additional
2980 contribution can be assumed. A practical HV network will radiate from a substation in more
2981 than one direction, and a contribution can be assumed from each 'leg' provided their areas of
2982 influence do not overlap. In cases of doubt, these systems should be modelled using
2983 appropriate computer software, or measurements carried out (taking care to use a method
2984 appropriate to the size of the network).

2985 Calculated values for network contribution are often pessimistic in dense urban areas, where
2986 numerous parallel contributions (such as water and gas pipes, building foundations, etc.)
2987 may exist. If this is so, the designer may commission a measurement of network contribution
2988 (if possible), or may use an estimated value for network contribution, or may be able to
2989 demonstrate that the area is a Global Earthing System (GES) – see next section.

2990 **[Include reference to worked example here – S34?]**

2991 **9.4.4 Global Earthing Systems**

2992 A 'Global Earthing System' (GES), is a system where all equipment is bonded together, and
2993 the ground is saturated with metallic 'electrode contributions' in the form of metallic cable
2994 sheaths or bare conductors laid direct in soil. In such a system, the voltage on the surface of
2995 the soil will rise in sympathy with that of bonded HV steelwork under fault conditions, and the
2996 voltage differences (leading to touch voltage risk) are minimal. The term is often used to
2997 describe dense urban networks where measurements or detailed calculation of network
2998 contribution is not practical. Refer to annex O (informative) in BS EN 50522 for more detail.

2999 Network operators may wish to designate certain geographic areas as 'GES', in which case
3000 they will need to carry out measurements or analysis to demonstrate that the designation is
3001 appropriate. In addition they should carry out calculations to assess the 'target resistance'
3002 required in these areas; this is most easily achieved by assuming a low value of network
3003 contribution and designing an electrode system that is sufficient to satisfy protection
3004 operation, current density and thermal ratings in the absence of this network contribution. A
3005 standard design using perimeter electrode/rebar mesh etc. is usually still warranted for these
3006 reasons, using an appropriate resistance value to ensure safety.

3007 GES networks by definition operate with combined HV/LV earthing. It should be noted that
3008 touch potentials in GES networks can arise from transferred sources that may not be locally
3009 bonded, e.g. cable sheaths bonded to remote systems, metallic gas/water pipes with
3010 insulated covering, pilot/communications cables, and HV or LV insulated sheathed cables
3011 connected to metallic plant that is not bonded to the local 'global' earthing system. Such
3012 arrangements can cause 'islands' of higher potential inside a 'GES', and thus the benefits of
3013 a GES do not apply.

3014 **9.5 Transfer Potential onto LV network**

3015 **9.5.1 General**

3016 ESQC Regulations (2002) require that danger will not arise on the LV system as a
3017 consequence of HV faults. In practice, this means that the HV and LV earthing systems must
3018 be separated if the HV EPR cannot be limited to the applicable limit.

3019 NOTE: Previously, a design limit of 430 V has been applied, i.e. the HV and LV systems could be combined if the
3020 HV EPR was ≤ 430 V; in practice, this EPR would be impressed on the LV neutral/earth (star point). The voltage
3021 ultimately transferred to a consumer's LV earth terminal would be less than this, and the touch voltage appearing
3022 within an installation would be even lower.

3023 **9.5.2 Touch voltage on LV system as a result of HV faults**

3024 BS EN 50522 Section 6.1 Table 2 introduces the concept of 'F' factors. In order to combine
3025 HV and LV earthing systems, the HV EPR must not exceed $F \times U_{Tp}$, where U_{Tp} is the
3026 acceptable touch voltage as a function of HV fault clearance time.

3027 The 'F' factor described above relates to the percentage of EPR that will appear as a touch
3028 voltage on the LV network; it relates to the potential grading that will occur within an
3029 installation, as well as the decay in exported potential along a multiple earthed neutral
3030 conductor. The resultant touch voltage within the consumer's installation is necessarily
3031 subject to a number of factors beyond the control of any network operator.

3032 It is recommended that in the UK, a value of $F = 2$ is used unless:

- 3033 • The LV neutral/earth conductor is earthed at only one point, and:
- 3034 • The LV supplies only a small system that is isolated from the general mass of earth (e.g.
3035 a metal pillar on a concrete plinth without outgoing circuits).

3036 In such circumstances note (d) of BS EN 50522 Table 2 applies, which states: "*If the PEN or*
3037 *neutral conductor of the low voltage system is connected to earth only at the HV earthing*
3038 *system, the value of F shall be 1.*"

3039 In such circumstances a reduced EPR limit is applicable (e.g. 233 volts for a 1 second fault,
3040 see Table 1) because it must be assumed that the full EPR could appear as a touch voltage.

3041 In practice, for typical arrangements in the UK where $F = 2$, the HV EPR must not exceed
3042 466 volts if the systems are to be combined. This assumes a 1 second fault clearance time.
3043 Lower limits will apply for longer fault durations.

3044 **9.5.3 Stress Voltage**

3045 The Stress Voltage is the voltage across any two points in a substation or connected circuits.
3046 The Stress Voltage Limit relates to the insulation withstand requirement of cables and
3047 equipment.

3048 If HV and LV systems are combined then stress voltage limits are unlikely to be exceeded in
3049 the substation.

3050 For segregated HV and LV systems, stress voltage includes the difference in potential
3051 between the HV and LV earths, and may be assumed equal to the EPR of the substation.
3052 Typically this needs to be considered in the insulation withstand of the LV neutral bushing,
3053 LV neutral busbar supports, and LV cable screen where these are in close proximity to HV
3054 steelwork (a value of 3 kV or more is often quoted for modern equipment).

3055 Care is needed if bringing (remotely earthed) LV supplies into such sites, particularly if
3056 feeding into metal equipment cabinets that are earthed to HV steelwork. In such
3057 circumstances the insulation withstand within the equipment should be verified to ensure that
3058 that breakdown between LV phase/neutral/earth and HV steelwork cannot occur internally.
3059 Isolation transformers may be required to ensure that HV and LV systems do not flash
3060 across under HV fault conditions.

3061 Where these criteria are met, the requirements of BS EN 50522 (Table 2) will be achieved.

3062 **9.6 Combined HV and LV earthing**

3063 HV and LV earthing systems will generally be combined if the EPR on HV steelwork does not
3064 exceed LV transfer voltage limits described above (Section 9.5).

3065 In general:

- 3066
- combine HV & LV earths if voltage rise due to an HV or EHV earth fault is safe to apply to the transformer LV earth;
 - segregate HV & LV earths if voltage rise on LV transformer earth is unacceptable.
- 3067
- 3068

3069 A substation with EPR limited to 466V will usually be suitable for combined earthing if
3070 supplying a PME network*. This limit is subject to the caveats described in Section 9.5.2.

3071 **9.7 Segregated HV and LV earthing**

3072 For segregated earth systems, it is necessary to ensure that the LV electrode system is sited
3073 at sufficient distance from the HV electrode so that the voltage rise on the LV network is
3074 acceptable.

3075 **9.7.1 Separation Distance**

3076 Table 11 below provide an approximate minimum separation distance based on the EPR and
3077 acceptable LV transfer limits. The values are not significantly dependent on soil resistivity
3078 once the EPR is known, although a uniform soil model is assumed.

3079 The tables are calculated for 3x3m substations and 5x5m substations, assuming both have a
3080 perimeter electrode. These are calculated values as given by **EREC S34 Equation P3**. They
3081 have been compared with modelled results (for uniform soil) and the most conservative
3082 values are presented in these tables; this represents the voltage contour furthest from the

* A factor of 2 can be assumed for PME networks compliant with ENA ER G12/4, i.e. the voltage appearing at the customer's earth terminal is expected to be no more than 50% of the substation EPR. This paragraph also assumes that HV faults will clear within 1 second.

3083 substation, such that any LV electrode beyond this distance from the substation boundary
 3084 will be at or below the stated Vx figure under HV fault conditions.

3085

3086

Table 11 - Separation distance (m) from 3x3m substation.

EPR(V) Vx (V)	1000	2000	3000	5000
233	3.0	7.6	12.2	21.5
324	1.8	5.0	8.3	15.0
376	1.4	4.2	7.0	12.7
466	0.8	3.0	5.3	9.9

3087

3088

Table 12 – Separation distance (m) from 5x5m substation.

EPR(V) Vx (V)	1000	2000	3000	5000
233	5.0	12.7	20.4	35.8
324	3.0	8.4	13.9	25.0
376	2.3	6.9	11.7	21.2
466	1.4	5.1	8.9	16.6

3089

3090 NOTE: The following voltage limits are tabulated. For other values refer to Table 1:

- 3091 233 V = 1 second touch voltage limit on soil (or EPR limit with F=1);
- 3092 324 V = 162 V x 2, EPR limit applicable to 3 second faults with F=2;
- 3093 376 V = 188 V x 2, EPR limit applicable to 1.5 second faults with F=2;
- 3094 466 V = 233 V x 2, EPR limit applicable to 1 second faults with F=1.

3095

3096 These figures relate to the distance of the voltage contour at its furthest point from the
 3097 substation; in some cases (multiple earthed systems) the first LV neutral/earth electrode may
 3098 be sited inside the appropriate contour, refer to Section 9.7.4 and to worked examples in
 3099 ENA **EREC S34**.

3100 **9.7.2 Transfer voltage to third parties**

3101 For substations that are close to third parties, refer to Section 4.3.3. Consideration must be
 3102 given to railways, pipelines, telecommunications, cable TV, etc. if such utilities pass through
 3103 an area of high potential. The formulae **in EREC S34 (ref xxx)** may be used to provide an
 3104 indication of the EPR that may be transferred to nearby objects.

3105 **9.7.3 Further Considerations**

3106 The precise separation distance to be maintained between the HV and LV earthing systems
3107 is dependent on the EPR, the soil layer structure, and the physical layout of the earth
3108 electrodes. If necessary, it should be calculated during the design phase using the methods
3109 contained in **EREC S34** or via detailed simulation and must include the effect of electrodes
3110 located away from the substation (See Section 9.7.4).

3111 For existing substations or during commissioning of a new installation the transfer potential
3112 should be determined by measurement where practicable to confirm the calculated value. A
3113 'Separation Factor' of 0.9 or greater should be achieved (as described in Section 7.10).

3114 **9.7.4 Multiple LV electrodes on segregated systems**

3115 The separation distances above are those relating to the potential contour, such that the LV
3116 electrode(s) is/are sited beyond this. In practice, if these distances cannot be maintained,
3117 one or more electrodes on a multiple earthed neutral (e.g. PME system) may be sited within
3118 a higher voltage contour (but no closer than 3m) provided that the majority of the PME LV
3119 electrodes are sited beyond this. An above ground separation of 2m or more must be
3120 maintained to prevent simultaneous (hand-hand) contact between the systems.

3121 This assumes that the remainder of the LV system as a whole will have a resistance lower
3122 than that of the LV neutral electrode. The LV earthing system will have a 'centre of gravity'
3123 that lies outside the relevant contour, i.e. the transfer voltage will be the weighted average of
3124 that appearing at all LV electrodes. Any design based on these assumptions should be
3125 backed up by a measurement of separation factor for the installed arrangement.

3126 Refer also to **EREC S34** for calculations / worked examples.

3127 This relaxation does not apply to SNE systems or PNB systems where the neutral/earth is
3128 earthed at only one point.

3129 Where calculations based on the local LV electrode (closest to the substation) indicate
3130 impractical separation distances or excessive transfer potentials, the design should be
3131 reviewed and further LV electrodes installed at the end of LV feeder cables, connected via
3132 the neutral earth conductor. To maximise this beneficial effect, they should be located as far
3133 away from the HV electrode as possible and have a lower resistance than the LV electrode
3134 at the substation.

3135 **9.8 Situations where HV/LV systems cannot be segregated**

3136 In some situations it is not possible to segregate HV and LV systems safely without
3137 additional measures. One example is where an LV system exists within a HV system, or
3138 there are other similar physical constraints meaning that systems cannot reasonably be kept
3139 apart. Refer to BS EN 50522.

3140 In such circumstances, consideration should be given to combining the HV and LV systems
3141 and augmenting the electrode system(s) such that EPR and HV-LV transfer voltage is
3142 acceptable. If this is not practical, insulated mats/barriers could be considered in relevant
3143 areas.

3144 If necessary, the building or area could operate with a combined HV/LV system, safely yet
3145 with a high EPR provided all sources of transfer potential into/out of the 'high EPR area' can
3146 be excluded, and touch voltages are managed in and around the building. Refer to guidance
3147 on stress voltage given in Section 9.5.3 above.

3148 **9.9 Practical Considerations**

3149 HV networks are usually capable of being manually, or automatically reconfigured. The
3150 change in 'running arrangements' will affect various parameters including fault level,
3151 protection clearance time, and sheath return current/percentage.

3152 This complication means that a bespoke design for a distribution substation may not be valid
3153 if the running arrangement changes, and therefore the value of detailed design calculations
3154 on a 'dynamic' network is questionable. It is recommended that the design considers all
3155 foreseeable running arrangements, or (for simplicity) makes worst case assumptions
3156 regarding fault level, protection clearance time, and ground return current.

3157 A network operator may wish to adopt or provide a target resistance value (tailored to
3158 different geographic areas and different system earthing/protection scenarios), or other
3159 simplification of these design rules, for these reasons.

3160 **9.10 LV installations near High EPR sites**

3161 LV electrodes (segregated systems) as described above must be clear of the relevant
3162 voltage contour. The consideration also applies to any customer's TT electrode. If
3163 necessary the electrode(s) should be relocated or the shape of the high EPR zone altered by
3164 careful positioning of HV electrodes. In addition, where possible, LV electrode locations
3165 should place them clear of any fallen HV or EHV conductors.

3166 The siting of LV earths must consider zones with elevated potential e.g. some properties
3167 close to high EPR substations or EHV towers may themselves be in an area of high EPR, in
3168 which case provision of an LV earth derived from outside that zone may introduce a touch
3169 voltage risk at the installation, due to the LV earth being a remote earth reference. The
3170 arrangement can also pose a risk to other customers on the LV network if it will permit
3171 dangerous voltages to be impressed on the LV neutral/earth.

3172 Detailed modelling of HV/LV networks may demonstrate that voltage differences are not
3173 significant, due to the influence of the network on the shape of the contours; however such
3174 modelling may not be practicable. If any doubt exists, customers should not be offered an
3175 earth terminal, and no LV network earths shall be located in the area of high EPR. Cables
3176 passing through the area should be ducted or otherwise insulated to limit stress voltage to
3177 permissible limits. Typically a customer will use their own TT earth electrode; however if
3178 properties are in an area where EPR exceeds 1200 V, it is possible that they will experience
3179 L-E or N-E insulation failures in HV or EHV fault conditions; isolation transformers (or careful
3180 siting of HV:LV transformers and electrode systems) may be required; refer to Section 9.11
3181 below, and to risk assessment case studies given in Section 11.

3182 For PME electrode locations, reference should be made to ENA EREC G12.

3183 **9.11 Supplies to/from High EPR (HPR) sites**

3184 Network supplies into HPR sites invariably need care if the network earth is to remain
3185 segregated from the HPR site earth. In remaining separate, this can introduce touch voltage
3186 risk within the site. It is normally necessary to use a careful combination of bonding and
3187 segregation to ensure that danger does not arise within the site, or on the wider network.
3188 Sheath breaks (insulated glands) or unearthed overhead line sections are often convenient
3189 mechanisms to segregate the earthing systems.

3190 Similar considerations are required for LV supplies derived from HPR sites if these are to
3191 'export' to a wider area. Typically the LV neutral will be earthed outside the contours of
3192 highest potential and will be kept separate from all HPR steelwork in accordance with normal
3193 best practice. It may be necessary to apply ducting or additional insulation to prevent

3194 insulation breakdown and resultant fault current diversion from the HPR site into the wider
3195 network.

3196 Refer to **EREC S34** for specific examples, and to Section 11 (Case Studies).

3197 **9.11.1 Special Arrangements**

3198 Where a standard substation earthing arrangement is not applicable, other options may
3199 include:

- 3200 • combining HV & LV earths and managing touch and step potentials by installing an earth
3201 grid to enclose the installation supplied, i.e. effectively producing a large 'equipotential'
3202 safe zone, irrespective of EPR. (The design must take into account any metallic services
3203 such as Telecoms entering or leaving the installation, and is most useful in rural areas);
- 3204 • using an isolation transformer with a separate earthing system where an LV supply has to
3205 be taken outside a HPR substation site with a bonded HV/LV earth system;
- 3206 • use of isolation transformers to provide small capacity LV supplies to HPR ground
3207 mounted substations. E.g. LV supplies to tele-control equipment located within
3208 substations with segregated HV/LV earths (as described in 9.5.3). The (alternative) use
3209 of TT supplies (derived outside the High EPR zone) in such circumstance does not
3210 protect against insulation failure/flashover between the LV phase/neutral conductors and
3211 HV steelwork and could lead to the systems becoming inadvertently combined.
- 3212 • For supplies to mobile phone base stations refer to ENA EREC G78.

3213

3214 **10 Pole Mounted Substation and Equipment Earthing**

3215 This section describes earthing associated with HV Distribution Overhead Line Networks
3216 (excluding Tower lines).

3217 **10.1 General Comments & Assumptions**

3218 Extreme care must be taken when replacing pole mounted equipment with ground mounted
3219 equipment, since any existing earthing system is unlikely to be adequate to limit touch
3220 voltages to safe levels on the new installation.

3221 **10.2 Pole Mounted Transformers**

3222 Pole mounted transformers (PMTs) typically operate with a segregated HV and LV earthing
3223 system* (see section 9.6), and (since the metalwork is out of reach), a high EPR can be
3224 tolerated on the HV steelwork, provided that the LV electrode system is suitably separated
3225 from the HV system. Figure 4 below shows a typical arrangement where the main LV
3226 electrode is at the first pole (i.e. one span away) from the HV pole.

3227 The limiting factor for EPR is usually insulation withstand (stress voltage) on the LV cables,
3228 insulators and bushings at the pole-top; often a design value of 2 kV to 5 kV is assumed,
3229 depending on equipment specifications. A high EPR (with a small electrode system) is often
3230 inevitable on systems supplied by unearthed overhead lines as these do not enjoy the 'return
3231 path' offered by a metallic cable sheath/armour.

3232 The HV electrode must be sited and designed so that it will not present a danger in terms of
3233 hazardous step potentials (voltage gradient) around it. In this respect it is no different to that
3234 of ground mounted systems described above, except that PMTs are often in fields, close to
3235 livestock/animals, and with high ground return currents. Refer to Section 10.3.


3236

3237

* In some network areas, combined HV/LV systems were employed, so this cannot be assumed.

3238

Figure 4 – Typical Pole Mounted transformer earthing arrangement



3239

3240

3241 10.3 Electrode Configuration for Pole Mounted Equipment

3242 The following earth electrode designs assume that the overhead network does not have a
3243 return earth conductor. With this type of system the earth potential rise (EPR) of the local
3244 earth electrode typically will exceed tolerable touch, step and transfer potentials under earth
3245 fault conditions.

3246 Due to the possible hazardous touch potentials, earth conductors above ground shall be
3247 suitably insulated and provided with mechanical protection for a minimum height of 3 m or
3248 above the height of the anti-climbing device, whichever is greater. In addition the main earth
3249 conductor shall be suitably insulated for a minimum of 500 mm below ground level. Where
3250 the separation of electrodes is required guidance will be given in the relevant section.

3251 It is not always reasonably practicable to ensure in all situations that step potentials directly
3252 above an installed earth electrode system remain below permissible limits under earth fault
3253 conditions*. It is generally considered that the probability of an earth fault occurring whilst an
3254 individual happens, by chance, to be walking across the earth electrode at the same time, is
3255 extremely small. Therefore, in most circumstances no special precautions are required.
3256 However, at sensitive locations that are often frequented† by people, particularly children,
3257 and concentrations of livestock in stables or pens for example, precautions may be justified
3258 to eliminate or minimise the risk. This can usually be achieved by careful site selection or at
3259 the time of installation by installing the earth electrode in a direction away from the area of

* This is now less of an issue as step voltage limits have been considerably relaxed compared with previous versions of this specification.

† Refer to BS EN 50341-1 clause 6.2.4.2 for definition

3260 concern, burying the electrode as deep as practicable, and/or fencing the electrode off to
3261 prevent access.

3262 A similar situation also applies to personnel carrying out live operations such as HV drop-out
3263 fuse replacement, live-line tapping at earthed locations or ABSD switching using hook stick
3264 (hot-stick or insulated rods) techniques on earthed poles.

3265 **10.4 HV Earth Electrode Value**

3266 The HV electrode is (usually) the only return path for HV fault current (except relatively rare
3267 instances of cable fed PMTs, or cable terminations), and its resistance must generally be low
3268 enough to operate HV protection within design limits for the network (typically 1 to 1.5
3269 seconds maximum); electrode resistance values between 10 Ohm and 40 Ohm are often
3270 quoted for design purposes, with lower values providing increased resilience to lightning
3271 strikes. (Lower resistance values will limit the voltage rise on HV steelwork, and can prevent
3272 'back flashover' across LV bushings resulting from lightning surges, which would otherwise
3273 destroy the transformer winding).

3274 In general the lower the earth electrode resistance the more earth fault current will flow,
3275 resulting in more reliable operation of the circuit protection. Where surge arresters are used it
3276 is generally accepted that 10 Ohm is the preferred maximum value of earth electrode
3277 resistance for satisfactory operation of the arrester. This is in line with the preferred 10 Ohm
3278 value in BS EN 62305 for high frequency lightning earth electrodes.

3279 **10.5 Electrode Arrangement Selection Method**

3280 A common arrangement of rods used for earth electrodes associated with overhead line
3281 equipment is a run of parallel rods interconnected with a horizontal conductor.

3282 Resistance values may be calculated using formulae in **EREC S34**. The calculated values
3283 are considered to be conservative and are based on uniform soil resistivity.

3284 Calculated resistance values for the same rod and soil arrangements, using earthing design
3285 software are approximately 30% lower. Where the ground conditions are difficult, i.e. of high
3286 resistivity and/or rocky, the cost of obtaining the required earth electrode resistance value
3287 may warrant carrying out a site specific design.

3288

3289 **10.6 Earthed Operating Mechanisms Accessible From Ground Level**

3290 This section deals with pole mounted auto-reclosers (PMARs), sectionalisers, and air break
3291 switch disconnectors, that are all capable of being manually operated via an earthed metallic
3292 control box or switch mechanism. It is important to note that where a low voltage supply is
3293 required for control circuits, the supply should be derived from a dedicated transformer
3294 whose LV neutral is earthed directly to the installation's main HV earth conductor.

3295 There are several methods of minimising the risk from possibly hazardous touch and step
3296 potentials at such installations. In selecting the most appropriate method due account should
3297 be taken of the nature of the site, the accessibility of the equipment to third parties and the
3298 EPR level under fault conditions.

3299 (1) Use of wireless remote control for a unit mounted on the pole out of reach from
3300 ground level. With this method, an HV earth electrode system may be required
3301 where surge arresters are fitted or where the manufacturer of the equipment
3302 specifies. Where equipment is unearthed its mounting height shall comply with the
3303 relevant regulations.

3304 (2) Place the control box out of reach from ground level, access being via an insulated
3305 ladder. Again, with this method an HV earth electrode system may be required
3306 where surge arresters are fitted or where the manufacturer of the equipment
3307 specifies. Where equipment is unearthed its mounting height shall comply with the
3308 relevant regulations.

3309 Install an operator's earth mat and grading conductors to help provide an
3310 equipotential zone for the operator. Figure 5 and Figure 7 show an example of how
3311 this may be achieved. Whilst this minimises the hazards for the operator it requires
3312 that the installation be carried out with great diligence. It is also important that the
3313 future integrity of the earth electrode is ensured. Misplacement of the earth
3314 electrode conductors can result in the operator being exposed to hazardous touch
3315 and step potentials. Consideration needs to be given to the selection of the site
3316 prior to installation to ensure that the required earth electrode configuration can be
3317 installed correctly, and maintained adequately into the future. Use of suitable
3318 personal protective equipment for switching operations may also be considered as
3319 an additional risk control measure; dielectric (insulated) footwear rated at >7 kV is
3320 now commonly used to protect operators against step potentials when stepping
3321 on/off the platform.

3322 (3) Where mechanical damage is likely, for example in farmland, protective measures
3323 need to be considered to ensure the integrity of the earth electrode and the earth
3324 mat. An example would be to install and fix the earth mat on or in a raft of concrete
3325 or fence off the area surrounding the earth mat.

3326 The use of grading conductors to minimise step potentials in the immediate vicinity of the
3327 operator's earth mat may prove impractical in some circumstances, particularly where there
3328 is a danger of them being damaged by ploughing. Burying the grading conductors at a
3329 greater depth will significantly reduce their effectiveness. Keeping step potentials within
3330 tolerable limits can be extremely difficult and in some case impracticable. In such
3331 circumstances alternative mitigation should be considered.

3332 Factors such as, soil structure, operating voltage, type of HV system earthing (solid or
3333 resistance) and system impedance all have an effect on the value of step and touch
3334 potentials created around the earth electrode, whereas protection clearance times will have a
3335 bearing in determining the tolerable touch and step potential limits. At some sites it may be
3336 prudent to restrict access to the control box, for example by use of insulating barriers or


3337 fences, so that it is not possible for third parties to touch the control box and where operators
3338 can only touch the control box when standing on the earth mat.

3339 It should be noted that burying the operator's earth mat will increase the touch potential
3340 between the control box and the surface of the ground above the earth mat; the greater the
3341 depth of the mat, the greater the potential difference between the soil surface above the mat
3342 and the control box. The hazard this presents can be managed by covering the mat with a
3343 high resistivity material which will increase the impedance path between the hands and feet.
3344 Burying the mat will also have the effect of reducing the step potentials for an operator
3345 stepping off the mat. However, the prime concern is to minimise the touch potentials as these
3346 are considered to be more hazardous than step potentials. Where the mat is buried the touch
3347 potential and the hazard it presents will be site specific, being dependent upon the actual
3348 EPR and the protection clearance times for the given site, therefore a site specific design is
3349 recommended. The surface mat shown in Figure 5 results in negligible touch potentials for
3350 the operator standing on the mat, irrespective of the EPR.

3351 In all cases it is an option to use control measures to mitigate risk if a company deems this is
3352 the most appropriate solution in the circumstances.

3353

3354




3355

3356

3357

NOTE: This arrangement does not exclude the use of a portable earth mat.
Figure 5 — Earthing Arrangement for a PMAR with Ground Level Control Box.



3358

3359 **Figure 6 — Alternative Earthing Arrangement for a PMAR with Ground Level Control Box.**

3360

3361 **10.7 Air Break Switch Disconnect (ABSD) with an isolated operating mechanism**

3362 There are several methods of controlling hazardous touch and step potentials, at pole
3363 mounted ABSDs.

3364 Install an insulated rod operated ABSD at high level that does not require an earth electrode.
3365 Where equipment is unearthed its mounting height shall comply with the relevant regulations.
3366 This option removes the risk of the operator being exposed to the hazard of touch and step
3367 potentials that could occur under certain earth fault conditions when adopting method 2
3368 below.

3369 (1) Install an ABSD that is operated manually from ground level with a separate HV
3370 earth electrode and operator's earth mat. This approach relies on effective
3371 separation of the HV earth electrode that connects the HV steelwork to earth, and
3372 the operator's earth mat connected to the operating handle. This arrangement is
3373 typical of existing earthed ABSD equipment found on rural overhead line distribution
3374 networks.

3375 Separation is achieved by placing the HV earth electrode a minimum of 5m away from the
3376 base of the operator's earth mat using insulated earth conductor from the electrode to the HV
3377 steel work, and by insulating the operating handle from the switch mechanism using an
3378 insulating insert in the operating rod. The top of the insert needs to be a minimum of 3m from
3379 ground level when in its lowest position. The operating handle needs to be connected to an
3380 earth mat positioned where the operator will stand to operate the handle. If the earth mat is
3381 installed such that it is visible the operator can verify its existence and its connection to the
3382 handle prior to operating the handle. The continuing effective segregation of the HV earth
3383 electrode and the operator's earth mat is the most important aspect of the way in which this
3384 arrangement seeks to control the touch and step potentials around the operator's earth mat
3385 position. To minimise the possibility of contact between the buried insulated earth conductor
3386 and the surrounding soil, should the earth conductor's insulation fail, the conductor could be
3387 installed in plastic ducting.

3388 Where mechanical damage is possible, for example in farmland, protective measures may
3389 need to be considered to ensure the integrity of the earth electrode and the earth mat. An
3390 example would be to install and fix the earth mat on or in a raft of concrete or fence off the
3391 area surrounding the earth mat using non-conducting fencing.

3392 Under earth fault conditions the HV earth electrode will rise in potential with respect to
3393 remote earth. A potential gradient will be produced around the electrode; the potentials being
3394 highest immediately above the electrode and reducing rapidly with distance. The earth mat
3395 will be located within the potential gradient surrounding the HV earth electrode, but due to
3396 the separation distance of 5m the potential at that point with respect to remote earth will be
3397 relatively small. The surface level earth mat for the operating handle and the handle itself will
3398 rise in potential but there will be effectively no potential difference between the mat and
3399 handle.

3400 Under earth fault conditions, assuming the correct separation distance between the HV earth
3401 electrode and the operating handle earth mat, should the operator have one foot on the mat
3402 and one off the mat, touch and step potentials surrounding the earth mat should not exceed
3403 tolerable limits. However, there is a risk of hazardous touch and step potentials arising if the
3404 HV earth electrode short circuits to the operating handle earth mat. The risk of such a short
3405 circuit occurring is extremely small provided that the earth installation is correctly installed,
3406 inspected and maintained.

3407 The actual size and shape of the earth mat shall be such as to ensure that the operator will
3408 be standing towards its centre whilst operating the handle. Notwithstanding this requirement

3409 the minimum size of earth mat should be 1 m by 1 m. Due consideration needs to be taken of
3410 the type of handle, whether it is a two handed or single handed operation and whether the
3411 operator may be left or right handed. A purpose made mat is recommended in preference to
3412 a mat formed on site out of bare conductor, as this eliminates problems of variation in shape
3413 and size that can occur with the latter. Where a buried earth mat is used, the maximum depth
3414 of the mat should be no greater than 300 mm.

3415 Under normal earth fault conditions the touch potential for both buried and surface
3416 mounted scenarios will be negligible. When deciding between the use of a buried
3417 earth mat and a surface mounted mat the following issues shall be considered:

3418 • A surface mounted mat will allow the operator to visually confirm both the
3419 position of the earth mat relative to the handle and also the integrity of the
3420 connection between the earth mat and the handle.

3421 • A surface mounted mat will minimise any touch potentials between the soil
3422 surface on the mat and the handle, both under normal earth fault conditions
3423 and under second fault conditions where the handle and the earth mat
3424 become energised although this scenario should be less likely because
3425 effective segregation can be visually confirmed before operation.

3426 • Conversely a surface mounted mat will maximise the step potential around
3427 the mat although this will only be an issue if the mat and handle become
3428 energised under a second fault scenario.

3429 • A buried earth mat will not allow the operator to visually confirm either its
3430 position relative to the handle, or the integrity of its physical connection to the
3431 handle before operation.


3432 • Burying the earth mat will increase the value of any touch potential between
3433 the handle and the soil above the earth mat, this potential will increase with
3434 depth.

3435 • To maintain the same effective soil surface area with a buried earth mat for
3436 the operator to stand on and minimise any resulting touch potentials requires
3437 a significantly larger mat than for a surface mounted mat.

3438 • Where a second fault occurs that energises the operating handle and earth
3439 mat, with a buried earth mat the touch potential could exceed tolerable
3440 levels.

3441 • Conversely burying the mat will have the effect of reducing the step
3442 potentials under such conditions for an operator stepping off the mat.

3443 The use of suitably rated PPE in these situations would assist in minimising the risk of
3444 exposure to possibly hazardous potentials.



3445

3446

Figure 7 - Recommended Earthing Arrangement for an ABSD.

3447 **10.8 Surge Arresters**

3448 The preferred value for the surge arrester earth electrode resistance is 10 Ohm or less.
 3449 Ideally this electrode system should be installed as close to the base of the pole as possible.
 3450 However, for some locations where it may be necessary for an operator to carry out
 3451 switching operations on the HV networks at that pole this may create unacceptable step
 3452 potential hazards. In such cases the HV earth electrode should be installed away from the
 3453 pole at a location where the step potential is calculated to be safe (typically 5m) for the
 3454 operator to stand when carrying out any switching operations, see section 15.8. It is
 3455 preferable to have a small number of deep earth rods rather than many shallow rods or plain
 3456 horizontal conductor. The earth conductor connecting the base of the surge arresters to the
 3457 earth electrode system should be as straight as possible, having as few bends in as is
 3458 practicable. Refer to Section 6.14 for further details.

3459 Where other HV equipment is situated on the same pole and requires an earth electrode,
 3460 only one HV earth electrode needs to be installed*. The preference is to install an earth
 3461 conductor directly from the surge arresters to the buried HV earth electrode, and then
 3462 connect the earths of the other items of HV equipment to it on the pole. At sites where
 3463 switching may take place the earth lead should be insulated to the first earth rod which
 3464 should be a minimum of 5m from the operating mat for an ABSD or 5m from the operating
 3465 position for equipment that requires the use of hot-sticks or insulated rods. Additional
 3466 protection may be achieved by placing the earth lead in ducting to that point.

3467 * Note: This practice differs for that in substations as described in Section 6.14, where separate power frequency
 3468 and high frequency earths are required.

3469 **10.9 Cable Terminations**

3470 Typically, cable terminations on poles are associated with surge arresters or other HV
 3471 equipment, in which case the cable sheath or screen is connected directly to the surge

3472 arrester or HV equipment main earth conductor. In the absence of surge arresters or other
3473 earthed HV equipment the cable will require the installation of an earth electrode.

3474 **10.10 Operations at Earthed Equipment Locations**

3475 At earthed installations fed via overhead line systems, it is essential to have robust
3476 operational procedures to minimise the risk from the possible hazards associated with the
3477 high rise of earth potential under earth fault conditions. It should be noted that the risk
3478 increases during live fault switching operations. It is beyond the scope of this document to
3479 detail such procedures but consideration should be given to the following points.

3480 Earth systems are usually designed to minimise hazards under main protection operation.
3481 They are not designed, unless specifically required, to minimise hazards under secondary or
3482 backup protection conditions. This is an important point to note when developing fault
3483 switching operational procedures. Temporarily disabling parts of the protection system,
3484 reconfiguring the network, or raising protection settings to aid in fault location during fault
3485 switching can give rise to touch, step and transfer potentials of a duration that the associated
3486 earth systems have not been designed to take account of.

3487 Precautions shall be taken, by virtue of the equipment design and earthing arrangements to
3488 minimise any touch and step potential hazards. For example, where rod operated (insulated
3489 hot sticks) equipment is used, the simplest way of minimising hazards from touch and step
3490 potentials is by, where practicable, placing the earthing electrode, not serving as grading
3491 conductors, away from the position where the operator will be standing. Where several
3492 people are present during operations, any person not actively carrying out operations should
3493 stand well clear of the installed earth electrode.

3494 **10.11 Installation**

3495 The following points should be considered when installing an earth electrode system for
3496 overhead line equipment:

- 3497 (1) Materials and jointing methods shall comply with the requirements of BS 7430.
- 3498 (2) Installation teams should have a basic understanding of the functions of an earth
3499 system, and should carry out installations to a detailed specification.
- 3500 (3) Typically, installing a horizontal earth electrode system at a greater depth than 500mm
3501 will not have any significant effect on reducing the earth electrode's resistance value.
3502 However, it is recommended that the electrode is buried as deep as is practically
3503 possible to minimise surface potentials and the possibility of mechanical damage.
3504 Where ploughing is a concern the electrode should be buried at a minimum depth of
3505 1m.
- 3506 (4) Ensure maximum separation is achieved on the pole between HV earth conductors and
3507 ABSD handle earth mat conductors.
- 3508 (5) It is recommended that a test point is made available for future connection of an earth
3509 tester above ground so that the earth electrode resistance can be measured. This test
3510 point should be installed and constructed so as to prevent unauthorised access, and on
3511 ABSD's prevent possible flashover to the operator's handle and associated earth mat.
- 3512 (6) Welded, brazed or compression connections are preferable to bolted connections for
3513 underground joints.
- 3514 (7) Corrosive materials and high resistivity materials such as sand should not be used as a
3515 backfill immediately around the electrode.

- 3516 (8) The earth resistance of the installed electrode should be measured and recorded.
- 3517 (9) Where a buried operator's earth mat has been installed, the mat should have two
3518 connections made to the operating handle.

3519 **10.12 Inspection & Maintenance of Earth Installations**

3520 **10.12.1 Items to Inspect**

3521 During routine line inspections it is recommended that the following items are visually
3522 inspected and their condition recorded, with any defects being rectified in a timely manner:

- 3523 (1) ABSD earth mat and connection to operating handle.
- 3524 (2) Separation of HV and operator's handle earth on an ABSD.
- 3525 (3) Separation of HV and LV earth conductors on the pole.
- 3526 (4) Check that the anti-climbing device does not compromise the separation between the
3527 HV earth conductor and the operating handle.
- 3528 (5) Insulation of HV and LV earth conductors.
- 3529 (6) Mechanical protection of HV and LV earth conductors.
- 3530 (7) Bonding of plant and equipment.
- 3531 (8) State of connections, including any test point.
- 3532 (9) Signs of possible mechanical damage to earth electrode and buried earth mats.

3533 **10.12.2 Items to Examine**

3534 Periodically examine a random sample of buried earth electrodes and buried ABSD handle
3535 earth mats, and rectify any defects found. The examination should check for the following:

- 3536 (1) position of earth mat and electrode locations relative to ABSD handle and operator's
3537 position;
- 3538 (2) insulating insert in the ABSD operating rod;
- 3539 (3) state of underground connections;
- 3540 (4) state of earth electrode components, particularly galvanised steel rods;
- 3541 (5) state of insulation on underground earth conductors where separation of electrodes is
3542 required.

3543 NOTE: When carrying out this work protective measures shall be taken to ensure the safety of personnel during
3544 fault conditions.

3545 The results of the examinations can then be used to assist in developing ongoing inspection
3546 and maintenance policy, and procedures.

3547 **10.12.3 Items to Test**

- 3548 (1) Periodically test the earth electrode resistance. For the relatively small earth systems
3549 typically associated with overhead line equipment, a small 3 terminal earth tester is
3550 adequate. The test should be carried out in accordance with the manufacturer's
3551 instructions.

- 3552 (2) Regularly test the continuity between operating handle and the operator's earth mat.
- 3553 (3) Regularly test the continuity of buried earth mats.
- 3554 (4) Periodically test a random sample of insulating inserts used in ABSD operating
3555 mechanisms.
- 3556 Important: When carrying out these measurements the equipment should be made dead or
3557 where this is not practicable a risk assessment should be carried out and suitable test
3558 procedures should be adopted which safeguard the operator from any rise of earth potential.
3559 Such procedures may for example include the use of insulating gloves and boots, mats and /
3560 or fully insulated test equipment.
- 3561
- 3562
- 3563

3564

3565 11 Case studies / examples


3566 Agreed topics:

3567

3568 1) Risk assessment case studies – house near substation.

3569


3570



3571

3572

3573




3574 2) Large substation design, fed from tower line (already in S34 so leave out?) [S34 includes 33kV OH
3575 and U/G substation design and 132kV Neutral current reduction and reduction factors]

3576

3577 3) Small distribution substation with cable connection [Physical layout and practical issues; refer to
3578 (and include) calculations and results in S34]

3579




Example drawing (courtesy UKPN)

3580
 3581

3582

3583 4) LV Supply into HOT (HPR) site [1 or 2 examples] – see next page for UKPN extract



3584

3585

3586

3587

3588

3589

3590

3591

3592

3593

3594

3595

3596

3597

3598

3599

3600

3601

3602

3603

3604

3605

3606

3607

3608

3609

3610

3611

3612

3613

3614

3615 This page deliberately left blank.

3616

3617